persons, or portion thereof, of the *occupant load* of the floor area served by the lobby.

**Exception:** The size of lobbies serving multiple banks of elevators shall have the minimum floor area *approved* on an individual basis and shall be consistent with the building's fire safety and evacuation plan.

**3008.11.5 Signage.** An *approved* sign, written in both Arabic and English, indicating elevators are suitable for occupant self-evacuation shall be posted on all floors adjacent to each elevator call station serving occupant evacuation elevators.

**3008.12 Lobby status indicator.** Each occupant evacuation elevator lobby shall be equipped with a status indicator arranged to display all of the following information:

- 1. An illuminated green light and the message, "Elevators available for occupant evacuation" when the elevators are operating in normal service and the fire alarm system is indicating an alarm in the building.
- 2. An illuminated red light and the message, "Elevators out of service, use exit stairs" when the elevators are in Phase I emergency recall operation in accordance with the requirements in ASME A17.1/CSA B44.
- 3. No illuminated light or message when the elevators are operating in normal service.

**3008.13 Two-way communication system.** A two-way communication system shall be provided in each occupant evacuation elevator lobby for the purpose of initiating communication with the fire command center or an alternative location *approved* by the Civil Protection and Safety Department of Civil Defence.

**3008.13.1 Design and installation.** The two-way communication system shall include audible and visible signals and shall be designed and installed in accordance with the requirements of Abu Dhabi/ICC A117.1.

**3008.13.2 Instructions.** Instructions for the use of the two-way communication system along with the location of the station shall be permanently located adjacent to each station. Signage shall comply with the Abu Dhabi/ICC A117.1 requirements for visual characters.

**3008.14 Elevator system monitoring.** The occupant evacuation elevators shall be continuously monitored at the fire command center or a central control point *approved* by the Civil Protection and Safety Department of Civil Defence and arranged to display all of the following information:

- 1. Floor location of each elevator car.
- 2. Direction of travel of each elevator car.
- 3. Status of each elevator car with respect to whether it is occupied.
- 4. Status of normal power to the elevator equipment, elevator controller cooling equipment, and elevator machine room ventilation and cooling equipment.
- 5. Status of standby or emergency power system that provides backup power to the elevator equipment, elevator controller cooling equipment, and elevator machine room ventilation and cooling equipment.