

Windward Parapet

Load Case A

1. Windward parapet pressure (p_1) is determined using the positive wall pressure (p_5) zones 4 or 5 from Table 30.7-2.

Leeward parapet pressure (p_2) is determined using the negative roof pressure (p_7) zones 2 or 3 from Table 30.7-2.

Leeward Parapet

Load Case B

- Windward parapet pressure (p₃) is determined using the positive wall pressure (p₅) zones 4 or 5 from Table 30.7-2.
- 2. Leeward parapet pressure (p_4) is determined using the negative wall pressure (p_6) zones 4 or 5 from Table 30.7-2.