# TEENDOW CS08

English quick guide for the 2.5 L dehumidifier with 7-color light. Model shown on the product is CS08; the Best Buy listing identifies the US version as US-CS08-NEW. This is a concise English guide based on the matching German CS08 manual and product information, not an official Teendow English manual.

| | |
|---|---|
| MODEL | CS08 / US-CS08-NEW |
| WATER TANK | 2.5 L |
| MOISTURE REMOVAL | Up to 1,100 mL per day at 30 C / 80% RH |
| POWER | 75 W |
| US POWER | AC 120 V, 60 Hz |
| SIZE | 202 x 150 x 352 mm |
| WEIGHT | 2.33 kg net |

## Before first use

- Set the unit upright on a level, stable surface. Keep it away from wet areas and place it in a well-ventilated room.
- For better results, close the room doors and windows. Keep the air inlet and dry-air outlet clear; leave at least 10 cm of open space around the air outlet.
- The manual lists 15-40 C (59-104 F) as the preferred operating range and says not to use below 5 C (41 F).
- Do not insert objects into the air outlet. Keep children from using or playing with the unit unsupervised.

## Controls

| | |
|---|---|
| **POWER** | Press once to turn the dehumidifier on; press again to turn it off. |
| **MOON / NIGHT** | Press for quieter, lower-speed operation with the lights off. Press again to return to normal mode. Moisture collection is slower in night mode. |
| **LIGHT** | Press to cycle the ambient colors. When the color you want appears, press to hold it. Continue cycling to switch the light off. |

The red water-level light may come on when the tank is full, not seated correctly, or its cover is not fitted properly. The unit may stop and sound a warning.

# EMPTYING AND DRAINING

Empty the tank when the red light or warning indicates that it is full.

## Empty the water tank

- Turn the unit off and unplug it.
- Pull the water tank straight out from the back of the dehumidifier.
- Remove the tank cover and pour out the collected water.
- Refit the tank cover, slide the tank fully back into the unit, then plug in and restart. A poorly seated tank may keep the unit from running.

## Optional continuous drainage

The manual shows using a drain hose through the opening at the bottom of the tank. The hose and stopper are separate accessories.

- Turn the unit off, unplug it, and remove the tank.
- Remove the drain-hole stopper and keep it for later.
- Push the hose securely into the drain hole at the bottom of the tank.
- Replace the tank cover, route the hose to a suitable drain with a steady downward slope, and reinstall the tank completely. Make sure the hose is not kinked or raised above the outlet.

Do not run continuous drainage unless the hose is securely connected and the tank is seated. Check the hose and drain for leaks after setup.

## Aromatherapy pad (optional)

- Switch off and unplug the unit before adding oil. Open the small aromatherapy compartment on top.
- Use only plant-based essential oil. Add 2-3 drops to the pad; start with 1 drop. Do not exceed 5 drops per use.
- Place the pad flat in its slot and close the compartment. Do not pour oil into the water tank.
- Avoid perfume, sprays, oils with dyes or additives, and chemical solvents. Keep oils away from children and pets. Air-dry the pad daily and replace it about monthly.

# CARE AND TROUBLESHOOTING

Unplug the unit before cleaning or checking it.

| SYMPTOM | CHECK / ACTION |
|---|---|
| Red light or warning sound | Tank full: empty it and reinstall it. Tank misaligned or cover loose: reseat the tank and cover. |
| Unit will not start | Check that the adapter is plugged in and the outlet works. Confirm the tank is seated. Keep the outlet clear and leave at least 10 cm around it. |
| Little water collected | Removal varies with room temperature, humidity, and room size. Close doors/windows and allow more time in a warm, humid room. Night mode collects more slowly. |

## Cleaning

- Wipe the outside with a soft, slightly damp cloth. Do not use abrasive cleaners or solvents.
- Keep the air inlet and outlet free of dust and debris. Let the unit dry before plugging it back in.

## Warranty and support

The box in your photo says “Lifetime Warranty,” but the matching German manual says one year. Those statements conflict, so keep the Best Buy receipt and ask the seller or Teendow to confirm which warranty applies to your unit. The manual lists CS@teendow.com for support.

## Sources and limitations

Prepared from the Teendow CS08 manual (German; product pages 2-10 contain the operating information) and the Best Buy listing for model US-CS08-NEW. Otto return instructions included later in the source PDF were excluded because they are not dehumidifier instructions. If any instruction here conflicts with a label on your unit, follow the product label and contact the seller/manufacturer.

Open the original German CS08 manual | Best Buy product listing