Firmware Version V1.26

TMCLTM FIRMWARE MANUAL



TMCM-1181

1-axis Stepper Controller / Driver up to 6.3 RMS / 24V DC USB, RS485 [or RS232]

UNIQUE FEATURES:





TRINAMIC Motion Control GmbH & Co. KG Hamburg, Germany

www.trinamic.com



Table of Contents

1	Feature	S	4
2	Putting	the Module into Operation	6
	_	sic Set-Up	
		Connecting the module	
		Start the TMCL-IDE Software Development Environment	
	2.2 Us	ing TMCL Direct Mode	8
	2.2.1	Important Motor Settings	
	2.3 Tes	sting with a Simple TMCL Program	
3	TMCL a	nd the TMCL-IDE: Introduction	11
	3.1 Bir	nary Command Format	11
	3.1.1	Checksum Calculation	12
	3.2 Re	ply Format	12
	3.2.1	Status Codes	13
	3.3 Sta	andalone Applications	13
	3.4 TM	CL Command Overview	14
	3.4.1	TMCL Commands	14
	3.4.2	Commands Listed According to Subject Area	15
	3.5 Co	mmands	
	3.5.1	ROR (rotate right)	19
	3.5.2	ROL (rotate left)	
	3.5.3	MST (motor stop)	
	3.5.4	MVP (move to position)	
	3.5.5	SAP (set axis parameter)	
	3.5.6	GAP (get axis parameter)	
	3.5.7	STAP (store axis parameter)	
	3.5.8	RSAP (restore axis parameter)	
	3.5.9	SGP (set global parameter)	
		GGP (get global parameter)	
		STGP (store global parameter)	
		RSGP (restore global parameter)	
		RFS (reference search)	
	3.5.14	SIO (set input / output)	
	3.5.15	GIO (get input /output)	
	3.5.16	CALC (calculate)	
		COMP (compare)	
	3.5.18	JC (jump conditional)	
		JA (jump always)	
		CSUB (call subroutine)	
		RSUB (return from subroutine)	
		WAIT (wait for an event to occur)	
		STOP (stop TMCL program execution)	
		CALCX (calculate using the X register)	
		AAP (accumulator to axis parameter)	
		AGP (accumulator to global parameter)	
		CLE (clear error flags)	
		VECT (set interrupt vector)	
		EI (enable interrupt)	
		DI (disable interrupt)	
		RETI (return from interrupt)	
		Customer specific TMCL command extension (UFO UF7/user function)	
	3.5.33	Request target position reached event	
	3.5.34	TMCL Control Functions	
4		rameters	
_	•	illGuard2	
		olStep Related Axis Parameters	
5		parameters	
•	JIODAL	Parameters	0 -

	5.1	Bank 0	. 65
		Bank 1	
		Bank 2	
		Bank 3	
6	Hint	s and Tips	. 69
		Reference Search	
	6.2	Changing the Prescaler Value of an Encoder	. 72
	6.3	Using the RS485 Interface	. 72
7	Life	Support Policy	. 73
8	Revi	sion History	. 74
		Firmware Revision	
	8.2	Document Revision	. 74
9	Refe	rences	. 74

1 Features

The TMCM-1181 is a single axis controller/driver module for 2-phase bipolar stepper motors. It is highly integrated and can be used in many decentralized applications. The module can be mounted on the back of NEMA34 (86mm flange size) stepper motors and has been designed for coil currents up to 6.3A RMS (programmable) and 24V DC supply voltage. With its high energy efficiency from TRINAMIC's coolStep™ technology cost for power consumption is kept down. The TMCL™ firmware supports both, standalone operation and direct mode.

MAIN CHARACTERISTICS

Motion controller

- Motion profile calculation in real-time
- On the fly alteration of motor parameters (e.g. position, velocity, acceleration)
- High performance microcontroller for overall system control and serial communication protocol handling

Bipolar stepper motor driver

- Up to 256 microsteps per full step
- High-efficient operation, low power dissipation
- Dynamic current control
- Integrated protection
- stallGuard2 feature for stall detection
- coolStep feature for reduced power consumption and heat dissipation

Encoder

- sensOstep magnetic encoder (max. 1024 increments per rotation) e.g. for step-loss detection under all operating conditions and positioning supervision

Interfaces

- inputs for stop switches (left and right) and home switch
- 2 analog inputs
- 2 general purpose outputs (open collector with freewheeling diodes)
- USB, RS485 [or RS232] communication interfaces

Software

 TMCL: standalone operation or remote controlled operation, program memory (non volatile) for up to 2048 TMCL commands, and PC-based application development software TMCL-IDE available for free.

Electrical and mechanical data

- Supply voltage: +24V DC nominal (11... 28V DC)
- Motor current: up to 6.3A RMS (programmable)

Refer to separate TMCM-1181 Hardware Manual, too.

TRINAMICS UNIQUE FEATURES - EASY TO USE WITH TMCL

stallGuard2™

stallGuard2 is a high-precision sensorless load measurement using the back EMF on the coils. It can be used for stall detection as well as other uses at loads below those which stall the motor. The stallGuard2 measurement value changes linearly over a wide range of load, velocity, and current settings. At maximum motor load, the value goes to zero or near to zero. This is the most energy-efficient point of operation for the motor.




Figure 1.1 stallGuard2 load measurement SG as a function of load

coolStep™

coolStep is a load-adaptive automatic current scaling based on the load measurement via stallGuard2 adapting the required current to the load. Energy consumption can be reduced by as much as 75%. coolStep allows substantial energy savings, especially for motors which see varying loads or operate at a high duty cycle. Because a stepper motor application needs to work with a torque reserve of 30% to 50%, even a constant-load application allows significant energy savings because coolStep automatically enables torque reserve when required. Reducing power consumption keeps the system cooler, increases motor life, and allows reducing cost.




Figure 1.2 Energy efficiency example with coolStep

2 Putting the Module into Operation

Here you can find basic information for putting your TMCM-1181 into operation. If you are already common with TRINAMICs modules you may skip this chapter.

The things you need:

- TMCM-1181 with fitting motor
- Interface (USB/RS485/[RS232]) suitable to your module with cables
- Nominal supply voltage +24V DC for your module
- TMCL-IDE program and PC

PRECAUTIONS

Do not connect or disconnect the TMCM-1181-RD while powered! Do not connect or disconnect the motor while powered! Do not exceed the maximum power supply voltage of 28V DC! Note, that the module is not protected against reverse polarity! START WITH POWER SUPPLY OFF!

2.1 Basic Set-Up

The following paragraph will guide you through the steps of connecting the unit and making first movements with the motor.

2.1.1 Connecting the module




Figure 2.1: Starting up

1. Connect power supply

2. Connect communication interface

Connect USB interface (use a normal USB cable)

Download and install the file TMCM-1181.inf.

3. Connect motor

Pin	Label	Description
1	0A1	Motor coil A
2	OA2	Motor coil A
3	OB1	Motor coil B
4	OB2	Motor coil B

4. Switch ON the power supply

Turn power ON. The green LED will start flashing slowly and the motor will be powered but in standstill now.

If this does not occur, switch power OFF and check your connections as well as the power supply.

2.1.2 Start the TMCL-IDE Software Development Environment

The TMCL-IDE is available on www.trinamic.com.

Installing the TMCL-IDE:

Make sure the COM port you intend to use is not blocked by another program.


Open TMCL-IDE by clicking TMCL.exe.

Choose **Setup** and **Options** and thereafter the **Connection tab**.

Choose COM port and type with the parameters shown in Figure 2.2 (baud rate 9600). Click OK.

USB interface

If the file TMCM-1181.inf is installed correctly, the module will be identified automatically.







Figure 2.2 Setup dialogue and connection tab of the TMCL-IDE.


Please refer to the TMCL-IDE User Manual for more information (see www.TRINAMIC.com).

2.2 Using TMCL Direct Mode

1. Start TMCL Direct Mode.



2. If the communication is established the TMCM-1181 is automatically detected. If the module is not detected, please check all points above (cables, interface, power supply, COM port, baud rate).



3. Issue a command by choosing *Instruction*, *Type* (if necessary), *Motor*, and *Value* and click *Execute* to send it to the module.

Examples:

- ROR rotate right, motor 0, value 500
- -> Click Execute. The first motor is rotating now.
- MST motor stop, motor 0
- -> Click Execute. The first motor stops now.

Top right of the *TMCL Direct Mode* window is the button *Copy to editor*. Click here to copy the chosen command and create your own TMCL program. The command will be shown immediately on the editor.

NOTE

Please mind chapter 3 (programming techniques) of the TMCL-IDE User Manual on <u>www.trinamic.com</u>. Here you will find information about creating general structures of TMCL programs. In particular initialization, main loop, symbolic constants, variables, and subroutines are described there. Further you can learn how to mix direct mode and stand alone mode.

Chapter 4 of this manual (axis parameters) includes a diagram which points out the coolStep related axis parameters and their functions. This can help you configuring your module to meet your needs.

2.2.1 Important Motor Settings

There are some axis parameters which have to be adjusted right in the beginning after installing your module. Please set the upper limiting values for the speed (axis parameter 4), the acceleration (axis parameter 5), and the current (axis parameter 6). Further set the standby current (axis parameter 7) and choose your microstep resolution with axis parameter 140. Please use the SAP (Set Axis Parameter) command for adjusting these values. The SAP command is described in paragraph 3.5.5. You can use the TMCM-IDE direct mode for easily configuring your module.

ATTENTION

The most important motor setting is the *absolute maximum motor current* setting, since too high values might cause motor damage!

IMPORTANT AXIS PARAMETERS FOR MOTOR SETTING

Number	Axis Parameter	Description			Range [Unit]	
4	Maximum	Should not	ould not exceed the physically highest possible			0 2047
	positioning	value. Adjus	ue. Adjust the pulse divisor (axis parameter 154), if			
	speed	the speed v	speed value is very low (<50) or above the uppe			$\left[\frac{16\text{MHz}}{65536} \cdot 2^{pulse_divisor} \frac{\mu \text{steps}}{\text{sec}}\right]$
		limit.	,			
5	Maximum	The limit fo	r acceleratio	n (and dece	eleration). Changing	0 2047*1
	acceleration	this paran	neter requ	iires re-ca	lculation of the	
		acceleration	factor (no. 1	L46) and the	acceleration divisor	
		(no. 137), v	vhich is doi	ne automati	cally. See TMC 429	
		datasheet fo	or calculation	n of physica	l units.	
6	Absolute max.				ue means 100% of	0 255
	current	the maximu	m current o	f the modul	e. The current	$I_{peak} = < value > \times \frac{4A}{255}$
	(CS / Current	adjustment	is within th	e range 0 2	255 and can be	255
	Scale)	adjusted in		3		$I_{RMS} = < value > \times \frac{2.8A}{255}$
		0 7	7987	160 167	240 247	255
		8 15	88 95	168 175	248 255	
		16 23	96 103	176 183		
		24 31	104 111	184 191		
		32 39 40 47	112 119 120 127	192 199 200 207		
		48 55	128 135	208 215		
		56 63	136 143	216 223		
		64 71	144 151	224 231		
		72 79	152 159	232 239		
		The most in	nost important motor setting, since too high		since too high	
			rost important motor setting, since too mgm s might cause motor damage!			
7	Standby current		he current limit two seconds after the motor has		0 255	
,	Standby current	stopped.	diffic two	seconds an	ter the motor has	
		stopped.				$I_{peak} = < value > \times \frac{4A}{255}$
						$I_{RMS} = \langle value \rangle \times \frac{2.8A}{255}$
140	Microstep	0 full st	ер			0 8
	resolution	1 half st	tep			
		2 4 mici	rosteps			
			rosteps			
			crosteps			
			5 32 microsteps			
			128 microsteps			
		J	пс. озтерз			l

*1 Unit of acceleration: $\frac{16MHz^2}{536870912 \cdot 2^{puls_divisor + ramp_divisor}} \frac{\text{microsteps}}{\text{sec}^2}$

www.trinamic.com

2.3 Testing with a Simple TMCL Program

Type in the following program:

```
ROL 0, 500
                                  //Rotate motor 0 with speed 500
        WAIT TICKS, 0, 500
        MST 0
        ROR 0, 500
                                   //Rotate motor 0 with 500
        WAIT TICKS, 0, 500
        MST 0
        SAP 4, 0, 500
                                    //Set max. Velocity
        SAP 5, 0, 50
                                    //Set max. Acceleration
        MVP ABS, 0, 10000
                                    //Move to Position 10000
Loop:
        WAIT POS, 0, 0
                                    //Wait until position reached
        MVP ABS, 0, -10000
                                    //Move to Position -10000
        WAIT POS, 0, 0
                                    //Wait until position reached
                                    //Infinite Loop
        JA Loop
```



- 1. Click the **Assemble** icon to convert the TMCL into machine code.
- 2. Then download the program to the TMCM-1181 module by clicking the *Download* icon.
- 3. Press icon *Run*. The desired program will be executed.
- 4. Click the **Stop** button to stop the program.

3 TMCL and the TMCL-IDE: Introduction

As with most TRINAMIC modules the software running on the microprocessor of the TMCM-1181 consists of two parts, a boot loader and the firmware itself. Whereas the boot loader is installed during production and testing at TRINAMIC and remains untouched throughout the whole lifetime, the firmware can be updated by the user. New versions can be downloaded free of charge from the TRINAMIC website (http://www.trinamic.com).

The TMCM-1181 supports TMCL direct mode (binary commands) and standalone TMCL program execution. You can store up to 2048 TMCL instructions on it.

In direct mode and most cases the TMCL communication over USB or RS485 / [RS232] follows a strict master/slave relationship. That is, a host computer (e.g. PC/PLC) acting as the interface bus master will send a command to the TMCL-1181-RD. The TMCL interpreter on the module will then interpret this command, do the initialization of the motion controller, read inputs and write outputs or whatever is necessary according to the specified command. As soon as this step has been done, the module will send a reply back over USB / RS485 / [RS232] to the bus master. Only then should the master transfer the next command. Normally, the module will just switch to transmission and occupy the bus for a reply, otherwise it will stay in receive mode. It will not send any data over the interface without receiving a command first. This way, any collision on the bus will be avoided when there are more than two nodes connected to a single bus.

The Trinamic Motion Control Language [TMCL] provides a set of structured motion control commands. Every motion control command can be given by a host computer or can be stored in an EEPROM on the TMCM module to form programs that run standalone on the module. For this purpose there are not only motion control commands but also commands to control the program structure (like conditional jumps, compare and calculating).

Every command has a binary representation and a mnemonic. The binary format is used to send commands from the host to a module in direct mode, whereas the mnemonic format is used for easy usage of the commands when developing standalone TMCL applications using the TMCL-IDE (IDE means *Integrated Development Environment*).

There is also a set of configuration variables for the axis and for global parameters which allow individual configuration of nearly every function of a module. This manual gives a detailed description of all TMCL commands and their usage.

3.1 Binary Command Format

Every command has a mnemonic and a binary representation. When commands are sent from a host to a module, the binary format has to be used. Every command consists of a one-byte command field, a one-byte type field, a one-byte motor/bank field and a four-byte value field. So the binary representation of a command always has seven bytes. When a command is to be sent via USB or RS485 / [RS232] interface, it has to be enclosed by an address byte at the beginning and a checksum byte at the end. In this case it consists of nine bytes.

The binary command format for USB / RS485 / [RS232] is as follows:

Bytes	Meaning	
1	Module address	
1	Command number	
1	Type number	
1	Motor or Bank number	
4	Value (MSB first!)	
1	Checksum	

The checksum is calculated by adding up all the other bytes using an 8-bit addition.

3.1.1 Checksum Calculation

As mentioned above, the checksum is calculated by adding up all bytes (including the module address byte) using 8-bit addition. Here are two examples to show how to do this:

```
in C:
 unsigned char i, Checksum;
 unsigned char Command[9];
 //Set the "Command" array to the desired command
 Checksum = Command[0];
 for(i=1; i<8; i++)
   Checksum+=Command[i];
 Command[8]=Checksum; //insert checksum as last byte of the command
 //Now, send it to the module
    in Delphi:
var
 i, Checksum: byte;
 Command: array[0..8] of byte;
  //Set the "Command" array to the desired command
  //Calculate the Checksum:
  Checksum:=Command[0];
  for i:=1 to 7 do Checksum:=Checksum+Command[i];
  Command[8]:=Checksum;
  //Now, send the "Command" array (9 bytes) to the module
```

3.2 Reply Format

Every time a command has been sent to a module, the module sends a reply. The reply format for RS485/RS232/USB is as follows:

Bytes	Meaning	
1	Reply address	
1	Module address	
1	Status (e.g. 100 means no error)	
1	Command number	
4	Value (MSB first!)	
1	Checksum	

The checksum is also calculated by adding up all the other bytes using an 8-bit addition. Do not send the next command before you have received the reply!

3.2.1 Status Codes

The reply contains a status code. The status code can have one of the following values:

Code	Meaning		
100	Successfully executed, no error		
101	Command loaded into TMCL		
	program EEPROM		
1	Wrong checksum		
2	Invalid command		
3	Wrong type		
4	Invalid value		
5	Configuration EEPROM locked		
6	Command not available		

3.3 Standalone Applications

The module is equipped with a TMCL memory for storing TMCL applications. You can use TMCL-IDE for developing standalone TMCL applications. You can download a program into the EEPROM and afterwards it will run on the module. The TMCL-IDE contains an editor and the TMCL assembler where the commands can be entered using their mnemonic format. They will be assembled automatically into their binary representations. Afterwards this code can be downloaded into the module to be executed there.

3.4 TMCL Command Overview

In this section a short overview of the TMCL commands is given.

3.4.1 TMCL Commands

Command	Number	Parameter	Description
ROR	1	<motor number="">, <velocity></velocity></motor>	Rotate right with specified velocity
ROL	2	<motor number="">, <velocity></velocity></motor>	Rotate left with specified velocity
MST	3	<motor number=""></motor>	Stop motor movement
MVP	4	ABS REL COORD, <motor number="">, <pre><pre><pre><pre><pre><pre><pre><pre></pre></pre></pre></pre></pre></pre></pre></pre></motor>	Move to position (absolute or relative)
SAP	5	<pre><pre><pre><pre><pre><pre><pre><pre></pre></pre></pre></pre></pre></pre></pre></pre>	Set axis parameter (motion control specific settings)
GAP	6	<pre><parameter>, <motor number=""></motor></parameter></pre>	Get axis parameter (read out motion control specific settings)
STAP	7	<pre><parameter>, <motor number=""></motor></parameter></pre>	Store axis parameter permanently (non volatile)
RSAP	8	<pre><parameter>, <motor number=""></motor></parameter></pre>	Restore axis parameter
SGP	9	<pre><parameter>, <bank number="">, value</bank></parameter></pre>	Set global parameter (module specific settings e.g. communication settings or TMCL™ user variables)
GGP	10	<parameter>, <bank number=""></bank></parameter>	Get global parameter (read out module specific settings e.g. communication settings or TMCL™ user variables)
STGP	11	<pre><parameter>, <bank number=""></bank></parameter></pre>	Store global parameter (TMCL™ user variables only)
RSGP	12	<pre><parameter>, <bank number=""></bank></parameter></pre>	Restore global parameter (TMCL™ user variable only)
RFS	13	START STOP STATUS, <motor number=""></motor>	Reference search
SIO	14	<port number="">, <bank number="">, <value></value></bank></port>	Set digital output to specified value
GIO	15	<pre><port number="">, <bank number=""></bank></port></pre>	Get value of analogue/digital input
CALC	19	<pre><operation>, <value></value></operation></pre>	Process accumulator & value
COMP	20	<value></value>	Compare accumulator <-> value
JC	21	<condition>, <jump address=""></jump></condition>	Jump conditional
JA	22	<jump address=""></jump>	Jump absolute
CSUB	23	<subroutine address=""></subroutine>	Call subroutine
RSUB	24		Return from subroutine
EI	25	<interrupt number=""></interrupt>	Enable interrupt
DI	26	<interrupt number=""></interrupt>	Disable interrupt
WAIT	27	<condition>, <motor number="">, <ticks></ticks></motor></condition>	Wait with further program execution
STOP	28	·	Stop program execution
SCO SCO	30	<pre><coordinate number="">, <motor number="">, <position></position></motor></coordinate></pre>	Set coordinate
GCO	31	<coordinate number="">, <motor number=""></motor></coordinate>	Get coordinate
CCO	32	<coordinate number="">, <motor number=""></motor></coordinate>	Capture coordinate
CALCX	33	<operation></operation>	Process accumulator & X-register
AAP	34	<pre><parameter>, <motor number=""></motor></parameter></pre>	Accumulator to axis parameter
AGP	35	<pre><pre><pre><pre><pre><pre><pre><pre></pre></pre></pre></pre></pre></pre></pre></pre>	Accumulator to global parameter
VECT	37	<interrupt number="">, <label></label></interrupt>	Set interrupt vector
RETI	38		Return from interrupt
ACO	39	<coordinate number="">, <motor number=""></motor></coordinate>	Accu to coordinate

3.4.2 Commands Listed According to Subject Area

3.4.2.1 Motion Commands

These commands control the motion of the motor. They are the most important commands and can be used in direct mode or in standalone mode.

Mnemonic	Command number	Meaning
ROL	2	Rotate left
ROR	1	Rotate right
MVP	4	Move to position
MST	3	Motor stop
RFS	13	Reference search
SC0	30	Store coordinate
CCO	32	Capture coordinate
GCO	31	Get coordinate

3.4.2.2 Parameter Commands

These commands are used to set, read and store axis parameters or global parameters. Axis parameters can be set independently for each axis, whereas global parameters control the behavior of the module itself. These commands can also be used in direct mode and in standalone mode.

Mnemonic	Command number	Meaning
SAP	5	Set axis parameter
GAP	6	Get axis parameter
STAP	7	Store axis parameter into EEPROM
RSAP	8	Restore axis parameter from EEPROM
SGP	9	Set global parameter
GGP	10	Get global parameter
STGP	11	Store global parameter into EEPROM
RSGP	12	Restore global parameter from EEPROM

3.4.2.3 Control Commands

These commands are used to control the program flow (loops, conditions, jumps etc.). It does not make sense to use them in direct mode. They are intended for standalone mode only.

Mnemonic	Command number	Meaning
JA	22	Jump always
JC	21	Jump conditional
COMP	20	Compare accumulator with constant value
CSUB	23	Call subroutine
RSUB	24	Return from subroutine
WAIT	27	Wait for a specified event
STOP	28	End of a TMCL™ program

3.4.2.4 I/O Port Commands

These commands control the external I/O ports and can be used in direct mode and in standalone mode.

Mnemonic	Command number	Meaning
SIO	14	Set output
GIO	15	Get input

3.4.2.5 Calculation Commands

These commands are intended to be used for calculations within TMCL™ applications. Although they could also be used in direct mode it does not make much sense to do so.

Mnemonic	Command number	Meaning
CALC	19	Calculate using the accumulator and a
		constant value
CALCX	33	Calculate using the accumulator and the X
		register
AAP	34	Copy accumulator to an axis parameter
AGP	35	Copy accumulator to a global parameter
ACO	39	Copy accu to coordinate

For calculating purposes there is an accumulator (or accu or A register) and an X register. When executed in a TMCL program (in standalone mode), all TMCL commands that read a value store the result in the accumulator. The X register can be used as an additional memory when doing calculations. It can be loaded from the accumulator.

When a command that reads a value is executed in direct mode the accumulator will not be affected. This means that while a TMCLTM program is running on the module (standalone mode), a host can still send commands like GAP and GGP to the module (e.g. to query the actual position of the motor) without affecting the flow of the TMCLTM program running on the module.

3.4.2.6 Interrupt Commands

Due to some customer requests, interrupt processing has been introduced in the TMCL™ firmware for ARM based modules.

Mnemonic	Command number Meaning				
EI	25	Enable interrupt			
DI	26	Disable interrupt			
VECT	37	Set interrupt vector			
RETI	38	Return from interrupt			

3.4.2.6.1 Interrupt Types

There are many different interrupts in TMCL, like timer interrupts, stop switch interrupts, position reached interrupts, and input pin change interrupts. Each of these interrupts has its own interrupt vector. Each interrupt vector is identified by its interrupt number. Please use the TMCL included file *Interrupts.inc* for symbolic constants of the interrupt numbers.

3.4.2.6.2 Interrupt Processing

When an interrupt occurs and this interrupt is enabled and a valid interrupt vector has been defined for that interrupt, the normal TMCL program flow will be interrupted and the interrupt handling routine will be called. Before an interrupt handling routine gets called, the context of the normal program will be saved automatically (i.e. accumulator register, X register, TMCL flags).

There is no interrupt nesting, i.e. all other interrupts are disabled while an interrupt handling routine is being executed.

On return from an interrupt handling routine, the context of the normal program will automatically be restored and the execution of the normal program will be continued.

3.4.2.6.3 Interrupt Vectors

The following table shows all interrupt vectors that can be used.

Interrupt number	Interrupt type
0	Timer 0
1	Timer 1
2	Timer 2
3	Target position reached
15	stallGuard2
21	Deviation
27	Left stop switch
28	Right stop switch
39	Input change 0
40	Input change 1
41	Input change 2
42	Input change 3
255	Global interrupts

3.4.2.6.4 Further Configuration of Interrupts

Some interrupts need further configuration (e.g. the timer interval of a timer interrupt). This can be done using SGP commands with parameter bank 3 (SGP <type>, 3, <value>). Please refer to the SGP command (paragraph 3.5.9) for further information about that.

3.4.2.6.5 Using Interrupts in TMCL

For using an interrupt proceed as follows:

- Define an interrupt handling routine using the VECT command.
- If necessary, configure the interrupt using an SGP <type>, 3, <value> command.
- Enable the interrupt using an EI <interrupt> command.
- Globally enable interrupts using an EI 255 command.
- An interrupt handling routine must always end with a RETI command

The following example shows the use of a timer interrupt:

```
VECT o, TimeroIrq //define the interrupt vector
    SGP 0, 3, 1000
                       //configure the interrupt: set its period to 1000ms
    EI o
                       //enable this interrupt
    EI 255
                       //globally switch on interrupt processing
//Main program: toggles output 3, using a WAIT command for the delay
Loop:
    SIO 3, 2, 1
   WAIT TICKS, o, 50
    SIO 3, 2, 0
   WAIT TICKS, o, 50
    JA Loop
//Here is the interrupt handling routine
TimeroIrq:
    GIO o, 2
                       //check if OUTo is high
    JC NZ, OutoOff
                       //jump if not
    SIO 0, 2, 1
                       //switch OUTo high
    RETI
                       //end of interrupt
OutoOff:
    SIO o, 2, o
                       //switch OUTo low
    RETI
                       //end of interrupt
```

In the example above, the interrupt numbers are used directly. To make the program better readable use the provided include file *Interrupts.inc*. This file defines symbolic constants for all interrupt numbers which can be used in all interrupt commands. The beginning of the program above then looks like the following:

```
#include Interrupts.inc
   VECT TI_TIMERo, TimeroIrq
   SGP TI_TIMERo, 3, 1000
   EI TI_TIMERo
   EI TI_GLOBAL
```

Please also take a look at the other example programs.

3.5 Commands

The module specific commands are explained in more detail on the following pages. They are listed according to their command number.

3.5.1 ROR (rotate right)

With this command the motor will be instructed to rotate with a specified velocity in *right* direction (increasing the position counter).

Internal function: First, velocity mode is selected. Then, the velocity value is transferred to axis parameter #0 (target velocity).

The module is based on the TMC429 stepper motor controller and the TMC262 power driver. This makes possible choosing a velocity between 0 and 2047.

Related commands: ROL, MST, SAP, GAP

Mnemonic: ROR 0, <velocity>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
1	(don't care)	0*	<velocity> 0 2047</velocity>
			U 2047

^{*}motor number is always 0 as only one motor is involved

Reply in direct mode:

STATUS	VALUE		
100 – OK	(don't care)		

Example:

Rotate right, velocity = 350 *Mnemonic:* ROR 0, 350

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$01	\$00	\$00	\$00	\$00	\$01	\$5e

3.5.2 ROL (rotate left)

With this command the motor will be instructed to rotate with a specified velocity (opposite direction compared to ROR, decreasing the position counter).

Internal function: First, velocity mode is selected. Then, the velocity value is transferred to axis parameter #0 (target velocity).

The module is based on the TMC429 stepper motor controller and the TMC262 power driver. This makes possible choosing a velocity between 0 and 2047.

Related commands: ROR, MST, SAP, GAP

Mnemonic: ROL 0, <velocity>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
2	(don't care)	0*	<velocity> 0 2047</velocity>

^{*}motor number is always 0 as only one motor is involved

Reply in direct mode:

STATUS	VALUE
100 - OK	(don't care)

Example:

Rotate left, velocity = 1200 Mnemonic: ROL 0, 1200

Binarv:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$02	\$00	\$00	\$00	\$00	\$04	\$b0

3.5.3 MST (motor stop)

With this command the motor will be instructed to stop with a soft stop.

Internal function: The axis parameter target velocity is set to zero.

Related commands: ROL, ROR, SAP, GAP

Mnemonic: MST 0

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE	
3	(don't care)	0*	(don't care)	

^{*}motor number is always 0 as only one motor is involved

Reply in direct mode:

STATUS	VALUE		
100 – OK	(don't care)		

Example:

Stop motor

Mnemonic: MST 0

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$03	\$00	\$00	\$00	\$00	\$00	\$00

3.5.4 MVP(move to position)

With this command the motor will be instructed to move to a specified relative or absolute position. It will use the acceleration/deceleration ramp and the positioning speed programmed into the unit. This command is non-blocking – that is, a reply will be sent immediately after command interpretation and initialization of the motion controller. Further commands may follow without waiting for the motor reaching its end position. The maximum velocity and acceleration are defined by axis parameters #4 and #5.

The range of the MVP command is 32 bit signed (-2.147.483.648... +2.147.483.647). Positioning can be interrupted using MST, ROL or ROR commands.

Two operation types are available:

- Moving to an absolute position in the range from -2.147.483.648... +2.147.483.647 (-2³¹... 2³¹-1).
- Starting a relative movement by means of an offset to the actual position. In this case, the new resulting position value must not exceed the above mentioned limits, too.

Please note, that the distance between the actual position and the new one should not be more than 2³¹-1 microsteps. Otherwise the motor will run in the opposite direction in order to take the shorter distance.

Internal function: A new position value is transferred to the axis parameter #2 target position".

Related commands: SAP, GAP, and MST

Mnemonic: MVP <ABS|REL>, 0, <position|offset| number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
4	0 ABS – absolute	0*	<position></position>
	1 REL – relative	0	<offset></offset>

^{*}motor number is always 0 as only one motor is involved

Reply in direct mode:

STATUS	VALUE		
100 – OK	(don't care)		

Example:

Move motor to (absolute) position 90000

Mnemonic: MVP ABS, 0, 9000

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$04	\$00	\$00	\$00	\$01	\$5f	\$90

Example:

Move motor from current position 1000 steps backward (move relative -1000) *Mnemonic:* MVP REL, 0, -1000

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$04	\$01	\$00	\$ff	\$ff	\$fc	\$18

3.5.5 SAP (set axis parameter)

With this command most of the motion control parameters of the module can be specified. The settings will be stored in SRAM and therefore are volatile. That is, information will be lost after power off. *Please use command STAP (store axis parameter) in order to store any setting permanently.*

For a table with parameters and values which can be used together with this command please refer to chapter 4.

Internal function: The parameter format is converted ignoring leading zeros (or ones for negative values). The parameter is transferred to the correct position in the appropriate device.

Related commands: GAP, STAP, RSAP, AAP

Mnemonic: SAP <parameter number>, 0, <value>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
5	<parameter< th=""><th>0*</th><th><value></value></th></parameter<>	0*	<value></value>
	number>		

^{*}motor number is always 0 as only one motor is involved

Reply in direct mode:

STATUS	VALUE
100 - OK	(don't care)

Example:

Set the absolute maximum current of motor to 200mA *Mnemonic:* SAP 6, 0, 200

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$05	\$06	\$00	\$00	\$00	\$00	\$c8

3.5.6 GAP (get axis parameter)

Most parameters of the TMCM-1181 can be adjusted individually for the axis. With this parameter they can be read out. In standalone mode the requested value is also transferred to the accumulator register for further processing purposes (such as conditioned jumps). In direct mode the value read is only output in the *value* field of the reply (without affecting the accumulator).

For a table with parameters and values which can be used together with this command please refer to chapter 4.

Internal function: The parameter is read out of the correct position in the appropriate device. The parameter format is converted adding leading zeros (or ones for negative values).

Related commands: SAP, STAP, AAP, RSAP

Mnemonic: GAP <parameter number>, 0

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE	
6	<pre><parameter number=""></parameter></pre>	0*	(don't care)	

^{*}motor number is always 0 as only one motor is involved

Reply in direct mode:

STATUS	VALUE		
100 – OK	(don't care)		

Example:

Get the actual position of motor *Mnemonic:* GAP 0, 1

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$06	\$01	\$00	\$00	\$00	\$00	\$00

Reply:

Byte Index	0	1	2	3	4	5	6	7
Function	Host-	Target-	Status	Instructio	Operand	Operand	Operand	Operand
	address	address		n	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$02	\$01	\$64	\$06	\$00	\$00	\$02	\$c7

[⇒] status=no error, position=711

3.5.7 STAP (store axis parameter)

An axis parameter previously set with a *Set Axis Parameter* command (SAP) will be stored permanent. Most parameters are automatically restored after power up (refer to axis parameter list in chapter 4).

For a table with parameters and values which can be used together with this command please refer to chapter 4.

Internal function: An axis parameter value stored in SRAM will be transferred to EEPROM and loaded from EEPORM after next power up.

Related commands: SAP, RSAP, GAP, AAP

Mnemonic: STAP <parameter number>, 0

Binary representation:

INSTRUCTION NO.	ТҮРЕ	MOT/BANK	VALUE
7	<pre><parameter number=""></parameter></pre>	0*1	(don't care)*2

^{*1}motor number is always 0 as only one motor is involved

Reply in direct mode:

STATUS	VALUE
100 - OK	(don't care)

Parameter ranges:

Parameter number	Motor number	Value
s. chapter 4	0	s. chapter 4

Example:

Store the maximum speed of motor *Mnemonic:* STAP 4, 0

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Туре	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$07	\$04	\$00	\$00	\$00	\$00	\$00

Note: The STAP command will not have any effect when the configuration EEPROM is locked (refer to 5.1). In direct mode, the error code 5 (configuration EEPROM locked, see also section 3.2.1) will be returned in this case.

^{*}²the value operand of this function has no effect. Instead, the currently used value (e.g. selected by SAP) is saved.

3.5.8 RSAP (restore axis parameter)

For all configuration-related axis parameters non-volatile memory locations are provided. By default, most parameters are automatically restored after power up (refer to axis parameter list in chapter 4). A single parameter that has been changed before can be reset by this instruction also.

For a table with parameters and values which can be used together with this command please refer to chapter 4.

Internal function: The specified parameter is copied from the configuration EEPROM memory to its RAM location.

Relate commands: SAP, STAP, GAP, and AAP

Mnemonic: RSAP <parameter number>, 0

Binary representation:

INSTRUCTION NO.	ТҮРЕ	MOT/BANK	VALUE
8	<pre><parameter number=""></parameter></pre>	0*	(don't care)

^{*}motor number is always 0 as only one motor is involved

Reply structure in direct mode:

STATUS	VALUE		
100 – OK	(don't care)		

Example:

Restore the maximum current of motor

Mnemonic: RSAP 6, 0

Byte Index	0	1	2	3	4	5	6	7
Function	Target- address	Instruction Number	Type	Motor/ Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$08	\$06	\$00	\$00	\$00	\$00	\$00

3.5.9 SGP (set global parameter)

With this command most of the module specific parameters not directly related to motion control can be specified and the TMCL user variables can be changed. Global parameters are related to the host interface, peripherals or application specific variables. The different groups of these parameters are organized in banks to allow a larger total number for future products. Currently, only bank 0 and 1 are used for global parameters, and bank 2 is used for user variables.

All module settings will automatically be stored non-volatile (internal EEPROM of the processor). The TMCL user variables will not be stored in the EEPROM automatically, but this can be done by using STGP commands.

For a table with parameters and bank numbers which can be used together with this command please refer to chapter 5.

Internal function: the parameter format is converted ignoring leading zeros (or ones for negative values). The parameter is transferred to the correct position in the appropriate (on board) device.

Related commands: GGP, STGP, RSGP, AGP

Mnemonic: SGP <parameter number>, <bank number>, <value>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
9	<parameter number=""></parameter>	<bank number=""></bank>	<value></value>

Reply in direct mode:

STATUS	VALUE		
100 – OK	(don't care)		

Example:

Set the serial address of the target device to 3 *Mnemonic:* SGP 66, 0, 3

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Туре	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$09	\$42	\$00	\$00	\$00	\$00	\$03

3.5.10 GGP (get global parameter)

All global parameters can be read with this function. Global parameters are related to the host interface, peripherals or application specific variables. The different groups of these parameters are organized in banks to allow a larger total number for future products. Currently, only bank 0 and 1 are used for global parameters, and bank 2 is used for user variables.

For a table with parameters and bank numbers which can be used together with this command please refer to chapter 5.

Internal function: The parameter is read out of the correct position in the appropriate device. The parameter format is converted adding leading zeros (or ones for negative values).

Related commands: SGP, STGP, RSGP, AGP

Mnemonic: GGP <parameter number>, <bank number>

Binary representation:

INSTRUCTION NO.	INSTRUCTION NO. TYPE		VALUE	
10	(see chapter 6)	<bank number=""></bank>	(don't care)	

Reply in direct mode:

STATUS	VALUE		
100 – OK	(don't care)		

Example:

Get the serial address of the target device *Mnemonic:* GGP 66, 0

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$0a	\$42	\$00	\$00	\$00	\$00	\$00

Reply:

Byte Index	0	1	2	3	4	5	6	7
Function	Host-	Target-	Status	Instructio	Operand	Operand	Operand	Operand
	address	address		n	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$02	\$01	\$64	\$0a	\$00	\$00	\$00	\$01

⇒ Status=no error, Value=1

3.5.11 STGP (store global parameter)

This command is used to store TMCL user variables permanently in the EEPROM of the module. Some global parameters are located in RAM memory, so without storing modifications are lost at power down. This instruction enables enduring storing. Most parameters are automatically restored after power up.

For a table with parameters and bank numbers which can be used together with this command please refer to chapter 5.

Internal function: The specified parameter is copied from its RAM location to the configuration EEPROM.

Related commands: SGP, GGP, RSGP, AGP

Mnemonic: STGP <parameter number>, <bank number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
11	(see chapter 8)	<bank number=""></bank>	(don't care)
		(see chapter 5)	

Reply in direct mode:

STATUS	VALUE		
100 – OK	(don't care)		

Example:

Store the user variable #42 *Mnemonic:* STGP 42, 2

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$0b	\$2a	\$02	\$00	\$00	\$00	\$00

3.5.12 RSGP (restore global parameter)

With this command the contents of a TMCL user variable can be restored from the EEPROM. For all configuration-related axis parameters, non-volatile memory locations are provided. By default, most parameters are automatically restored after power up. A single parameter that has been changed before can be reset by this instruction.

For a table with parameters and bank numbers which can be used together with this command please refer to chapter 5.

Internal function: The specified parameter is copied from the configuration EEPROM memory to its RAM location.

Relate commands: SAP, STAP, GAP, and AAP

Mnemonic: RSAP <parameter number>, 0

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
8	<pre><parameter number=""></parameter></pre>	0*	(don't care)

^{*}motor number is always 0 if only one motor is involved

Reply structure in direct mode:

STATUS	VALUE	
100 - OK	(don't care)	

Example:

Restore the maximum current of motor

Mnemonic: RSGP 6, 0

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$0c	\$2a	\$02	\$00	\$00	\$00	\$00

3.5.13 RFS (reference search)

The TMCM-1181 has a built-in reference search algorithm which can be used. The reference search algorithm provides switching point calibration and three switch modes. The status of the reference search can also be queried to see if it has already finished. (In a TMCL program it is better to use the WAIT command to wait for the end of a reference search.) Please see the appropriate parameters in the axis parameter table to configure the reference search algorithm to meet your needs (chapter 4). The reference search can be started, stopped, and the actual status of the reference search can be checked.

Internal function: the reference search is implemented as a state machine, so interaction is possible during execution.

Related commands: WAIT

Mnemonic: RFS <START|STOP|STATUS>, <motor>

Binary representation:

INSTRUCTION NO.	ТҮРЕ	MOT/BANK	VALUE
13	0 START – start ref. search 1 STOP – abort ref. search 2 STATUS – get status	0	see below

REPLY IN DIRECT MODE:

When using type 0 (START) or 1 (STOP):

STATUS	VALUE
100 - OK	don't care

When using type 2 (STATUS):

STATÚS	VALUE					
100 - OK	0	ref. search active				
	other values	no ref. search active				

Example:

Start reference search of motor 0 *Mnemonic:* RFS START, 0

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$0d	\$00	\$00	\$00	\$00	\$00	\$00

With this module it is possible to use stall detection instead of a reference search.

3.5.14SIO (set input / output)

SIO sets the status of the general digital outputs either to low (0) or to high (1). For the two open-drain outputs a high value (1) means that the output is pulled actively to ground and a low value (0) means that the output is floating.

SIO can be used also to switch on or off the pull-up resistors for the three digital inputs IN1, IN2 and IN3. A high value (1) means that the pull-ups are switched on (for all three inputs – this is also the default setting) and a low value (0) that the pull-ups are switched off.

Internal function: the parameter value is transferred to the specified output line.

Related commands: GIO, WAIT

Mnemonic: SIO <port number>, <bank number>, <value>

Binary representation:

INSTRUCTION NO.	ТҮРЕ	MOT/BANK	VALUE
14	<port number=""></port>	<bank number=""></bank>	<value></value>
		2	0/1

Reply structure:

STATUS	VALUE
100 – OK	don't care

Example:

Pull OUT1 actively low (bank 2, output 1)

Mnemonic: SIO 1, 2, 1

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$0e	\$01	\$02	\$00	\$00	\$00	\$01




Figure 3.1 TMCM-1181 connectors and location of general purpose outputs

SIO COMMANDS AND OUTPUTS

Connector	Pin	I/O port	Command	Range
In / Out	3	OUT0	SIO 0, 2, <n></n>	1/0
In / Out	4	OUT1	SIO 1, 2, <n></n>	1/0

ADDRESSING BOTH OUTPUT LINES WITH ONE SIO COMMAND:

- Set the type parameter to 255 and the bank parameter to 2.
- The value parameter must then be set to a value between 0... 255, where every bit represents one output line.
- Furthermore, the value can also be set to -1. In this special case, the contents of the lower 8 bits of the accumulator are copied to the output pins.

Example:

Set both output pins high. *Mnemonic:* SIO 255, 2, 3

THE FOLLOWING PROGRAM WILL SHOW THE STATES OF THE INPUT LINES ON THE OUTPUT LINES:

Loop: GIO 255, 0 SIO 255, 2,-1 JA Loop

SPECIAL COMMAND FOR SWITCHING THE PULL-UP RESISTORS FOR STOP_L, STOP_R, AND HOME

Connector	Pin	I/O port	Command	Range
In / Out	6	STOP_L / IN_1	SIO 0, 0, <n></n>	1/0
	7	STOP_R / IN_2		1: ON
	8	HOME / IN_3		0: OFF

3.5.15 GIO (get input /output)

With this command the status of all general purpose inputs INO .. IN4 of the module can be read out. The function reads a digital or analog input port. Digital lines will read as 0 or 1, while the ADC channels deliver their 12 bit result in the range of 0... 4095.

GIO IN STANDALONE MODE

In standalone mode the requested value is copied to the *accumulator* (accu) for further processing purposes such as conditioned jumps.

GIO IN DIRECT MODE

In direct mode the value is only output in the *value* field of the reply, without affecting the accumulator. The actual status of a digital output line can also be read.

Internal function: the specified line is read.

Related commands: SIO, WAIT

Mnemonic: GIO <port number>, <bank number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
15	<port number=""></port>	<bank number=""></bank>	don't care

Reply in direct mode:

STATUS	VALUE
100 - OK	<status of="" port="" the=""></status>

Example:

Get the analog value of INO *Mnemonic:* GIO 0, 1

Binary:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$0f	\$00	\$01	\$00	\$00	\$00	\$00

Reply:

Byte Index	0	1	2	3	4	5	6	7
Function	Host-	Target-	Status	Instructio	Operand	Operand	Operand	Operand
	address	address		n	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$02	\$01	\$64	\$0f	\$00	\$00	\$01	\$2e

Status = no error, value = 320




Figure 3.2 TMCM-1181 connectors and location of digital and analog general purpose inputs

3.5.15.1 I/O Bank 0 - Digital Inputs

The ADIN lines can be read as digital or analogue inputs at the same time. The analogue values can be accessed in bank 1.

Connector	Pin	I/O port	Command	Range
In / Out	5	IN0	GIO 0, 0 <n></n>	0/1
In / Out	6	IN1	GIO 1, 0, <n></n>	0/1
In / Out	7	IN2	GIO 2, 0, <n></n>	0/1
In / Out	8	IN3	GIO 3, 0, <n></n>	0/1
Interface	2	IN4	GIO 4, 0, <n></n>	0/1

FURTHER READ-OUT COMMANDS

I/O port	Command
S/D ENABLE input	
0 active	
1 off	GIO 12, 0
Limited performance because of	
input low pass filter.	

READING ALL DIGITAL INPUTS WITH ONE GIO COMMAND:

- Set the type parameter to 255 and the bank parameter to 0.
- In this case the status of all digital input lines will be read to the lower eight bits of the accumulator.

Use following program to represent the states of the input lines on the output lines:

3.5.15.2 I/O Bank 1 - Analog Inputs

The ADIN lines can be read back as digital or analogue inputs at the same time. The digital states can be accessed in bank 0.

Connector	Pin	I/O port	Command	Range
In / Out	5	IN0	GIO 0, 1 <n></n>	04095
Interface	2	IN4	GIO 4, 1, <n></n>	04095

READ OUT OPERATING VOLTAGE AND TEMPERATURE

I/O port	Command
Operating voltage [1/10 V]	GIO 8, 1
Temperature [°C]	GIO 9, 1

3.5.15.3 I/O Bank 2 -States of Digital Outputs

The states of the OUT lines (that have been set by SIO commands) can be read back using bank 2.

Connector	Pin	I/O port	Command	Range
In / Out	3	OUT0	GIO 0, 2 <n></n>	0/1
In / Out	4	OUT1	GIO 1, 2, <n></n>	0/1

3.5.16 CALC (calculate)

A value in the accumulator variable, previously read by a function such as GAP (get axis parameter) can be modified with this instruction. Nine different arithmetic functions can be chosen and one constant operand value must be specified. The result is written back to the accumulator, for further processing like comparisons or data transfer.

Related commands: CALCX, COMP, JC, AAP, AGP, GAP, GGP

Mnemonic: CALC <operation>, <value>

where <op> is ADD, SUB, MUL, DIV, MOD, AND, OR, XOR, NOT or LOAD

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
19	0 ADD - add to accu	(don't care)	<operand></operand>
	1 SUB – subtract from accu		
	2 MUL – multiply accu by		
	3 DIV – divide accu by		
	4 MOD – modulo divide by		
	5 AND – logical and accu with		
	6 OR – logical or accu with		
	7 XOR – logical exor accu with		
	8 NOT – logical invert accu		
	9 LOAD - load operand to accu		

Example:

Multiply accu by -5000 Mnemonic: CALC MUL, -5000

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$13	\$02	\$00	\$FF	\$FF	\$EC	\$78

3.5.17 COMP (compare)

The specified number is compared to the value in the accumulator register. The result of the comparison can for example be used by the conditional jump (JC) instruction. This command is intended for use in standalone operation only.

The host address and the reply are only used to take the instruction to the TMCL program memory while the program loads down. It does not make sense to use this command in direct mode.

Internal function: The specified value is compared to the internal *accumulator*, which holds the value of a preceding *get* or calculate instruction (see GAP/GGP/ CALC/CALCX). The internal arithmetic status flags are set according to the comparison result.

Related commands: JC (jump conditional), GAP, GGP, CALC, CALCX

Mnemonic: COMP <value>

Binary representation:

INSTRUCTION NO.			VALUE
20	(don't care)	(don't care)	<comparison value=""></comparison>

Example:

Jump to the address given by the label when the position of motor is greater than or equal to 1000.

GAP 1, 2, 0 //get axis parameter, type: no. 1 (actual position), motor: 0, value: 0 (don't care) //compare actual value to 1000

JC GE, Label //jump, type: 5 greater/equal, the label must be defined somewhere else in the program

Binary format of the COMP 1000 command:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$14	\$00	\$00	\$00	\$00	\$03	\$e8

3.5.18 JC (jump conditional)

The JC instruction enables a conditional jump to a fixed address in the TMCL program memory, if the specified condition is met. The conditions refer to the result of a preceding comparison. Please refer to COMP instruction for examples. This function is for standalone operation only.

The host address and the reply are only used to take the instruction to the TMCL program memory while the program loads down. It does not make sense to use this command in direct mode. See the host-only control functions for details.

Internal function: the TMCL program counter is set to the passed value if the arithmetic status flags are in the appropriate state(s).

Related commands: JA, COMP, WAIT, CLE

Mnemonic: JC <condition>, <label>

where <condition>=ZE|NZ|EQ|NE|GT|GE|LT|LE|ETO|EAL|EDV|EPO

Binary representation:

INSTRUCTION NO.	ТҮРЕ	MOT/BANK	VALUE
21	0 ZE - zero	(don't care)	<jump address=""></jump>
	1 NZ - not zero		
	2 EQ - equal		
	3 NE - not equal		
	4 GT - greater		
	5 GE - greater/equal		
	6 LT - lower		
	7 LE - lower/equal		
	8 ETO - time out error		
	9 EAL – external alarm		
	12 ESD – shutdown error		

Example:

Jump to address given by the label when the position of motor is greater than or equal to 1000.

GAP 1, 0, 0 //get axis parameter, type: no. 1 (actual position), motor: 0, value: 0 (don't care)

COMP 1000 //compare actual value to 1000 JC GE, Label //jump, type: 5 greater/equal

...

Label: ROL 0, 1000

Binary format of JC GE, Label when Label is at address 10:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$15	\$05	\$00	\$00	\$00	\$00	\$0a

3.5.19 JA (jump always)

Jump to a fixed address in the TMCL program memory. This command is intended for standalone operation only.

The host address and the reply are only used to take the instruction to the TMCL program memory while the program loads down. This command cannot be used in direct mode.

Internal function: the TMCL program counter is set to the passed value.

Related commands: JC, WAIT, CSUB

Mnemonic: JA <Label>

Binary representation:

•	ary representation			
	INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
	22	(don't care)	(don't care)	<jump address=""></jump>

Example: An infinite loop in TMCL™

Loop: MVP ABS, 0, 10000

WAIT POS, 0, 0 MVP ABS, 0, 0 WAIT POS, 0, 0

JA Loop //Jump to the label Loop

Binary format of JA Loop assuming that the label Loop is at address 20:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$16	\$00	\$00	\$00	\$00	\$00	\$14

3.5.20 CSUB (call subroutine)

This function calls a subroutine in the TMCL program memory. It is intended for standalone operation only.

The host address and the reply are only used to take the instruction to the TMCL program memory while the program loads down. This command cannot be used in direct mode.

Internal function: The actual TMCL program counter value is saved to an internal stack, afterwards overwritten with the passed value. The number of entries in the internal stack is limited to 8. This also limits nesting of subroutine calls to 8. The command will be ignored if there is no more stack space left.

Related commands: RSUB, JA

Mnemonic: CSUB <Label>

Binary representation:

INSTRUCTION NO.	ТҮРЕ	MOT/BANK	VALUE		
23	(don't care)	(don't care)	<subroutine address=""></subroutine>		

Example: Call a subroutine

Loop: MVP ABS, 0, 10000

CSUB SubW //Save program counter and jump to label SubW

MVP ABS, 0, 0 JA Loop

SubW: WAIT POS, 0, 0

WAIT TICKS, 0, 50

RSUB //Continue with the command following the CSUB command

Binary format of the CSUB SubW command assuming that the label SubW is at address 100:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$17	\$00	\$00	\$00	\$00	\$00	\$64

3.5.21 RSUB (return from subroutine)

Return from a subroutine to the command after the CSUB command. This command is intended for use in standalone mode only.

The host address and the reply are only used to take the instruction to the TMCL program memory while the program loads down. This command cannot be used in direct mode.

Internal function: The TMCL program counter is set to the last value of the stack. The command will be ignored if the stack is empty.

Related command: CSUB

Mnemonic: RSUB

Binary representation:

•	ary representations			
	INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
	24	(don't care)	(don't care)	(don't care)

Example: please see the CSUB example (section 3.5.20).

Binary format of RSUB:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$18	\$00	\$00	\$00	\$00	\$00	\$00

3.5.22 WAIT (wait for an event to occur)

This instruction interrupts the execution of the TMCL program until the specified condition is met. This command is intended for standalone operation only.

The host address and the reply are only used to take the instruction to the TMCL program memory while the program loads down. This command cannot be used in direct mode.

There are five different wait conditions that can be used:

- TICKS: Wait until the number of timer ticks specified by the <ticks> parameter has been reached.
- POS: Wait until the target position of the motor specified by the <motor> parameter has been reached. An optional timeout value (0 for no timeout) must be specified by the <ticks> parameter.
- REFSW: Wait until the reference switch of the motor specified by the <motor> parameter has been triggered. An optional timeout value (0 for no timeout) must be specified by the <ticks> parameter.
- LIMSW: Wait until a limit switch of the motor specified by the <motor> parameter has been triggered. An optional timeout value (0 for no timeout) must be specified by the <ticks> parameter.
- RFS: Wait until the reference search of the motor specified by the <motor> field has been reached. An optional timeout value (0 for no timeout) must be specified by the <ticks> parameter.

The timeout flag (ETO) will be set after a timeout limit has been reached. You can then use a JC ETO command to check for such errors or clear the error using the CLE command.

Internal function: The TMCL program counter is held until the specified condition is met.

Related commands: JC, CLE

Mnemonic: WAIT <condition>, 0, <ticks>

where <condition> is TICKS|POS|REFSW|LIMSW|RFS

Binary representation:

INSTRUCTION NO.	ТҮРЕ	MOT/BANK	VALUE	
	0 TICKS - timer ticks*1	don't care	<no. of="" ticks*1=""></no.>	
	1 POS - target position reached	<motor>*2</motor>	<no. for="" of="" ticks*1="" timeout="">,</no.>	
	1 FO3 - target position reached		0 for no timeout	
	2 REFSW – reference switch	<motor>*2</motor>	<no. for="" of="" ticks*1="" timeout="">,</no.>	
27	Z KEF3W – Telefelice Switch		0 for no timeout	
	3 LIMSW – limit switch	<motor>*2</motor>	<no. for="" of="" ticks*1="" timeout="">,</no.>	
	5 LIMSW - HITH SWITCH		0 for no timeout	
	4 RFS – reference search	<motor>*2</motor>	<no. for="" of="" ticks*1="" timeout="">,</no.>	
	completed		0 for no timeout	

^{*1} one tick is 10 milliseconds (in standard firmware)

Example:

Wait for motor to reach its target position, without timeout *Mnemonic:* WAIT POS, 0, 0

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$1b	\$01	\$00	\$00	\$00	\$00	\$00

^{*2} motor number is always 0 as only one motor is involved

3.5.23 STOP (stop TMCL program execution)

This function stops executing a TMCL program. The host address and the reply are only used to transfer the instruction to the TMCL program memory.

This command should be placed at the end of every standalone TMCL program. It is not to be used in direct mode.

Internal function: TMCL instruction fetching is stopped.

Related commands: none

Mnemonic: STOP

Binary representation:

INSTRUCTION NO. TYPE		MOT/BANK	VALUE	
28	(don't care)	(don't care)	(don't care)	

Example:

Mnemonic: STOP

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$1c	\$00	\$00	\$00	\$00	\$00	\$00

3.5.24 CALCX (calculate using the X register)

This instruction is very similar to CALC, but the second operand comes from the X register. The X register can be loaded with the LOAD or the SWAP type of this instruction. The result is written back to the accumulator for further processing like comparisons or data transfer.

Related commands: CALC, COMP, JC, AAP, AGP

Mnemonic: CALCX <operation>

with <operation>=ADD|SUB|MUL|DIV|MOD|AND|OR|XOR|NOT|LOAD|SWAP

Binary representation:

INSTRUCTION NO.	ТҮРЕ	MOT/BANK	VALUE
33	0 ADD – add X register to accu	(don't care)	(don't care)
	1 SUB – subtract X register from accu		
	2 MUL – multiply accu by X register		
	3 DIV – divide accu by X-register		
	4 MOD – modulo divide accu by x-register		
	5 AND – logical and accu with X-register		
	6 OR – logical or accu with X-register		
	7 XOR – logical exor accu with X-register		
	8 NOT – logical invert X-register		
	9 LOAD – load accu to X-register		
	10 SWAP – swap accu with X-register		

Example:

Multiply accu by X-register Mnemonic: CALCX MUL

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$21	\$02	\$00	\$00	\$00	\$00	\$00

3.5.25 AAP (accumulator to axis parameter)

The content of the accumulator register is transferred to the specified axis parameter. For practical usage, the accumulator has to be loaded e.g. by a preceding GAP instruction. The accumulator may have been modified by the CALC or CALCX (calculate) instruction.

For a table with parameters and values which can be used together with this command please refer to chapter 4.

Related commands: AGP, SAP, GAP, SGP, GGP, CALC, CALCX

Mnemonic: AAP <parameter number>, 0

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
34	<parameter number=""></parameter>	0*	<don't care=""></don't>

^{*} Motor number is always 0 as only one motor is involved

Reply in direct mode:

STATUS	VALUE		
100 - OK	(don't care)		

Example:

Positioning motor by a potentiometer connected to the analogue input #0:

Start: GIO 0,1 // get value of analogue input line 0

CALC MUL, 4 // multiply by 4

AAP 0,0 // transfer result to target position of motor 0

JA Start // jump back to start

Binary format of the AAP 0,0 command:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$22	\$00	\$00	\$00	\$00	\$00	\$00

3.5.26 AGP (accumulator to global parameter)

The content of the accumulator register is transferred to the specified global parameter. For practical usage, the accumulator has to be loaded e.g. by a preceding GAP instruction. The accumulator may have been modified by the CALC or CALCX (calculate) instruction. **Note that the global parameters in bank 0 are EEPROM-only and thus should not be modified automatically by a standalone application.** (See chapter 5 for a complete list of global parameters).

Related commands: AAP, SGP, GGP, SAP, GAP

Mnemonic: AGP <parameter number>, <bank number>

Binary representation:

INSTRUCTION NO.	ТҮРЕ	MOT/BANK	VALUE
35	<pre><parameter< pre=""></parameter<></pre>	<bank number=""></bank>	(don't care)
, , ,	number>	Coalik Hullibel>	(don't care)

Reply in direct mode:

STATUS	VALUE		
100 – OK	(don't care)		

Example:

Copy accumulator to TMCL user variable #3 *Mnemonic:* AGP 3, 2

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$23	\$03	\$02	\$00	\$00	\$00	\$00

3.5.27 CLE (clear error flags)

This command clears the internal error flags. It is intended for use in standalone mode only and must not be used in direct mode.

The following error flags can be cleared by this command (determined by the <flag> parameter):

ALL: clear all error flags.

- ETO: clear the timeout flag.

- EAL: clear the external alarm flag

- EDV: clear the deviation flag

- EPO: clear the position error flag

Related commands: JC

Mnemonic: CLE <flags>

where <flags>=ALL|ETO|EDV|EPO

Binary representation:

INSTRUCTION NO.	ТҮРЕ	MOT/BANK	VALUE
36	0 – (ALL) all flags	(don't care)	(don't care)
	1 – (ETO) timeout flag		
	2 – (EAL) alarm flag		
	3 – (EDV) deviation flag		
	4 – (EPO) position flag		
	5 – (ESD) shutdown flag		

Example:

Reset the timeout flag Mnemonic: CLE ETO

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$24	\$01	\$00	\$00	\$00	\$00	\$00

3.5.28 VECT (set interrupt vector)

The VECT command defines an interrupt vector. It needs an interrupt number and a label as parameter (like in JA, JC and CSUB commands).

This label must be the entry point of the interrupt handling routine.

Related commands: EI, DI, RETI

Mnemonic: VECT <interrupt number>, <label>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE	
37	<interrupt number=""></interrupt>	don't care	<label></label>	

THE FOLLOWING TABLE SHOWS ALL INTERRUPT VECTORS THAT CAN BE USED:

Interrupt number	Interrupt type
0	Timer 0
1	Timer 1
2	Timer 2
3	(Target) position reached
15	Stall (stallGuard2™)
21	Deviation
27	Stop left
28	Stop right
39	IN_0 change
40	IN_1 change
41	IN_2 change
42	IN_3 change

Example: Define interrupt vector at target position 500

VECT 3, 500

Binary format of VECT:

Byte Index	0	1	2	3	4	5	6	7
Function	Target- address	Instruction Number	Type	Motor/ Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Bvte0
	addiess			Dalik	bytes	bytez	Бугет	byteo
Value (hex)	\$01	\$25	\$03	\$00	\$00	\$00	\$01	\$F4

3.5.29 EI (enable interrupt)

The EI command enables an interrupt. It needs the interrupt number as parameter. Interrupt number 255 globally enables interrupts.

Related command: DI, VECT, RETI

Mnemonic: EI <interrupt number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE	
25	<interrupt number=""></interrupt>	don't care	don't care	

THE FOLLOWING TABLE SHOWS ALL INTERRUPT VECTORS THAT CAN BE USED:

Interrupt number	Interrupt type
0	Timer 0
1	Timer 1
2	Timer 2
3	(Target) position reached
15	Stall (stallGuard2™)
21	Deviation
27	Stop left
28	Stop right
39	IN_0 change
40	IN_1 change
41	IN_2 change
42	IN_3 change

Examples:

Enable interrupts globally EI, 255

Binary format of EI:

Billary Joinnac o	,							
Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$19	\$FF	\$00	\$00	\$00	\$00	\$00

Enable interrupt when target position reached EI, 3

Binary format of EI:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$19	\$03	\$00	\$00	\$00	\$00	\$00

3.5.30 DI (disable interrupt)

The DI command disables an interrupt. It needs the interrupt number as parameter. Interrupt number 255 globally disables interrupts.

Related command: EI, VECT, RETI

Mnemonic: DI <interrupt number>

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE	
26	<interrupt number=""></interrupt>	don't care	don't care	

THE FOLLOWING TABLE SHOWS ALL INTERRUPT VECTORS THAT CAN BE USED:

Interrupt number	Interrupt type
0	Timer 0
1	Timer 1
2	Timer 2
3	(Target) position reached
15	Stall (stallGuard2™)
21	Deviation
27	Stop left
28	Stop right
39	IN_0 change
40	IN_1 change
41	IN_2 change
42	IN_3 change

Examples:

Disable interrupts globally DI, 255

Binary format of DI:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$1A	\$FF	\$00	\$00	\$00	\$00	\$00

Disable interrupt when target position reached DI, 3

Binary format of DI:

Byte Index	0	1	2	3	4	5	6	7
Function	Target- address	Instruction Number	Type	Motor/ Bank	Operand Byte3	Operand Byte2	Operand Byte1	Operand Byte0
Value (hex)	\$01	\$1A	\$03	\$00	\$00	\$00	\$00	\$00

3.5.31 RETI (return from interrupt)

This command terminates the interrupt handling routine, and the normal program execution continues.

At the end of an interrupt handling routine the RETI command must be executed.

Internal function: the saved registers (A register, X register, flags) are copied back. Normal program execution continues.

Related commands: EI, DI, VECT

Mnemonic: RETI

Binary representation:

INSTRUCTION NO.	ТҮРЕ	MOT/BANK	VALUE
38	don't care	don't care	don't care

Example: Terminate interrupt handling and continue with normal program execution

RETI

Binary format of RETI:

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Instruction	Type	Motor/	Operand	Operand	Operand	Operand
	address	Number		Bank	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$01	\$26	\$00	\$00	\$00	\$00	\$01	\$00

3.5.32 Customer specific TMCL command extension (UF0... UF7/user function)

The user definable functions UFO... UF7 are predefined, functions without topic for user specific purposes. Contact TRINAMIC for the customer specific programming of these functions.

Internal function: Call user specific functions implemented in C by TRINAMIC.

Related commands: none

Mnemonic: UF0... UF7

Binary representation:

INSTRUCTION NO.	TYPE	MOT/BANK	VALUE
64 71	(user defined)	(user defined)	(user defined)

Reply in direct mode:

mepty in an ee								
Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Target-	Status	Instructio	Operand	Operand	Operand	Operand
	address	address		n	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$02	\$01	(user	64 71	(user	(user	(user	(user
			defined)		defined)	defined)	defined)	defined)

3.5.33 Request target position reached event

This command is the only exception to the TMCL protocol, as it sends two replies: One immediately after the command has been executed (like all other commands also), and one additional reply that will be sent when the motor has reached its target position. This instruction can only be used in direct mode (in standalone mode, it is covered by the WAIT command) and hence does not have a mnemonic.

Internal function: Send an additional reply when the motor has reached its target position

Mnemonic: ---

Binary representation:

INSTRUCTION NO.	ТҮРЕ	MOT/BANK	VALUE
138	(don't care)	(don't care)	0*

^{*} Motor number

Reply in direct mode (right after execution of this command):

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Target-	Status	Instructio	Operand	Operand	Operand	Operand
	address	address		n	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$02	\$01	100	138	\$00	\$00	\$00	Motor bit
								mask

Additional reply in direct mode (after motors have reached their target positions):

Byte Index	0	1	2	3	4	5	6	7
Function	Target-	Target-	Status	Instructio	Operand	Operand	Operand	Operand
	address	address		n	Byte3	Byte2	Byte1	Byte0
Value (hex)	\$02	\$01	128	138	\$00	\$00	\$00	Motor bit
								mask

3.5.34 TMCL Control Functions

The following functions are for host control purposes only and are not allowed for standalone mode. In most cases, there is no need for the customer to use one of those functions (except command 139). They are mentioned here only for reasons of completeness. These commands have no mnemonics, as they cannot be used in TMCL programs. The Functions are to be used only by the TMCL-IDE to communicate with the module, for example to download a TMCL application into the module.

The only control commands that could be useful for a user host application are:

- get firmware revision (command 136, please note the special reply format of this command, described at the end of this section)
- run application (command 129)

All other functions can be achieved by using the appropriate functions of the TMCL-IDE.

Instruction	Description	Туре	Mot/Bank	Value
128 - stop application	a running TMCL standalone application is stopped		(don't care)	(don't care)
129 - run application	TMCL execution is started (or continued)	current address 1 - run from	(don't care)	(don't care) starting address
130 - step application	only the next command of a TMCL application is executed	specified address (don't care)	(don't care)	(don't care)
131 - reset application	the program counter is set to zero, and the standalone application is stopped (when running or stepped)	(don't care)	(don't care)	(don't care)
132 – start download mode	target command execution is stopped and all following commands are transferred to the TMCL memory	(don't care)	(don't care)	starting address of the application
133 – quit download mode	target command execution is resumed	(don't care)	(don't care)	(don't care)
134 - read TMCL memory	the specified program memory location is read	(don't care)	(don't care)	<memory address=""></memory>
135 - get application status	one of these values is returned: 0 - stop 1 - run 2 - step 3 - reset	(don't care)	(don't care)	(don't care)
136 – get firmware version	return the module type and firmware revision either as a string or in binary format		(don't care)	(don't care)
137 – restore factory settings	reset all settings stored in the EEPROM to their factory defaults This command does not send back a reply.	(don't care)	(don't care)	must be 1234

Special reply format of command 136:

Type set to 0 - reply as a string:

Byte index	Contents
1	Host Address
2 9	Version string (8 characters, e.g. 1181V1.26)

There is no checksum in this reply format!

Type set to 1 - version number in binary format:

- Please use the normal reply format.
- The version number is output in the *value* field of the reply in the following way:

Byte index in value field	Contents				
1	Version number, low byte				
2	Version number, high byte				
3	Type number, low byte				
	(currently not used)				
4	Type number, high byte				
	(currently not used)				

4 Axis parameters

The following sections describe all axis parameters that can be used with the SAP, GAP, AAP, STAP and RSAP commands.

Meaning of the letters in column Access:

Access	Related	Description
type	command(s)	
R	GAP	Parameter readable
W	SAP, AAP	Parameter writable
E	STAP, RSAP	Parameter automatically restored from EEPROM after reset or power-on. These parameters can be stored permanently in EEPROM using STAP command and also explicitly restored (copied back from EEPROM into RAM) using RSAP.

Basic parameters should be adjusted to motor / application for proper module operation.

Parameters for the more experienced user – please do not change unless you are absolutely sure.

Number	Axis Parameter	Description				Range [Unit]	Acc.
0	Target (next)	The desired	position	in position	mode (see	± 2 ³¹ -1	RW
	position	ramp mode	, no. 138).	-		[µsteps]	
1	Actual position	· ·		the motor. S	Should only	± 2 ³¹ -1	RW
	'		•	rence point s	•	[µsteps]	
2	Target (next)			elocity mode		±2047	RW
	speed		•	position r		$\frac{16\text{MHz}}{65536} \cdot 2^{pulse_divisor} \frac{\mu \text{steps}}{\text{sec}}$	
		_		dware: to th		[65536 sec]	
		1 ·	•	ion, and to			
		deceleration	-	.01., 41.4	zero daring		
3	Actual speed	The current		eed		±2047	RW
	Actual speed	The carrent	Totation 3p	ccu.			1000
						$ \left[\frac{16\text{MHz}}{65536} \cdot 2^{pulse_divisor} \frac{\mu \text{steps}}{\text{sec}} \right] $	
4	Maximum			the physica		0 2047	RWE
	positioning			the pulse o		100	
	speed			speed value	is very low	$\left[\frac{16\text{MHz}}{65536} \cdot 2^{pulse_divisor} \frac{\mu \text{steps}}{\text{sec}}\right]$	
		(<50) or abo					
5	Maximum	The limit f	or accelerat	ion (and de	eceleration).	0 2047*1	RWE
	acceleration	Changing th	nis paramete	er requires re	-calculation		
		of the acce	eleration fa	ctor (no. 14	6) and the		
		acceleration divisor (no. 137), which is done					
		automatically. See TMC 429 datasheet for					
		calculation	of physical	units.			
6	Absolute max.	The maximu	ım value is	255. This va	lue means	0 255	RWE
	current	100% of the	maximum	current of th	ne module.	$I_{peak} = < value > \times \frac{4A}{255}$	
	(CS / Current	The current	adjustment	is within th	e range 0	255	
	Scale)		•	d in 32 step	_	$I_{RMS} = \langle value \rangle \times \frac{2.8A}{2.55}$	
		0 7	7987	160 167	240 247	255	
		8 15	88 95	168 175	248 255		
		16 23	96 103	176 183			
		24 31	104 111	184 191			
		32 39 40 47	112 119 120 127	192 199 200 207			
		48 55	128 135	208 215			
		56 63	136 143	216 223			
		64 71	144 151	224 231			
		72 79	152 159	232 239			
			•	otor setting,			
		high values	might caus	se motor dar	mage!		

Number	Axis Parameter	Description	Range [Unit]	Acc.	
7	Standby current	The current limit two seconds after the motor has stopped.	0 255 $I_{peak} = \langle value \rangle \times \frac{4A}{255}$ $I_{RMS} = \langle value \rangle \times \frac{2.8A}{255}$	RWE	
8	Target pos. reached	Indicates that the actual position equals the target position.	0/1	R	
9	Ref. switch status	The logical state of the reference home switch.	0/1	R	
10	Right limit switch status	The logical state of the (right) limit switch.	0/1	R	
11	Left limit switch status	The logical state of the left limit switch (in three switch mode)	0/1	R	
12	Right limit switch disable	If set, deactivates the stop function of the right switch	0/1	RWE	
13	Left limit switch disable	Deactivates the stop function of the left switch resp. reference switch if set.	0/1	RWE	
130	Minimum speed	Should always be set 1 to ensure exact reaching of the target position.	0 2047 Default = 1 [\frac{16MHz}{65536}. 2^{pulse_divisor} \frac{\musteps}{\sec}]	RWE	
135	Actual acceleration	The current acceleration (read only).	0 2047*	R	
138	Ramp mode	Automatically set when using ROR, ROL, MST and MVP. O: position mode. Steps are generated, when the parameters actual position and target position differ. Trapezoidal speed ramps are provided. 2: velocity mode. The motor will run continuously and the speed will be changed with constant (maximum) acceleration, if the parameter target speed is changed. For special purposes, the soft mode (value 1) with exponential decrease of speed can be selected.		RWE	
140	Microstep resolution	0 full step 1 half step 2 4 microsteps 3 8 microsteps 4 16 microsteps 5 32 microsteps 6 64 microsteps 7 128 microsteps 8 256 microsteps	0 8	RWE	
149	Soft stop flag	If cleared, the motor will stop immediately 0/1 (disregarding motor limits), when the reference			
153	Ramp divisor	The exponent of the scaling factor for the ramp generator- should be de/incremented carefully (in steps of one).	generator- should be de/incremented carefully		
154	Pulse divisor	The exponent of the scaling factor for the pulse (step) generator – should be de/incremented carefully (in steps of one).	0 13	RWE	

Number	Axis Parameter	Description	Range [Unit]	Acc.
160	Step interpolation enable	Step interpolation is supported with a 16 microstep setting only. In this setting, each step impulse at the input causes the execution of 16 times 1/256 microsteps. This way, a smooth motor movement like in 256 microstep resolution is achieved. 0 – step interpolation off		RW
161	Double step enable	1 - step interpolation on Every edge of the cycle releases a step/microstep. It does not make sense to activate this parameter for internal use. Double step enable can be used with Step/Dir interface. 0 - double step off 1 - double step on	0/1	RW
162	Chopper blank time	Selects the comparator blank time. This time needs to safely cover the switching event and the duration of the ringing on the sense resistor. For low current drivers, a setting of 1 or 2 is good.	0 3	RW
163	Chopper mode	Selection of the chopper mode: 0 - spread cycle 1 - classic const. off time	0/1	RW
164	Chopper hysteresis decrement	Hysteresis decrement setting. This setting determines the slope of the hysteresis during on time and during fast decay time. 0 - fast decrement 3 - very slow decrement	0 3	RW
165	Chopper hysteresis end	Hysteresis end setting. Sets the hysteresis end value after a number of decrements. Decrement interval time is controlled by axis parameter 164. -31 negative hysteresis end setting 0 zero hysteresis end setting 1 12 positive hysteresis end setting		RW
166	Chopper hysteresis start	Hysteresis start setting. Please remark, that this value is an offset to the hysteresis end value.	0 8	RW
167	Chopper off time	The off time setting controls the minimum chopper frequency. An off time within the range of 5µs to 20µs will fit. Off time setting for constant t _{off} chopper: N _{CLK} = 12 + 32*t _{OFF} (Minimum is 64 clocks) Setting this parameter to zero completely disables all driver transistors and the motor can free-wheel.		RW
168	smartEnergy current minimum (SEIMIN)	Sets the lower motor current limit for coolStep™ operation by scaling the CS (Current Scale, see axis parameter 6) value. minimum motor current: 0 - 1/2 of CS 1 - 1/4 of CS	0/1	RW

Number	Axis Parameter	Description	Range [Unit]	Acc.
169	smartEnergy current down step	Sets the number of stallGuard2 TM readings above the upper threshold necessary for each current decrement of the motor current. Number of stallGuard2 TM measurements per	0 3	RW
		decrement: Scaling: 0 3: 32, 8, 2, 1 0: slow decrement 3: fast decrement		
170	smartEnergy hysteresis	Sets the distance between the lower and the upper threshold for stallGuard2™ reading. Above the upper threshold the motor current becomes decreased.	0 15	RW
		Hysteresis: (smartEnergy hysteresis value + 1) * 32		
		Upper stallGuard threshold: (smartEnergy hysteresis start + smartEnergy hysteresis + 1) * 32		
171	smartEnergy current up step	Sets the current increment step. The current becomes incremented for each measured stallGuard2 TM value below the lower threshold (see smartEnergy hysteresis start). current increment step size:	1 3	RW
		Scaling: 0 3: 1, 2, 4, 8 0: slow increment 3: fast increment / fast reaction to rising load		
172	smartEnergy hysteresis start	The lower threshold for the stallGuard2™ value (see smart Energy current up step).	0 15	RW
173	stallGuard2™ filter enable	Enables the stallGuard2 [™] filter for more precision of the measurement. If set, reduces the measurement frequency to one measurement per four fullsteps. In most cases it is expedient to set the filtered mode before using coolStep [™] . Use the standard mode for step loss detection. 0 – standard mode 1 – filtered mode	0/1	RW
174	stallGuard2™ threshold	This signed value controls stallGuard2 TM threshold level for stall output and sets the optimum measurement range for readout. A lower value gives a higher sensitivity. Zero is the starting value. A higher value makes stallGuard2 TM less sensitive and requires more torque to indicate a stall. 0		RW
175	Slope control high side	Determines the slope of the motor driver outputs. Set to 2 or 3 for this module or rather use the default value. 0: lowest slope 3: fastest slope	0 3	RW
176	Slope control low side	Determines the slope of the motor driver outputs. Set identical to slope control high side.	0 3	RW

Number	Axis Parameter	Description	Range [Unit]	Acc.
177	short protection disable	0: Short to GND protection is on 1: Short to GND protection is disabled Use default value!	0/1	RW
178	Short detection timer	0: 3.2µs 1: 1.6µs 2: 1.2µs 3: 0.8µs Use default value!	03	RW
179	Vsense	sense resistor voltage based current scaling 0: Full scale sense resistor voltage is 1/18 VDD 1: Full scale sense resistor voltage is 1/36 VDD (refers to a current setting of 31 and DAC value 255) Use default value. Do not change!	0/1	RW
180	smartEnergy actual current	This status value provides the actual motor current setting as controlled by coolStep™. The value goes up to the CS value and down to the portion of CS as specified by SEIMIN. actual motor current scaling factor: 0 31: 1/32, 2/32, 32/32	0 31	RW
181	Stop on stall	Below this speed motor will not be stopped. Above this speed motor will stop in case stallGuard2™ load value reaches zero.	0 2047	RW
182	smartEnergy threshold speed	Above this speed coolStep™ becomes enabled.	0 2047 [16MHz . 2pulse_divisor usteps sec]	RW
183	smartEnergy slow run current	Sets the motor current which is used below the threshold speed.	0 255 $I_{peak} = \langle value \rangle \times \frac{4A}{255}$ $I_{RMS} = \langle value \rangle \times \frac{2.8A}{255}$	RW
193	Ref. search mode	1 search left stop switch only 2 search right□stop switch, then search left stop switch 3 search right stop switch, then search left stop switch from both sides 4 search left stop switch from both sides 5 search home switch in negative direction, reverse the direction when left stop switch reached 6 search home switch in positive direction, reverse the direction when right stop switch reached 7 search home switch in positive direction, ignore end switches 8 search home switch in negative direction, ignore end switches Additional functions: - Add 128 to a mode value for inverting the home switch (can be used with mode 5 8) Add 64 to a mode for driving the right instead of the left reference switch (can be used with mode 1 4).	1 8	RWE

Number	Axis Parameter	Description	Range [Unit]	Acc.
194	Referencing	For the reference search this value directly	0 2047	RWE
	search speed	specifies the search speed.		
195	Referencing	Similar to parameter no. 194, the speed for the	0 2047	RWE
	switch speed	switching point calibration can be selected.		
196	Distance end	This parameter provides the distance between	0 2.147.483.647	R
	switches	the end switches after executing the RFS		
		command (mode 2 or 3).		
197	Last reference	Reference search: the last position before	-2 ³¹ 2 ³¹ -1	R
	position	setting the counter to zero can be read out.	[µsteps]	
200	Boost current	Current used for acceleration and deceleration	0 255	RWE
		phases.	$I_{peak} = < value > \times \frac{4A}{255}$	
		If set to 0 the same current as set by axis		
		parameter 6 will be used.	$I_{RMS} = < value > \times \frac{2.8A}{255}$	
204	Freewheeling	Time after which the power to the motor will	0 65535	RWE
		be cut when its velocity has reached zero.	0 = never	
			[msec]	
206	Actual load value		0 1023	R
		stall detection (stallGuard2™).		
207	Extended error	1 Motor stopped because of	1 3	R
	flags	stallGuard2 detection.		
		2 Motor stopped because of encoder		
		deviation.		
		3 Motor stopped because of (1) and		
		(2).		
		Will be reset automatically by the next motion		
200	TMC262 driver	command. Bit 0 stallGuard2 status	0/1	D
208		(1: threshold reached)	0/1	R
	error flags	Bit 1 Overtemperature		
		(1: driver is shut down due to		
		Bit 2 Pre-warning overtemperature		
		(1: Threshold is exceeded)		
		Bit 3 Short to ground A		
		(1: Short condition detected,□driver currently shut down)		
		Bit 4 Short to ground B		
		(1: Short condition detected, driver currently		
		shut down) Bit 5 Open load A		
		Bit 5 Open load A (1: no chopper event has happened during		
		the last period with constant coil polarity)		
		Bit 6 Open load B		
		(1: no chopper event has happened during the last period with constant coil polarity)		
		Bit 7 Stand still		
		(1: No step impulse occurred on the step		
		input during the last 2^20 clock cycles)		
		Please refer to the TMC262 Datasheet for more information.		
209	Encoder position	The value of an encoder register can be read	[encoder steps]	RW
20)	Lincoder position	out or written.	[encoder steps]	IVVV
210	Encoder	Prescaler for the encoder.	See paragraph 6.2	RWE
210	prescaler	Trescater for the efficuer.	See paragraph 0.2	IVAAE
212	Maximum	When the actual position (parameter 1) and the	0 65535	RWE
LIL	encoder	encoder position (parameter 209) differ more	U U.J.J.	IVAAE
	deviation	than set here the motor will be stopped. This	[encoder steps]	
	acviation	function is switched off when the maximum		
		deviation is set to zero.		
		activation is set to zero.	L	

Number	Axis Parameter	Description	Range [Unit]	Acc.
214	Power down delay	Standstill period before the current is changed down to standby current. The standard value is 200 (value equates 2000msec).	_	RWE
254	Step/dir mode	1 Use of the ENABLE input on step/dir connector to switch between hold current and run current (no automatic switching) 2 Automatic switching between hold and run current: after the first step pulse the module automatically switches over to run current, and a configurable time after the last step pulse the module automatically switches back to hold current. The ENABLE input on the step/dir connector does not have any functionality. 3 Always use run current, never switch to hold current. The ENABLE input on the step/dir connector does not have any functionality. 4 Automatic current switching like (2), but the ENABLE input is used to switch the driver stage completely off or on. 5 Always use run current like (3), but the ENABLE pin is used to switch the driver stage completely off or on.	1 5	RWE

* Unit of acceleration: $\frac{16MHz^2}{536870912 \cdot 2puls_divisor + ramp_divisor} \frac{\text{microsteps}}{\text{sec}^2}$

4.1 stallGuard2

The module is equipped with TMC262 motor driver chip. The TMC262 features load measurement that can be used for stall detection. stallGuard2 delivers a sensorless load measurement of the motor as well as a stall detection signal. The measured value changes linear with the load on the motor in a wide range of load, velocity and current settings. At maximum motor load the stallGuard2 value goes to zero. This corresponds to a load angle of 90° between the magnetic field of the stator and magnets in the rotor. This also is the most energy efficient point of operation for the motor.

Stall detection means that the motor will be stopped when the load gets too high. It is configured by axis parameter #174.

Stall detection can also be used for finding the reference point. Do not use RFS in this case.

4.2 coolStep Related Axis Parameters

The figure below gives an overview of the coolStep related parameters. Please have in mind that the figure shows only one example for a drive. There are parameters which concern the configuration of the current. Other parameters are for velocity regulation and for time adjustment.

It is necessary to identify and configure the thresholds for current (I6, I7 and I183) and velocity (V182). Furthermore the stallGuard2 feature has to be adjusted and enabled (SG170 and SG181).

The reduction or increasing of the current in the coolStep area (depending on the load) has to be configured with parameters I169 and I171.

In this chapter only basic axis parameters are mentioned which concern coolStep and stallGuard2. The complete list of axis parameters in chapter 4 contains further parameters which offer more configuration possibilities.




Figure 4.1: coolStep™ adjustment points and thresholds

Number	Axis parameter	Description
I 6	absolute max. current (CS / Current Scale)	The maximum value is 255. This value means 100% of the maximum current of the module. The current adjustment is within the range 0 255 and can be adjusted in 32 steps (0 255 divided by eight; e.g. step 0 = 0 7, step 1 = 8 15 and so on). The most important motor setting, since too high values might cause motor damage!
I 7	standby current	The current limit two seconds after the motor has stopped.
I168	smartEnergy current minimum (SEIMIN)	Sets the lower motor current limit for coolStep [™] operation by scaling the CS (Current Scale, see axis parameter 6) value. Minimum motor current: 0 – 1/2 of CS 1 – 1/4 of CS
I169	smartEnergy current down step	Sets the number of stallGuard2 [™] readings above the upper threshold necessary for each current decrement of the motor current. Number of stallGuard2 [™] measurements per decrement: Scaling: 0 3: 32, 8, 2, 1 0: slow decrement 3: fast decrement
I171	smartEnergy current up step	Sets the current increment step. The current becomes incremented for each measured stallGuard2™ value below the lower threshold (see smartEnergy hysteresis start). current increment step size: Scaling: 0 3: 1, 2, 4, 8 0: slow increment 3: fast increment / fast reaction to rising load
I183	smartEnergy slow run current	Sets the motor current which is used below the threshold speed. Please adjust the threshold speed with axis parameter 182.
SG170	smartEnergy hysteresis	Sets the distance between the lower and the upper threshold for stallGuard2™ reading. Above the upper threshold the motor current becomes decreased.
SG181	stop on stall	Below this speed motor will not be stopped. Above this speed motor will stop in case stallGuard2™ load value reaches zero.
V182	smartEnergy threshold speed	Above this speed coolStep™ becomes enabled.
T214	power down delay	Standstill period before the current is changed down to standby current. The standard value is 200 (value equates 2000msec).

For further information about the coolStep $^{\text{TM}}$ feature please refer to the TMC262 Datasheet.

5 Global parameters

Global parameters are grouped into 4 banks:

- bank 0 (global configuration of the module)
- bank 1 (user C variables)
- bank 2 (user TMCL variables)
- bank 3 (interrupt configuration)

Please use SGP and GGP commands to write and read global parameters.

5.1 Bank 0

Parameters with numbers from 64 on configure stuff like the serial address of the module RS232/RS485 baud rate. Change these parameters to meet your needs. The best and easiest way to do this is to use the appropriate functions of the TMCL-IDE. The parameters with numbers between 64 and 128 are stored in EEPROM only.

An SGP command on such a parameter will always store it permanently and no extra STGP command is needed

Take care when changing these parameters, and use the appropriate functions of the TMCL-IDE to do it in an interactive way.

Meaning of the letters in column Access:

Access	Related	Description
Type	Command(s)	
R	GGP	Parameter readable
W	SGP, AGP	Parameter writable
E	STGP, RSGP	Parameter automatically restored from EEPROM after reset or power-on. These parameters can be stored permanently in EEPROM using STGP command and also explicitly restored (copied back from EEPROM into RAM) using RSGP.

Number	Parameter	Descr	iption		Range	Access
64	EEPROM magic	Settin	g this paramete	er to a different value as	0 255	RWE
		\$E4 w	vill cause re-init	ialization of the axis and		
		1 -		factory defaults) after the		
			•	is useful in case of miss-		
			juration.	is ascial in case of fillss		
65	RS232/RS485	0	9600 baud	Default	0 11	RWE
	baud rate	_1	14400 baud			
		_2	19200 baud			
		3	28800 baud			
		4	38400 baud			
		5	57600 baud			
		6	76800 baud	Not supported by Windows!		
		7	115200 baud			
		8	230400 baud			
		9	250000 baud	Not supported by Windows!		
		10	500000 baud	Not supported by Windows!		
		11	1000000 baud	Not supported by Windows!		
		Atten	tion!			
		The u	ipper speed fo	r RS232 is 115200 baud		
		limite	d by the RS232	transceiver.		
			•	rk with higher speed but		
			out of specification.			
66	serial address	The m	nodule (target) a	ddress for RS232/RS485.	0 255	RWE

Number	Parameter	Description	Range	Access	
67	ASCII mode	Configure the TMCL ASCII interface: Bit 0: 0 – start up in binary (normal) mode 1 – start up in ASCII mode Bits 4 and 5: 00 – echo back each character		RWE	
		01 – echo back complete command 10 – do not send echo, only send command reply			
73	configuration EEPROM lock flag	Write: 1234 to lock the EEPROM, 4321 to unlock it. Read: 1=EEPROM locked, 0=EEPROM unlocked.	0/1	RWE	
75	telegram pause time	Pause time before the reply via RS232 or RS485 is sent. For RS232 set to 0. For RS485 it is often necessary to set it to 15 (for RS485 adapters controlled by the RTS pin).	0 255	RWE	
76	serial host address	Host address used in the reply telegrams sent back via RS232 or RS485.	0 255	RWE	
77	auto start mode	O: Do not start TMCL application after power up (default). Start TMCL application automatically after power up.	0/1	RWE	
79	End switch polarity	0: normal polarity 1: reverse polarity	0/1	RWE	
81	TMCL code protection	Protect a TMCL program against disassembling or overwriting. 0 - no protection 1 - protection against disassembling 2 - protection against overwriting 3 - protection against disassembling and overwriting If you switch off the protection against disassembling, the program will be erased first! Changing this value from 1 or 3 to 0 or 2, the TMCL program will be wiped off.		RWE	
84	Coordinate storage	0 - coordinates are stored in the RAM only (but can be copied explicitly between RAM and EEPROM) 1 - coordinates are always stored in the EEPROM only	0/1	RWE	
85	Do not restore user variables	0 - user variables are restored (default) 1 - user variables are not restored (default)	0/1	RWE	
87	Serial secondary address	Second module (target) address for RS485.	0 255	RWE	
128	TMCL application status	0 -stop 1 - run 2 - step 3 - reset	0 3	R	
129	download mode	0 – normal mode 1 – download mode	0/1	R	
130	TMCL program counter	The index of the currently executed TMCL instruction.		R	
132	tick timer	A 32 bit counter that gets incremented by one every millisecond. It can also be reset to any start value.	0 2 ³²	RW	
133	random number	Choose a random number. Read only!	0 2147483647	R	

5.2 Bank 1

The global parameter bank 1 is normally not available. It may be used for customer specific extensions of the firmware. Together with user definable commands (see section 7.3) these variables form the interface between extensions of the firmware (written in C) and TMCL applications.

5.3 Bank 2

Bank 2 contains general purpose 32 bit variables for the use in TMCL applications. They are located in RAM and the first 56 variables can be stored permanently in EEPROM, also. After booting, their values are automatically restored to the RAM. Up to 256 user variables are available.

Meaning of the letters in column Access:

Access Type	Related Command(s)	Description
R	GGP	Parameter readable
W	SGP, AGP	Parameter writable
E	STGP, RSGP	Parameter automatically restored from EEPROM after reset or power-on. These parameters can be stored permanently in EEPROM using STGP command and also explicitly restored (copied back from EEPROM into RAM) using RSGP.

GENERAL PURPOSE VARIABLES FOR TMCL APPLICATIONS (BANK 2)

Number	Global parameter	Description	Range	Access
0 55	general purpose variables #0 #55	for use in TMCL applications	-2 ³¹ +2 ³¹	RWE
56 255	general purpose variables #56 #255	for use in TMCL applications	-2 ³¹ +2 ³¹	RW

5.4 Bank 3

Bank 3 contains interrupt parameters. Some interrupts need configuration (e.g. the timer interval of a timer interrupt). This can be done using the SGP commands with parameter bank 3 (SGP <type>, 3, <value>). The parameter number defines the priority of an interrupt. Interrupts with a lower number have a higher priority.

Meaning of the letters in column Access:

Access type	Related command(s)	Description
R	GGP	Parameter readable
W	SGP, AGP	Parameter writable

The following table shows all interrupt parameters that can be set.

Number	Global parameter	Description		Range	Acce ss	
0	Timer 0 period (ms)	Time between two interrupts (ms)		0 4.294.967.295 [ms]	RW	
1	Timer 1 period (ms)	Time be	Time between two interrupts (ms)		0 4.294.967.295 [ms]	RW
2	Timer 2 period (ms)	Time be	tween two into	errupts (ms)	0 4.294.967.295 [ms]	RW
27	Stop left 0 trigger transition	0=off, 3=both	1=low-high,	2=high-low,	0 3	RW
28	Stop right 0 trigger transition	0=off, 3=both	1=low-high,	2=high-low,	0 3	RW
39	Input 0 trigger transition	0=off, 3=both	1=low-high,	2=high-low,	0 3	RW
40	Input 1 trigger transition	0=off, 3=both	1=low-high,	2=high-low,	0 3	RW
41	Input 2 trigger transition	0=off, 3=both	1=low-high,	2=high-low,	0 3	RW
42	Input 3 trigger transition	0=off, 3=both	1=low-high,	2=high-low,	0 3	RW

6 Hints and Tips

This chapter gives some hints and tips on using the functionality of TMCL, for example how to use and parameterize the built-in reference point search algorithm or the incremental sensOstep encoder. Further you will find basic information about stallGuard2 and coolStep.

6.1 Reference Search

The built-in reference search features switching point calibration and support of one or two reference switches. The internal operation is based on a state machine that can be started, stopped and monitored (instruction RFS, no. 13). The settings of the automatic stop functions corresponding to the switches (axis parameters 12 and 13) have no influence on the reference search.

Please note:

- Until the reference switch is found for the first time, the searching speed is identical to the maximum positioning speed (axis parameter 4), unless reduced by axis parameter 194.
- After hitting the reference switch, the motor slowly moves until the switch is released. Finally the switch is re-entered in the other direction, setting the reference point to the center of the two switching points. This low calibrating speed is a quarter of the maximum positioning speed by default (axis parameter 195).
- The reference switch is connected in series with the left limit switch. The differentiation between the left limit switch and the home switch is made through software. Switches with open contacts (normally closed) are used.


Choose one of these values for axis parameter 193:

.,,	5				
Value	Description				
1	search left stop switch only				
2	search right stop switch, then search left				
	stop switch				
3	search right stop switch, then search left				
	stop switch from both sides				
4	search left stop switch from both sides				
5	search home switch in negative				
	direction, reverse the direction when left				
	stop switch reached				
6	search home switch in positive direction,				
	reverse the direction when right stop				
	switch reached				
7	search home switch in positive direction,				
	ignore end switches				
8	search home switch in negative				
	direction, ignore end switches				

Adding 128 to these values reverses the polarity of the home switch input.


The next two pages show all possible modes of reference search according to the specific commands on top of each drawing.

SAP 193, 0, 1




Search left stop switch only.

SAP 193, 0, 2




Search right stop switch, then search left stop switch.

SAP 193, 0, 3




Search right stop switch, then search left stop switch from both sides.

SAP 193, 0, 4




Search left stop switch from both sides.

SAP 193, 0, 5




Search home switch in negative direction, reverse the direction when left stop switch reached.

SAP 193, 0, 6




Search home switch in positive direction, reverse the direction when right stop switch reached.

SAP 193, 0, 7



Search home switch in positive direction, ignore end switches.

SAP 193, 0, 8



Search home switch in negative direction, ignore end switches.

6.2 Changing the Prescaler Value of an Encoder

The TMCM-1181 offers an integrated sensOstep encoder. The built-in encoder has 1024 steps/rotation.

For the operation with encoder please consider the following hints:

- The encoder counter can be read by software and can be used to control the exact position of the motor. This also makes closed loop operation possible.
- To read out or to change the position value of the encoder, axis parameter #209 is used.
 So, to read out the position of your encoder 0 use GAP 209, 0. The position values can also be changed using command SAP 209, 0, <n>, with n = ± 0,1,2,...
- To change the encoder settings, axis parameter #210 is used. For changing the prescaler of the encoder 0 use SAP 210, 0, .
- Automatic motor stop on deviation error is also usable. This can be set using axis parameter 212 (maximum deviation). This function is turned off when the maximum deviation is set to 0.

To select a prescaler, the following values can be used for :

Value for	Resulting prescaler	SAP command for motor 0	Microstep solution of
		SAP 210, 0,	axis parameter 140
25600	50 (default)	SAP 210, 0, 25600	8 (256 micro steps)
12800	25	SAP 210, 0, 12800	7 (128 micro steps)
6400	12.5	SAP 210, 0, 6400	6 (64 micro steps)
3200	6.25	SAP 210, 0, 3200	5 (32 micro steps)
1600	3.125	SAP 210, 0, 1600	4 (16 micro steps)
800	1.5625	SAP 210, 0, 800	3 (8 micro steps)
400	0.78125	SAP 210, 0, 400	2 (4 micro steps)
200	0.390625	SAP 210, 0, 200	1 (2 micro steps)

The table above just shows a subset of those prescalers that can be selected. Also other values between those given in the table can be used. Only the values 1, 2, 4, and 16 must not be used for (because they are needed to select the special encoder function below or rather are reserved for intern usage).

Consider the following formula for your calculation:

$$Prescaler = \frac{p}{512}$$

Example: $\langle p \rangle = 6400$

6400/512 = 12.5 (prescaler)

There is one special function that can also be configured using . To select it just add the following value to :

	SAP command for motor 0 SAP 210, M0,
4	Clear encoder with next null channel event

Add up both values from these tables to get the required value for the SAP 210 command. The resulting prescaler is Value/512.

6.3 Using the RS485 Interface

With most RS485 converters that can be attached to the COM port of a PC the data direction is controlled by the RTS pin of the COM port. Please note that this will only work with Windows 2000, Windows XP or Windows NT4, not with Windows 95, Windows 98 or Windows ME (due to a bug in these operating systems). Another problem is that Windows 2000/XP/NT4 switches the direction back to *receive* too late. To overcome this problem, set the *telegram pause time* (global parameter #75) of the module to 15 (or more if needed) by issuing an *SGP 75*, 0, 15 command in direct mode. The parameter will automatically be stored in the configuration EEPROM.

7 Life Support Policy

TRINAMIC Motion Control GmbH & Co. KG does not authorize or warrant any of its products for use in life support systems, without the specific written consent of TRINAMIC Motion Control GmbH & Co. KG.

Life support systems are equipment intended to support or sustain life, and whose failure to perform, when properly used in accordance with instructions provided, can be reasonably expected to result in personal injury or death.

© TRINAMIC Motion Control GmbH & Co. KG 2013

Information given in this data sheet is believed to be accurate and reliable. However neither responsibility is assumed for the consequences of its use nor for any infringement of patents or other rights of third parties, which may result from its use.

Specifications are subject to change without notice.

All trademarks used are property of their respective owners.



8 Revision History

8.1 Firmware Revision

Version	Date	Description
1.26	2012-APR-12	First release version

Table 8.1 Firmware revision

8.2 Document Revision

Version	Date	Author	Description
0.90	2013-APR-15	GE	Preliminary version

Table 8.2 Document revision

9 References

[TMCM-1181] TMCM-1181 Hardware Manual

[TMC262]TMC262 Datasheet[TMC429]TMC429 Datasheet[TMCL-IDE]TMCL-IDE User Manual

Please refer to www.trinamic.com.