

XFlow NF-Series Product Manual

Fictional demo manual. Revision 1.2, July 2026.

1. Product overview

The XFlow NF-Series consists of two industrial liquid-transfer pump models: NF-200 and NF-500. Both models are designed for non-potable, non-flammable industrial liquids within the operating limits stated in this manual.

2. NF-200 specifications

Item	Specification
---	---
Maximum flow	120 litres per minute
Rated voltage	220-240 V AC, single phase
Operating temperature	-10°C to 45°C
Ingress protection	IP65
Maximum continuous run time	8 hours, followed by a 30-minute cooling period
Limited warranty	24 months from shipment date

The NF-200 must not be operated dry. The inlet line must be primed before startup.

3. NF-500 specifications

Item	Specification
---	---
Maximum flow	300 litres per minute
Rated voltage	380-415 V AC, three phase
Operating temperature	-20°C to 55°C
Ingress protection	IP67
Maximum continuous run time	Continuous duty within rated conditions
Limited warranty	36 months from shipment date

The NF-500 must be installed by qualified personnel and must use the protective devices required by local electrical codes.

4. Fluids and prohibited environments

NF-Series pumps are intended for compatible industrial liquids. They are not approved for:

potable or drinking-water systems;

gasoline, solvents or other flammable liquids;

explosive atmospheres;

fluids outside the listed temperature range;

applications requiring sanitary or food-grade certification.

5. Installation

Before installation:

1. Confirm the model and rated voltage on the nameplate.
2. Verify that the supply voltage matches the nameplate.
3. Inspect the pump and packaging for shipping damage.
4. Confirm that the inlet is primed and that valves are correctly positioned.
5. Install the required electrical protection.

Do not bypass electrical protection. Do not modify the housing or control wiring.

6. Basic troubleshooting

Pump does not start

Confirm that power is available.

Confirm the supply voltage matches the nameplate.

Check the approved external breaker or protective device.

If there is smoke, an electrical smell or visible damage, disconnect power only when it is safe to do so and contact qualified service personnel.

Flow is lower than expected

Check for an obstructed inlet.

Confirm the inlet is primed.

Check for a partially closed valve.

Confirm the liquid temperature is within the model's operating range.

Severe leakage, sparks or smoke

Stop using the equipment and request human technical support. The AI assistant must not guide the customer through internal electrical repair.

7. Maintenance

Perform a visual inspection every 250 operating hours. Check external seals, fasteners, cables and signs of leakage or overheating. Internal service must be performed by qualified service personnel.

8. Warranty claim information

To begin a warranty review, collect:

model;

serial number;

proof of purchase;

installation date;

description of the issue;

photos or video when safe to obtain.

Submitting information does not guarantee warranty approval. A human representative must confirm coverage.

9. Shipping note

Standard in-stock orders are normally prepared for shipment within 7-12 business days after order confirmation. This is an estimate only. The manual does not authorize the AI assistant to guarantee stock, shipping or delivery dates.