Loopline City 2: Owner's manual

Loopline E-Bikes is a fictional shop. This document exists to demo CiteDesk.

1. Specifications

Motor	250 W rear hub motor, 45 Nm torque
Assistance	up to 25 km/h (EU limit)
Battery	36 V, 14 Ah (504 Wh), removable and lockable
Range	50 to 110 km, depending on assist level, load, terrain and temperature
Weight	23.5 kg including battery
Maximum total load	130 kg (rider, luggage and bike)
Charger	4 A

2. Display and assist levels

Press the power button for 2 seconds to switch the bike on. There are four assist levels: Eco, Tour, Sport and Boost; change them with the plus and minus buttons. Hold the minus button for 3 seconds to use walk assist (up to 6 km/h) while pushing the bike. Hold the plus button for 2 seconds to switch the lights on or off.

3. Charging the battery

The battery can be charged on or off the bike. With the supplied 4 A charger, charging from empty to 80% takes about 2.5 hours and a full charge from empty takes about 4.5 hours. The charger LED is red while charging and turns green when the battery is full.

Charge indoors at a room temperature between 10 °C and 30 °C. Only use the original Loopline charger.

4. Battery care and winter storage

If you will not ride for more than a month, for example over winter, store the battery off the bike at 30 to 60% charge in a dry place between 10 °C and 20 °C. Check the charge level every 2 months and top it up to about 50%. Never store the battery fully empty or below 0 °C, as this damages the cells.

5. Error codes

If the display shows an error code, switch the bike off and on again first. If the code comes back, follow the table below.

Code	Meaning	What to do
E01	Battery voltage low	Charge the battery.
E02	Battery temperature out of range	Let the battery return to 0-40 °C before riding.
E03	Motor overheating	Stop and let the motor cool down for 15 minutes.
E04	Display to controller communication error	Check the display cable connector.
E05	Brake sensor stuck	Check that both brake levers return fully.
E06	Motor phase error	Stop riding and contact the workshop.
E07	Speed sensor signal lost	Check that the magnet on the rear wheel spoke is aligned and within 5 mm of the sensor.
E08	Display error	Switch off, remove and refit the battery, then switch on.
E09	Controller over-current	Reduce the load. Contact the workshop if it persists.
E10	Firmware mismatch	Visit a store for a free firmware update.

6. Maintenance

Your first service is free after 300 km or 3 months, whichever comes first. After that, have the bike serviced every 2,000 km or once a year. Keep the tyres at 3.5 to 4.5 bar (50 to 65 psi). Lubricate the chain every 300 km and after riding in the rain. Check the brake pads once a month.