

PDU Relay

Installation guide – deploying the relay service and web interface that let the PDU Ctrl.grid DashBoard panel power-cycle USP-PDU-Pro outlets.

What this is

The DashBoard panel (**PDU Ctrl.grid**) cannot log into the UniFi Network controller directly – its scripting engine can only send plain HTTP requests with no custom headers, so it can't carry the cookie/CSRF session UniFi's outlet-control API requires. This relay does that login on the panel's behalf and exposes the endpoints the panel calls instead: a PDU list, an outlet list per PDU, and a power-cycle action per outlet.

It also serves a small **web interface** (open `http://<relay-host>:8090/` in a browser) for setup and day-to-day use, so nothing has to be configured by editing files over SSH: a one-time login page creates an admin account, a Connection Settings page holds the UniFi controller host/credentials, and a PDUs page shows every discovered PDU with live outlet status and reboot buttons – the same control the touch panel has, from any browser on the network.

The web UI's login only protects that configuration/browser surface. The three endpoints the touch panel calls (`/pdu/list` and friends) have no authentication of their own – they can't, since the panel's scripting engine can't send an auth header – so they stay reachable to anything that can reach the port. Restrict that at the firewall (Step 6), not with a login.

Quick install

The code lives at `github.com/hendogg02/pdu-relay`. On a fresh Debian (or Debian-based) host, one command handles Node.js, cloning the repo, installing dependencies, and setting up the systemd service:

```
curl -fsSL https://raw.githubusercontent.com/hendogg02/pdu-relay/main/install.sh | bash
```

That replaces Steps 1–3 and Step 5 below. Review `install.sh` before running it against a host you care about, the way you would with any `curl | bash` installer. Once it finishes, skip ahead to Step 4 (finish setup in the browser).

Steps 1–3 and 5 below walk through what that script does, for anyone who'd rather run each piece by hand or understand it before trusting it.

Prerequisites

- A Debian (or Debian-based) LXC container or VM reachable from both the UniFi controller and the Ultritouch touch panel (and, ideally, whoever will administer it).

- A local UniFi admin account (username + password) – not a Ubiquiti cloud SSO login. Outlet control only exists on the controller's legacy REST API, which needs a real logged-in session.
- The USP-PDU-Pro already adopted in the UniFi Network application.

Step 1 – Install Node.js (manual path)

The relay needs Node 18 or newer (it uses the built-in fetch). Debian's stock apt package is often older, so install from NodeSource:

```
curl -fsSL https://deb.nodesource.com/setup_20.x | sudo -E bash -
sudo apt-get install -y nodejs
node --version
```

Step 2 – Get the code onto the container (manual path)

SSH into the container and clone the repo:

```
sudo git clone https://github.com/hendogg02/pdu-relay.git /opt/pdu-relay
```

(Or copy a local working copy instead, if testing unpushed changes: `scp -r "/path/to/PDU Relay" user@debian-host:/opt/pdu-relay.`)

Step 3 – Install dependencies and start the relay

SSH into the container, install dependencies, and start the relay in the foreground for the first run:

```
cd /opt/pdu-relay
npm install
node pdu-relay-server.js
```

You should see `PDU relay listening on :8090`. Nothing needs to be edited by hand here – there's no `.env` to fill in for the UniFi connection. A `config.json` file is created automatically the first time settings are saved through the web UI in the next step (permissions restricted to the owner, since it holds the UniFi password).

Step 4 – Finish setup in the browser

From a browser on the same network, open:

```
http://debian-host:8090/
```

4a. Create the admin account – this is the login for this web page only, separate from UniFi. Pick a username and an 8+ character password.

4b. Open Connection Settings and fill in:

UDM Host / IP – your UDM SE's IP, e.g. 192.168.1.1

Local admin username / password – a local UniFi admin account

Leave site name, self-signed certificate, and PDU model at their defaults unless you have a specific reason to change them, then press **Save**.

4c. Open the PDUs tab. Within a few seconds it should list every discovered PDU with live outlet buttons – green for on, red for off. Clicking one power-cycles that outlet.

If the PDUs tab shows an error instead, it will say why (bad credentials, unreachable host, connection timeout, etc.) – fix that before moving on to the touch panel.

Stop the foreground process (Ctrl-C) once this works – Step 5 sets it up to run permanently.

Step 5 – Run it as a persistent service (manual path)

So the relay survives reboots and doesn't die when an SSH session ends, run it under systemd. Create `/etc/systemd/system/pdu-relay.service`:

```
[Unit]
Description=PDU Relay for DashBoard PDU Ctrl.grid
After=network-online.target
Wants=network-online.target

[Service]
Type=simple
WorkingDirectory=/opt/pdu-relay
ExecStart=/usr/bin/node /opt/pdu-relay/pdu-relay-server.js
Restart=on-failure
RestartSec=5
User=nobody
Environment=NODE_ENV=production

[Install]
WantedBy=multi-user.target
```

Swap `User=nobody` for a dedicated account if preferred – whichever user runs it just needs read/write access to `/opt/pdu-relay/config.json`. Then enable it:

```
sudo chown -R nobody:nogroup /opt/pdu-relay
sudo systemctl daemon-reload
sudo systemctl enable --now pdu-relay
sudo systemctl status pdu-relay
```

The admin account and connection settings from Step 4 are already saved in `config.json` and will still be there. Check logs any time with:

```
sudo journalctl -u pdu-relay -f
```

Step 6 – Firewall

The relay's port (default 8090) serves both the unauthenticated panel endpoints and the login-gated web UI. Restrict access to only the devices that need it: the Ultritouch panel's IP (for outlet control) and whichever admin machines will manage it (for the web UI) – not the whole LAN.

Step 7 – Point the panel at the relay

Open **PDU Ctrl.grid** on the Ultritouch. It will show only the **Settings** tab until a PDU is found. Enter:

Relay Host – the Debian container's IP or hostname

Relay Port – 8090 (or whatever port the relay is listening on)

Then press **Connect / Refresh PDUs**. A tab should appear for each PDU, matching what the web UI's PDUs page already showed in Step 4.

Updating

```
cd /opt/pdu-relay
sudo git pull --ff-only
sudo npm install --omit=dev
sudo systemctl restart pdu-relay
```

The saved admin login and UniFi connection settings live in `config.json`, which is git-ignored and untouched by an update.

Using the web UI afterward

The web UI stays available for as long as the relay runs – there's no need to go back to the command line for routine use:

PDUs – live outlet status and reboot buttons, same as the touch panel.

Connection Settings – update the UniFi host/credentials any time; changes apply immediately, no restart needed.

Admin Account – change the web UI's own login username/password.

Troubleshooting

PDUs tab shows an error – the message is specific (bad credentials, connection timeout, "UniFi connection isn't configured yet", etc.). Fix it in Connection Settings and it re-checks automatically every few seconds.

No PDUs found, but the connection itself works – the PDU may not be adopted, or the PDU model code on the Connection Settings page may not match this firmware's reported model.

Forgot the web UI's admin password – stop the service, delete `config.json`, and restart it. This clears the admin login *and* the saved UniFi connection settings, so Step 4 will need to be repeated.

Touch panel can't reach the relay – check the firewall rule from Step 6 actually allows the panel's specific IP, and that the relay service is running (`systemctl status pdu-relay`).