

One switch makes everything *bigger*.

Samsung phones have a setting called **Easy mode**. It makes the text larger, the icons bigger, and the keyboard easier to tap — all in one step.

TO TURN IT ON

1

Open Settings.

Look for the round gear icon.

2

Tap Display.

3

Scroll down and tap Easy mode.

4

Tap Apply.

A preview shows you how it will look first.



Your home screen changes right away.

What you'll *notice*.



Bigger text, everywhere

Menus, messages, and web pages all grow.



Larger app icons

Easier to find and tap the right one.



A bigger keyboard

Wider keys with clearer, high-contrast letters.



Fewer accidental taps

The screen waits a moment longer before responding.

GOOD TO KNOW

Nothing is deleted. Your apps, photos, and messages all stay exactly where they are.

You can switch back to the normal view **any time**.

TO TURN IT BACK OFF

Open **Settings** → **Display** → **Easy mode**, then tap to turn it off. Your phone returns to normal right away.