

Steady taps, shaky hands.

When a finger jiggles, the screen reads the tap as a swipe. Tap Assistance pins the tap to where the finger **first lands** — set it up before switching on, and dial it in with them.

What's happening

A jiggle reads as a swipe.

The tap drifts, and the screen scrolls instead of selecting.

Tap Assistance fixes the drift.

It locks the tap to where the finger first lands.

Set it up before turning it on.

It changes how every touch responds.

The setup

Settings → Accessibility → Touch.

Then Touch Accommodations, under Physical & Motor.

Tap Assistance → Initial Touch Location.

The core fix for a drifting tap.

Then switch Touch Accommodations on.

The master toggle at the top.

Two more for tremor

Hold Duration.

The screen waits before a touch counts — grazes don't fire.

Ignore Repeat.

Several shaky taps in a row count as one.

Keep the timers short.

Start small; long delays feel broken.

Set it with them

Dial it in gently.

Too much delay frustrates more than the tremor did.

Let them tap as you adjust.

Tune to their hand, not a default.

Warn them it'll feel slower.

The pause is the feature, not a fault.

Show the off switch first.

Triple-click the side button toggles it.

Using it after

Tap = touch, then lift.

It lands at the first touch point.

Swipe = touch, wait, then drag.

Gestures work after the gesture delay.

It's in the Accessibility Shortcut.

Quick on/off without digging in Settings.

Settings plus support

Pair it with bracing.

Phone on a table, elbow steadied, a stylus.

Revisit as their hand changes.

What fits today may need a nudge later.

Helping elders keep their independence — and giving their helpers the tools to do it well.