

Each key = a switch in series with a diode (COL -> switch -> diode -> ROW).
The rotary encoder's push-switch sits on col P15 x row P11 (see Encoder).

net label = logical signal assigned to it. Match your firmware to these pins.

Parasonic EVQWGD001 scroll encoder. A/C to MCU, B/D to GND. Push-switch (S1/S2) is in the key matrix (col P15 x row P11) via node ENC1_SW and diode D30.

Battery+ -> power switch -> nice!nano RAW; Battery- -> GND.
Reset button shorts RST to GND for reflashing.