



Each key = a switch in series with a diode (COL → switch → diode → F)
The rotary encoder's push-switch sits on col P15 x row P11 (see Encoder).

nicelnano (or Pro Micro compatible). Pin name = physical pin
net label = logical signal assigned to it. Match your firmware
to these pins.



Panasonic EVQWGD001 scroll encoder. A/C to MCU, B/D to GND.
Push-switch (S1/S2) is in the key matrix (col P15 x row P11)
via node ENC1_SW and diode D30.



Battery+ -> power switch -> nice!nano RAW; Battery- -> GND;
Reset (Panasonic EVQ-PUC02K) shorts RST to GND for reflashing;

