Version 0.0 (rev 1)
Designed for use with Eagle PCB layout software
www.freeware.com
Author: Kevin Hall
Date: 2/12/2005
U2
ATMEGA328
TP5
R8
TP4
TP3
U3
TP13
TP14
C8
C7
TP9
TP10
U4
TP11
TP12
R7
C6
C10
U1
C1
R1
C2
R6
U5
C9
R9
OUT
TP6 TP7TP8
M2
R4
IN
R3
TP2
TP1
C4
C3
D1
D2

Version 0.0 (rev 1)
Designed for use with Eagle PCB layout software
www.freeware.com
Author: Kevin Hall
Date: 2/12/2005
U2
ATMEGA328
TP5
R8
TP4
TP3
U3
TP13
TP14
C8
C7
TP9
TP10
U4
TP11
TP12
R7
C6
C10
U1
C1
R1
C2
R6
U5
C9
R9
OUT
TP6 TP7TP8
M2
R4
IN
R3
TP2
TP1
C4
C3
D1
D2

Version 0.0 (rev 1)
Designed for use with Eagle PCB layout software
www.freeware.com
Author: Kevin Hall
Date: 2/12/2005
U2
ATMEGA328
TP5
R8
TP4
TP3
U3
TP13
TP14
C8
C7
TP9
TP10
U4
TP11
TP12
R7
C6
C10
U1
C1
R1
C2
R6
U5
C9
R9
OUT
TP6 TP7TP8
M2
R4
IN
R3
TP2
TP1
C4
C3
D1
D2