## YunSDR V3.0

00 TOP PAGE01 PAGE02 01 ZINGSOM SODIMM 02 CONFIG PAGE03 03 DEVICE MIO PAGE04 04 LAN&USBOTG PAGE05 09 FMC-LPC PAGE06 06 SMA PAGE07 PAGE08 07 PL PIO 08 SYS POWER PAGE09

4













