

Introducing

World's Leading Domestic Robots

Now, maintaining homes is a pleasure!

Self sufficient and packed with advanced features, these Robots gently scrub, clean and disinfect your space, all on their own! Just pre-programme them as per your needs. Thereafter, go wherever; do whatever, your floors and windows will be squeaky clean automatically. With Milagrow cleaning robots, now cleaning will be a delight!



Floor Cleaning Robots



Order online at www.milagrowhumantech.com | 0% Finance available. Conditions apply.

- 6 reasons why you need a Domestic Robot:
- Time Constraints
 - Security
 - Hygiene and Disinfection
 - Unskilled Domestic Help
 - 24x7 Availability
 - Maintenance of Expensive Furniture & Carpets

Milagrow Business and Knowledge Solutions (P) Limited
796, Phase V, Udyog Vihar, Gurgaon - 122 016, Phone : +91-124-4309570-79
Fax : +91-124-4309580, E-mail : customercare@milagrow.in

Customers - SMS <Window + E-mail ID + City> to 09953476189 or E-mail at customercare@milagrow.in

Specifications are subject to change without prior notice with the purpose of product enhancement and quality improvement. Brand Names and Brand Logos are trademarks or registered trademarks of those companies. Milagrow Business & Knowledge Solutions has rights only on the Milagrow brand name mentioned in the catalogue.

MILAGROW


User Manual

MILAGROW

World's only TabTop™ PC



MRP: ₹9,990



MGPT09

Laptops and Tablets are now history!

5-point Capacitive Multi-Touch 16:9 Screen

Calling function, in-built 3G SIM slot

1.2 GHz Processor
1 GB DDR 3 RAM

Dual Camera

Bluetooth

3000 mAh Battery,
8+ hours



Please read carefully before use

- Please read this manual before you operating your tablet, and keep it for future reference
- The descriptions in this manual are based on the default settings
- Images and screenshots used in this manual may differ from the actual product
- Available features and additional services may vary by device, software or service provider
- Our company is not liable for performance issues caused by third-party applications

Table of Contents

Assembling	- 5 -
Unpack	- 5 -
Charge the Battery	- 5 -
Install the SIM Card	- 5 -
Install the Memory Card	- 5 -
Getting started	- 6 -
Turn your device ON and OFF	- 6 -
Switch to Flight Mode	- 6 -
Device Layout	- 7 -
Home Screen	- 7 -
Add items to the Home Screen	- 7 -
Task Bar	- 8 -
Notification Panel	- 8 -
Auto Rotation	- 9 -
Lock & Unlock the Screen	- 9 -
Enter Text	- 9 -
Customize your Device	- 9 -
Manage Applications	- 10 -
Security	- 10 -
Reset Tablet	- 10 -
Communication	- 11 -
Phone	- 11 -
Contacts	- 12 -
Messaging	- 13 -
Email	- 14 -
Gmail	- 15 -
Web	- 16 -
Browser	- 16 -
Play Store	- 16 -
Talk	- 17 -

Table of Contents



MILAGROW 

Entertainment

- Super-HD Player - 18 -
- Music - 19 -
- Camera - 20 -

Tools

- Calendar - 22 -
- Alarm - 22 -
- File Manager - 22 -
- Sound Recorder - 22 -
- Calculator - 23 -

Connectivity

- USB Connection - 23 -
- Bluetooth - 23 -
- Wi-Fi - 24 -

Safety Precautions

Care & Maintenance

- 18 -

- 18 -

- 19 -

- 20 -

- 22 -

- 22 -

- 22 -

- 22 -

- 22 -

- 23 -

- 23 -

- 23 -

- 23 -

- 23 -

- 24 -

- 25 -

- 26 -

Assembling

Unpack

Check your product box for the following items

- Tablet
- User manual
- Adapter

You can purchase additional accessories from your local retailer.

Charge the Battery

Before using the device for the first time, you must charge the battery.

1. You can charge the device with a travel adapter or by connecting the device to a PC with a USB cable

2. 'Battery Full' icon is shown when charging is finished even if your device is off

Warning: Use only original batteries and chargers. Unapproved chargers or cables can cause batteries to explode or damage your device.

Install the SIM Card

You need to insert a SIM card to use the Phone function. To install the SIM card, follow the instructions below.

1. Make sure that the card's gold contacts face into the device
2. Push the SIM card into the slot until it clicks

Install the Memory Card

To store additional multimedia files, you need insert a memory card.

1. Insert a memory card with the gold contacts facing downwards
2. Push the memory card into the slot until it clicks

Notice: Our company uses approved industry standards for memory cards, but some brands may not be fully compatible with your device.



Getting started

Turn your device ON and OFF

To turn ON your device, press and hold the power key.

To turn OFF your device, press x and hold the power key, and then tap OK.

Switch to Flight Mode

To use only your device's non-network services, switch to flight mode. Please follow the instructions below to turn ON flight mode:

Tap **Settings**→**WIRELESS & NETWORKS**→**More**→**Airplane** mode from application list or turn ON **Airplane mode** from the notification panel.


Device Layout



Volume Keys	Adjust the device volume.
Power/Lock/Reset	Press and hold for 2 seconds to turn ON or turn OFF the device.
	Press to lock the device.
	Press and hold for 6 seconds to reset the device.

Home Screen

The Home Screen has multiple panels. Scroll left or right to the panels on the Home Screen, you can view indicator icons, widgets, shortcuts to applications, and other items.



- | | |
|---|---|
| 1 | Open the search bar |
| 2 | Access the application list and widget screen |
| 3 | Scroll left or right to the other panels |
| 4 | Task bar |

Add items to the Home Screen

Tap the icon at the upper right to access the application list shown below from Home Screen.



Scroll left or right to view more items.

To add items to the Home Screen, tap and hold an item, then drag the item to a new location.

To remove items from the Home Screen, tap and hold an item, then drag the item to the **Remove** area at the top of the Home Screen.


Getting started



MILAGROW

Task Bar

The Task Bar is shown at the bottom of the screen. It displays commonly used option buttons, battery level indicator, current time and other indicator icons.



1	Return to previous screen
2	Return to home screen
3	View the applications you have accessed recently
4	Adjust the device volume to low
5	Adjust the device volume to high
6	Open a list of options available on the current screen
7	Display notification icons. Tap the notifications area to open the Notification Panel


Indicator icons

Icon	Definition	Icon	Definition
	Open Wi-Fi available		Flight mode activated
	Wi-Fi connected		New email
	Signal strength		New text or multimedia message
	Roaming mode		Call in progress
	Uploading data		Missed call
	Downloading data		Call on hold
	Connected to PC		Call diverting activated
	Bluetooth activated		Alarm activated
	Battery power level		Music being played

Notification Panel

Tap the notifications area to open the Notification Panel shown below. You can access a list of notifications.

Tap to activate or deactivate wireless connection features and other settings.



Airplane mode: Activate or deactivate the flight mode.

Wi-Fi: Activate or deactivate the Wi-Fi connection.

Auto-rotate screen: Activate or deactivate the auto rotation feature.

Brightness: Adjust the basic brightness level of the display to lighter or darker.

Notifications: Activate or deactivate the notification feature.

Settings: Access Settings application.

Auto Rotation

If you rotate the device while using some features, the interface will automatically rotate as well. To prevent the interface from rotating, open the notifications panel and select Auto-rotate screen, then scroll it to OFF.

Lock & Unlock the Screen

To Unlock the Screen, tap and hold the lock icon, then drag it to the unlock area where the **Unlock** icon is.

To lock the screen manually, press **Power** key.

Enter Text

You can enter text by selecting characters on the virtual keyboard.

Tap the text input field to display the virtual keyboard. To hide the keyboard, tap at the task bar.

To change the text input method, tap at the task bar.

From a text field, you can use the copy and paste feature for faster input.

Customize your Device

To customize your device according to your preferences, tap **Settings** from application list or Notification Panel.



Manage Applications

To manage the applications installed on your device, tap **Settings**→**App.**

1. To uninstall an application, select **DOWNLOADED**, then select an item and tap **Uninstall**, tap **OK** to confirm
2. To stop or change the settings of an application, select **RUNNING** or **ALL**, then select an item and tap the option you need

Security

You can protect your device and data by setting screen lock or encrypting your tablet.

❖ Set a screen lock

To set a screen lock, tap **Settings**→**Security**→**Screen lock** from application list.

- **None:** Deactivate the screen lock
- **Slide:** Slide to unlock the screen
- **PIN:** Enter a numeric PIN to unlock. When prompted, enter the PIN to unlock the screen
- **Pattern:** Draw a pattern to unlock. Follow the instructions to draw your lock pattern. When prompted, draw the pattern to unlock the screen
- **Password:** Enter a passcode to unlock. When prompted, enter the passcode to unlock the screen

❖ Screen time-out

Select **Settings**→**Display**→**Sleep** from application list, you can set the time before the screen times out and goes into lock mode. (you have not entered any characters or made other selections).

❖ Encrypt tablet

You can encrypt your accounts, settings, downloaded apps and their data, media and other files. Once you encrypt your tablet, you must enter a numeric PIN or password to decrypt it each time you switch on your device.

Reset Tablet

You can reset system and desktop settings to their original values by the following steps:

1. Select **Settings**→**Backup & reset** from application list
2. Tap Factory data reset
3. If you want to erase all data on your tablet, such as music, pictures, and other data, tap **Erase SD card** checkbox to create a checkmark
4. Tap **Reset Tablet**

The device resets to the factory default settings automatically.

Warning: Factory data reset will erase all data from your device and SD card, including your google account, system and application data and settings, and downloaded applications.

Communication

Phone

To use calling functions, tap **Phone** from application list.

❖ Make calls

To make calls, you can use any of the three ways:

- Enter numbers by using the virtual numeric keypad on the screen
- Make a call from call log
- Make a call from contacts

❖ Answer a call

To answer a call, drag the circled button to the green button.

❖ Decline or end a call

To decline a call, drag the circled button to the red button.

To end a call in progress, tap the red button.

❖ Call settings

To change call settings, tap the option button at the upper right.

1. Fixed Dialing Numbers

If FDN mode is activated, your device will restrict outgoing calls, except for the numbers stored in the FDN list.

2. Quick responses

Quick response is a feature to reject the call with the predefined messages.

Tap one of the pre-written messages to be displayed when you want the call to be rejected, then tap **OK**.

3. Voice mail service

With the call divert network service, you can direct incoming calls to your voice mailbox. Tap this item to set your voice mail service provider.

4. Voice mail settings

Set your voice mail number.

5. Call forwarding

Call diverting is a network feature to send incoming calls to another number that you specify.

6. Call waiting

If call waiting is activated, the network notifies you of a new incoming call while you have a call in progress or you can make a new call during a call.



Contacts

Tap **People** from application list to access contacts.

- **Groups:** List all your contacts by group.
- **All:** List all your contacts saved in the device memory.
- **Favorites:** List the contacts that you have set as favourites or the contacts that you have sent message to or dialed.

(To set the contact as your favourites, select  at the title bar.)

❖ Add new contact

1. Access **People**

2. Tap 

3. Enter necessary fields

4. Tap **DONE**

❖ Edit a contact

1. To edit a contact, scroll to the contact you want to change

2. Tap the option button at the upper right, then select **Edit**

3. Change necessary fields

4. Tap **DONE**

❖ Create new group

1. Tap the first tab at the upper left

2. Tap  at the upper right

3. Enter a category name

4. Tap **DONE**

❖ Rename group

1. To rename the group, scroll to the group you want to change

2. Tap  at the upper right or tap the option button and then select **Edit**

3. Enter a new category name

4. Tap **DONE**

❖ Import/Export contacts

1. Import from the SIM card

To copy the contacts from the SIM card, tap the option button at the upper right and then select **Import/Export→Import from the SIM card**, select **contacts**, and then select **Import**.

2. Import from SD card

To import contact files (in vcf format) from a memory card to your device, tap the **option** button at the upper right and then select **Import/Export→Import from SD card**, select a memory location and contact files to import and select **OK**.

3. Export to SD card

To export contacts from your device to a memory card, tap the option button at the upper right and then select **Import/Export→Export to SD card**, select **OK** to confirm.

4. Share visible contacts

With this feature, you can send the visible contacts via Email or Bluetooth.

❖ Search for contacts

1. Tap  at the title bar from contact list screen, enter the desired information, then your device shows the result

2. Tap the search icon at the upper left from home screen, enter the contact's name or number, your device shows the result immediately

Messaging

Learn to create and send a text or multimedia message, and view or manage messages that you have sent or received.

❖ View messages

1. Tap **Messaging** from application list

2. Tap the message to view the detailed information

❖ Create and send SMS

1. Tap **NEW MESSAGE**

2. In **To** field, enter the recipient's mobile phone numbers manually. If you enter more than one number, separate the numbers with a comma

3. In **Type message**, enter the text of the message

4. Select **Send** to send the message

❖ Create and send MMS

Multimedia message can include pictures, sound and text.

1. Tap **NEW MESSAGE**

2. Tap  at the title bar

3. Select one of the items below



- **Pictures:** Insert image
 - **Capture picture:** Capture new picture and insert the picture
 - **Videos:** Insert video clip
 - **Capture video:** Capture new video clip and insert the video clip
 - **Audio:** Insert sound clip
 - **Record audio:** Record sound clip and insert the sound clip
 - **Slideshow:** Add more than one slide
4. In **To** field, enter the recipient's mobile phone numbers or email addresses manually. If you enter more than one number or email, separate them with a comma
5. In Type message field, enter the text of the message
6. Select Send to send the message

Email

To receive and send mail, you must have a remote mailbox service. This service may be offered by a service provider. Your device is compliant with applicable internet standards for POP3/IMAP/ Exchange.

Before you can send or receive mail on your device, you need to set up an email account and define the email settings correctly. You can define more than 1 mailbox.

❖ Set up your email

1. Tap **Email** from application list.
2. You can use mailbox guide to set up your mailbox, tap **Next** until it's done.
3. If you need to add another email account, tap the option button at the upper right→**Settings**→**ADD ACCOUNT**, then set up the email account with the mailbox guide.

When you are finished setting up the email account, the email messages are downloaded to your device. If you have created more than two accounts, you can switch between email accounts. Select an account name at the top left of the screen and select the one you want to retrieve messages from.

❖ Delete your email account

1. Open the application list and select **Email**.
2. Tap the option button at the upper right, then select **Settings** and the email account you want to delete.
3. Tap **Remove account**.
4. Tap **OK** to confirm.

❖ Create and send email

1. Open **Email** application
2. Tap +
3. In **To** field, enter the recipient's email addresses manually and separate them with a comma. Add more recipients by tapping **Cc/Bcc**
4. To insert attachments, tap the **option** button at the upper right and select **Attach file**
5. Enter the subject and the text
6. Tap **SEND** to send the email

Gmail

You can retrieve new email messages from the **Google Mail** webmail service to your inbox. Before you can send or receive mail on your device, you need to set up a **Gmail** account.

❖ Create a Gmail account

If you don't have a Google Account, tap **New**, then follow the on-screen instructions to create a new one.

❖ Set up a Gmail account

If you want to add an existing account, tap **Existing**, enter your email address and password, and then select **Next**, when you are finished setting up the email account, the email messages are downloaded to your device.

❖ View email messages

1. When you open the email account, the amount of unread email messages is displayed at the title bar and the unread email messages are displayed in bold
2. To view an email message, tap it
3. To mark an important email message, tap show the icon below the date. To cancel the mark, tap the show the icon again

❖ Create and send an email

1. Tap +
2. In **To** field, enter the recipient's email addresses manually and separate them with a comma. Add more recipients by tapping **Cc/Bcc**
3. To insert attachments, tap the **option** button at the upper right and select **Attach file**
4. Enter the subject and the text
5. Tap **SEND** to send the email



Web

Browser

Tap **Browser** from application list to access to the web.

❖ Browser webpages

1. Select Browser to launch a specified homepage
2. To access a specific webpage, select the URL input field, enter the web address of the webpage, and select **Go**
3. To zoom in, place two fingers on the screen and spread them apart. To zoom out, move your fingers closer together. You can also double-tap the screen

❖ Add windows

You can have multiple windows open at one time.

1. To add a new window, tap at the title bar
2. To open up a window, tap the title of the window
3. To close the window, tap at the title bar

❖ Set homepage

1. Tap the **option** button at the upper right
2. Select **Settings**→**General**→**Set homepage**
3. Enter the web address of the desired webpage

❖ Add bookmarks

While navigating a website, tap to add current URL to your bookmark list and easily access it later.

❖ View bookmarks and history

Tap to open the bookmark list and the recent history. Tap a bookmark or any entry to display the webpage.

❖ Customize browser

To make adjustments in your browser settings, tap the **option** button at the upper right, and then select **Settings**.

Play Store

Play Store allows you to easily download an abundance of applications directly to your device. Before using the Play Store, you must have a Google Account.

1. From the application list, tap **Play Store**
2. Sign in to your Google Account
3. Search for and download applications as desired
4. Follow the on-screen instructions

Note

- All applications offered by Play Store are developed by third party. To get the information about the developers, you can read the descriptions of each application.
- Our company is not liable for performance issues caused by third-party applications.

Talk

Google Talk is a free web-based application for instant text, voice and video chats. Before using the Google Talk, you must have a Google Account.

1. From the application list, tap **Talk**
2. Set up a Google account or sign in, follow the on-screen instructions
3. Select **Add friend**, enter a friends email address and select **Send invitation**
4. When your friend accepts the invitation, he or she is added to your friend list. You can start talking



Entertainment

Super-HD Player

To view or organize your images and video clips, or edit and send your files to other devices, or set photos as wallpapers, select **Super-HD Player** from application list.

Note: It takes a few more minutes to enter this application if you store more files.

❖ Supported file formats

Type	Format
Image	JPEG, GIF, BMP, PNG
Video	AVI, RM, RMVB, MOV, FLV, 3GP, MP4

Note: Some files may not play properly depending on how they are encoded.

❖ View a photo

1. Select a folder
2. Select a photo to view. To view more photos, scroll left or right
3. To zoom in, place two fingers on the screen and spread them apart. To zoom out, move fingers closer together, you can also double-tap the screen
4. To start a slideshow, tap  at the title bar
5. To view the details of a file, tap the **option** button, then select **Details**
6. To share a photo with others via Bluetooth, Email, Gmail or Messaging, tap  at the title bar
7. To set a photo as wallpaper, tap the option button at the upper right→select **Set picture as→Wallpaper**→drag the slides of the crop box to create the crop area, then tap **Crop**
8. To set a photo as a caller ID, tap the option button at the upper right→select **Set picture as→Contact photo→Contacts**→Create a new contact or select an existing contact→drag the slides of the crop box to create the crop area, then tap **Crop**

❖ Edit a photo

1. To crop the image, tap the option button at the upper right, then select **Crop**
 - To move the crop box , tap and hold the crop box and drag it to the desired location
 - To add or subtract from the selection border of the crop box, drag the crop box to the desired size
 - When you are finished, tap **Save**
2. To edit photos and apply various effects, tap the **option** button at the upper right, then select **Edit**
 - To adjust contrast, tap 
 - To apply a filter effect, tap 

- To apply a colour effect, tap 

- To crop, straighten, rotate or flip the image, tap 

❖ Play a video

1. Select a folder
2. Select a video to play
3. Control playback with the virtual keys
4. To watch a video saved on your device on TV, **connect** your device and TV with HDMI cable

Music

With Music, you can play music files. The music player supports the following file formats: MP3, AAC, APE, WMA, OGG, WAV, M4A and many more.

Note: Some files may not play properly depending on how they are encoded.

❖ Add music files to your device

Start by transferring files to your device or memory card.

❖ Play music

1. Select a music file
2. Control playback with the virtual keys
 -  The current list of songs are randomly shuffled for playback
 -  Replays the current list when the list ends
 -  Repeats the current playing song

❖ Create a playlist

1. Tap and hold a music file
2. Select **Add to playlist**
3. Select **New**
4. Enter a name
5. Tap **Save**

❖ Delete a playlist

1. Tap **Playlists**
2. Tap and hold the playlist you want to delete
3. Select **Delete**



Camera

With the camera function, you can capture photos and take videos.

❖ Capture a photo

1. Open the application list and select **Camera**
2. Before taking a picture, you need to make some adjustments




Icon	Definition
	Tap to switch between the front and rear camera lenses
	Tap and drag it to zoom in or zoom out.
	Tap to display other settings.
	Change to camera mode.
	Change to panorama mode to take a landscape photo.
	Adjust the colour balance.
	Adjust the exposure value.
	Go to the camera settings to change the resolution option or reset menus to default settings.

3. Aim the lens at the subject and tap to take a photo. The photo is saved automatically to the folder **DCIM**

4. Select the picture the icon at the upper right to view the pictures

❖ Record a video

1. Open the application list and select Camera. Tap to change to video mode
2. Before recording a video, you need to make some adjustments



Icon	Definition
	Tap to switch between the front and rear camera lenses
	Tap and drag it to zoom in or zoom out.
	Tap to display other settings.
	Change to video mode.
	Adjust the colour balance.
	Set the self-timer delay.
	Go to the camera settings to reset menus to default settings.

3. Tap to start recording. The length of the video recording is restricted by the available space on your storage
4. Tap to stop recording. The video is saved automatically to the folder **DCIM**
5. After recording videos, select picture the icon at the upper right to view the recorded videos



Tools

Calendar

With the Calendar feature, you can consult the calendar by day, week, or month, create events, and set an alarm as a reminder, if necessary.

To access the calendar, tap **Calendar** from application list.

1. To create an event, tap

- Fill in the fields, and set category, date, time & an alarm
- After you finish, select **DONE**

2. You can view calendar in different views, Day, Week, Month and All

3. To delete an entry, tap the event to open it, and then select

Alarm

From application list, tap **Clock**, and then select **Set alarm**.

1. Tap **Add alarm**

2. Select the tick box next to **Turn alarm** ON to activate alarm

3. Set alarm details, when you are finished, select **OK**

4. When the alarm sounds, to stop the alarm, tap **Dismiss**. To repeat the alarm after a specified length of time, tap **Snooze**

5. To cancel an alarm, remove the tick in the check box by tapping on it

6. To delete an alarm, tap and hold the alarm to delete, and then select **Delete alarm**

File Manager

Many features of the device, such as images, videos, documents, received attachments and downloaded files or applications, use memory to store data. With **File manager**, you can store and browse files and folders in your device, or edit, move, copy files; you can send files to compatible devices as well.

Note:

1. Some files formats are not supported depending on the software of the device

2. Some files may not play properly depending on how they are encoded

Sound Recorder

With **Recorder**, you can record a voice memo. From application list, tap **Recorder**.

1. To record a voice memo, tap

2. To pause the recording, tap

3. To listen to a voice recording that you just recorded, tap

Calculator

With this feature, you can use the device as a calculator. The calculator provides the basic arithmetic functions. Tap the virtual numeric and calculation keys to perform a calculation.

Connectivity

USB Connection

You can connect your device to a PC and use it as a removable disk, which allows you access the file directory.

1. If you want to transfer files from or to a memory card, insert a memory card into the device
2. With a USB cable, connect your device to a PC
3. Open the notification panel, select **USB connected**
4. Tap **Turn on USB storage**
5. Open the folder to view files
6. Copy files from the PC to the memory card

Bluetooth

You can connect wirelessly to other compatible devices with wireless Bluetooth technology. The two devices only need to be within 33 feet of each other.

With Bluetooth technology you can do the followings: handle calls with wireless Bluetooth headset, listen to music wirelessly with Bluetooth stereo headset, send or receive data.

❖ Activate Bluetooth

1. From application list, tap **Settings**.
2. In the field of **WIRELESS & NETWORKS**, turn ON the Bluetooth feature.

❖ Find and pair with other Bluetooth-enabled devices

1. Select **Settings** **WIRELESS & NETWORKS** **Bluetooth** **Search for devices**
2. Select a device
3. Enter a PIN and select **OK**. When the owner of the other device enters the same PIN or accepts the connection, pairing is complete. If the pairing is successful, the device will automatically search for available services

Note: Some devices, especially headsets may have a fixed Bluetooth PIN, such as 0000. If the other device has a PIN, you must enter it.

❖ Send data via Bluetooth

1. Select a file, such as a contact or a media file
2. Select an option of sending data via Bluetooth
3. Search for and pair with a Bluetooth-enabled device



❖ Receive data via Bluetooth

1. Select **Settings**→**WIRELESS & NETWORKS**→**Bluetooth**, tap **Bluez** to set your device is visible to other Bluetooth devices
2. When prompted, enter the PIN for the Bluetooth wireless feature and select **OK**
3. Tap  at the task bar and then select **Accept** to confirm and receive data from the device

Wi-Fi

With Wi-Fi, you can connect to the internet or other network devices anywhere an access point or wireless hotspot is available.

❖ Activate the Wi-Fi feature

1. From application list, tap **Settings**
2. In the field of **WIRELESS & NETWORKS**, turn on the Wi-Fi feature

❖ Find and connect to Wi-Fi

1. Once the Wi-Fi feature is activated, the device automatically search for available Wi-Fi connection
2. Select a network
3. Enter a password for the network (if necessary)
4. Select **Connect**

Safty Precautions

Read these simple guidelines before using your device. Not following them may be dangerous or illegal.

❖ Aircraft

Switch off in aircraft and follow any restrictions. Wireless devices can cause interference in aircraft.

❖ Vehicles

Never use your device while driving. Place it in a safe place.

Position your device within easy reach. Be able to access your device without taking your eye off the road.

❖ Electronic devices

In some circumstances your device may cause interference with other devices.

❖ Potentially explosive environments

Switch OFF your device when in any area with a potentially explosive atmosphere, and obey all signs and instructions. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death.

❖ Pacemakers and other medical devices

Pacemaker manufacturers recommend that a minimum separation of 8 inches be maintained between a wireless device and a pacemaker to avoid potential interference with the pacemaker.

Operation of any radio transmitting equipment, including wireless phones may interfere with the functionality of inadequately protected medical devices. Consult a physician or the manufacturer of the medical device to determine if they are adequately shielded from external RF energy or if you have any questions.

Switch off your device in health care facilities when any regulations posted in these areas instruct you to do so.

❖ Operating environment

When connecting to other device, read its user guide for detailed safety instructions. Do not connect incompatible products.

Do not place your device in the air bag deployment area.

Use the device only in its normal operating positions as explained in the product documentation.

Always switch OFF your device when its use is prohibited or when it may cause interference and danger.

❖ Areas with posted regulations

Switch OFF your device when any regulations posted in these areas instruct you to do so.



Care & Maintenance



Care & Maintenance

- ❖ Use only manufacturer-approved accessories. Use of general accessories may shorten the life of your device or cause device to malfunction
 - ❖ Keep your device dry. Humidity and all types of liquids may damage device parts or electronic circuits
 - ❖ Do not use or store the device in dusty, dirty areas
 - ❖ Do not store the device in hot or cold areas
 - ❖ Do not store your device near magnetic fields
 - ❖ Do not store your device with such metal objects as coins, keys and necklace
 - ❖ Do not drop your device or cause impacts to your device

Notes