Screw Air Compressor SC-22 - Operation and Service Manual (sample)

1. Operating data

Rated working pressure 8 bar; maximum pressure 10 bar. The safety valve opens at 11 bar. Motor power 22 kW. Normal oil temperature during operation is 75 to 95 degrees C. The compressor shuts down automatically when the oil temperature reaches 110 degrees C (fault F-12).

2. Service intervals

Replace the air intake filter AF-22 every 2000 operating hours, or every 1000 hours in a dusty environment. Replace the oil filter OF-22 and change the compressor oil (12 litres, ISO VG 46 compressor oil) every 4000 operating hours. Replace the oil separator element OS-22 every 8000 operating hours. Drain condensate from the receiver every day. Check belt tension every 500 operating hours.

3. Faults

Fault F-12: high oil temperature. Check the oil level, clean the oil cooler fins with compressed air and check that the room ventilation is not blocked.
Fault F-20: motor overload. Check the supply voltage on all three phases and the belt tension.
Fault F-31: pressure does not build up. Check the intake valve and look for leaks in the delivery line.