

Hardware Connections (TSOP1738 to Arduino)

Hold the TSOP1738 so the rounded bump (the sensor side) is facing you. The pins from left to right are **GND**, **VCC**, and **OUT**.

Connect them to your Arduino as follows:

- **Pin 1 (Left - GND):** Connect to any **GND** pin on the Arduino.
- **Pin 2 (Middle - VCC):** Connect to the **5V** pin on the Arduino.
- **Pin 3 (Right - OUT):** Connect to **Digital Pin 11** on the Arduino (as defined by `RECV_PIN = 11` in your code).

Required Library to Install

Your code requires the **IRremote** library. Since your code uses the newer syntax (`IrReceiver.begin()` and `IrReceiver.decodedIRData.decodedRawData`), you need to ensure you install **version 3.0 or higher**.

How to install it in the Arduino IDE:

1. Open the Arduino IDE.
2. Go to **Sketch > Include Library > Manage Libraries...** (or press `Ctrl + Shift + I` / `Cmd + Shift + I` on Mac).
3. In the search bar of the Library Manager, type **IRremote**.
4. Look for the library named **IRremote** (usually authored by *shirriff*, *z3t0*, *ArminJo*).
5. Select the latest version from the dropdown menu and click **Install**.

Once installed, simply compile and upload your code. Open the Serial Monitor, set the baud rate to **9600**, and point your remote at the sensor!