

Wiring Connections

A standard Rain Drop Sensor typically consists of two parts: a rain-sensing board (the plate with exposed traces) and a control module (the small board with the potentiometer and pins).

Step 1: Connect the Sensor Board to the Control Module

- Use the two female-to-female jumper wires to connect the two pins on the rain-sensing plate to the two unmarked pins on the control module. Polarity does not matter for these two wires.

Step 2: Connect the Control Module to the Arduino

- **VCC:** Connect to the **5V** pin on the Arduino.
- **GND:** Connect to any **GND** pin on the Arduino.
- **A0 (Analog Output):** Connect to analog pin **A0** on the Arduino.
- **D0 (Digital Output):** Connect to digital pin **2** on the Arduino.

Required Libraries

- **No external libraries are required.** Just like your previous sound sensor, this code relies completely on built-in standard Arduino functions (`analogRead`, `digitalRead`, and `Serial`). You can upload this code directly without using the Library Manager.