HAUL AND APEX AIR SYSTEMS

Air suspension installation guide

This system includes a compressor, a tank, four air springs, height sensors and a controller. Allow a full day and plan the routing of the lines before drilling anything.

Before you begin

Disconnect the battery. Lay out every part and check it against the packing list.

1. Mount the compressor and tank in the spare wheel well or under the floor, away from the exhaust.
2. Fit the air springs in place of the coil springs. Torque the mount bolts to 25 ft·lb.
3. Route the air lines away from heat and moving parts, with a drip loop at each fitting.
4. Fit the height sensors and connect the harness to the controller.

Steps, continued

5. Wire the power lead through the supplied fuse directly to the battery.
6. Reconnect the battery, fill the tank and leak test every fitting with soapy water.
7. Calibrate the four presets with the controller app before the first drive.

Torque and settings

Bag mount bolts	25 ft·lb
Leak test	Every fitting, soapy water
Working pressure	25 to 120 psi