TT426 — Clamps After a Short Cut

This guide explains how the clamps (profile clamping cylinders) are opened on the TT426 after a **short cut**.

Applies to: **PLC V27.1 and later.**

Behavior

After a cut made in short cut mode:

Part length	Clamps after the cut
Equal to or longer than the **Short Cut Clamp Length** parameter	**Stay closed.** They open when the **Open Clamps** button on the main screen is pressed (Turkish screen: *Baskıları Aç*).
Shorter than the parameter	Open automatically, as before.

- The machine does not continue to the next cut until the clamps are open. The cycle continues once the clamps reach the up position.
- This rule also applies when the next part is a normal (not short) cut. The decision is based on the **cut that was made**.
- On emergency stop the clamps always open.

Operation

1. The short cut is completed; the clamps keep holding the part.
2. Remove or check the part.
3. Press **Open Clamps** at the bottom of the main screen.
4. The clamps open and the machine continues with the next cut.

Parameter

Parameter	Location	Factory value
Short Cut Clamp Length	Service screen → Machining parameters	431.8 mm (17")

The value is saved and kept when the machine is switched off and on.

Earlier versions

Before PLC V27.1, holding the clamps depended on the **next part's** cutting mode: if the part after a short cut was a normal cut, the clamps opened automatically.