

UV84 Choke Settings

Choke settings need to be adjusted as needed to get the desired print quality for both flat and raised prints. Mostly used to help with peaking. Examples below.

Examples of Peaking

Raised Print Peaking

FlatPrint Peaking



**Direct
Color
Systems**

To help stop peaking, in the Corelbyte rip software (green icon) double click the Standard tab then select ##### to see the choke settings. Adjust the choke settings of the desired color in the negative direction to add more color spread to cover the white peaking.



Choke Tips:

Evac maps often need to have the black choke adjusted in the negative to see the lines.