

White Ink Recovery

When there is a power loss the white ink doesnt circulate and needs help circulating again. The dome light will flash amber when its needs recovery.

1. Close the two white ink valves pictured using the cross tool.
2. Push the silver button wait a minute to see if the amber light goes solid. Push it again if the amber light begins blinking again. Do this until the amber light stays solid amber. This indicates that the white ink tanks are filled.
3. Release the white negative pressure valve. See picture.
4. Open the white ink valves and wait 30 seconds.
5. Close the white negative pressure valve.
6. Do a purge and wipe and run a test to see if white is printing properly.



**Direct
Color
Systems**