


Board Pins: PPM_PWM009




Connection for RC read (PPM decoding)



Connection for Servo/Brushless control



Connection for RC read (PPM decoding) and Servo/Brushless control



In this connection, power is supplied to the RC receive from the Raspberry pi