P/N: KIT-AC00006-00

Description: WIRED ETHERNET REPEATER KIT

<u>Alternative names:</u> inline repeater / PoE repeater

What does the kit include?



When do we use it?

There are two common scenarios:

- 1. When installing a WiFi repeater (KIT-AC000007-00) that requires a long CAT5 run. Typically, every 100m of CAT5 run we will need to amplify/repeat the power and data, and install such wired repeater. Our WiFi repeater is an active PoE device and thus the wired repeater needs to be installed in active PoE configuration (as is), to allow the load (Wifi repeater) to negotiate its power requirement from the source (active PoE injector KIT-AC000005-00).
- 2. When installing a remote Sensor Unit, where the customer requires wired data connection (CAT5). Typically, every 100m of CAT5 run we will need to amplify/repeat the data only. As our SU is powered locally, its ETH port is data only. We can't pass power (PoE) to the SU, only data, or we risk damaging it. Thus, the wired repeater needs to be installed in passive PoE configuration. It is fed by KIT-AC000008-00, passive PoE injector (power + data), but outputs data only. To do that, remove both jumpers on the "PoE out" side.



f multiple wired repeaters are needed (very long CAT5 run), those jumpers are removed only rom the last repeater.					