

Assembly-Robot — Standard Operating Procedure

Assembly-Robot — Standard Operating Procedure

1. Purpose
2. Normal operating envelope
3. Idle reasons
4. Faults & corrective actions
5. Preventive maintenance schedule
6. References

Assembly-Robot — Standard Operating Procedure

Audience: Maintenance Tech · Line Manager **Applies to:** Line-C, station 5, Assembly-Robot

1. Purpose

The Assembly-Robot performs the final robotic pick-and-place assembly operations before Leak-Test verifies the sealed subassembly.

2. Normal operating envelope

- Ideal cycle time: **20 s**
- Max acceptable cycle time: **25 s**
- Expected reject rate: **$\leq 2\%$**
- Fault probability per cycle: **0.4 %**
- Input buffer capacity: **5 parts**

3. Idle reasons

idle_reason	Meaning here	First check
Starved	Fastening-Station (station 4) is not feeding parts.	Verify Fastening state.
Blocked	Leak-Test (station 6) cannot accept the assembled part.	Verify Leak-Test state.

4. Faults & corrective actions

4.1 Joint-Calibration

- **Symptoms in telemetry:** fault_type = "Joint-Calibration". Misplacement rejects climb at Leak-Test.
- **Likely root cause:** robot joint encoder zero drifted, or a hard stop was disturbed.
- **Corrective action:**
 1. Run the robot zero-position calibration routine.

2. Re-teach the pick and place positions against the master.
- **Restart criteria:** TCP position within ± 0.5 mm of master.

4.2 Gripper-Fail

- **Symptoms in telemetry:** `fault_type = "Gripper-Fail"`. Part dropped or mis-grasped; downstream Leak-Test reports missing components.
- **Likely root cause:** gripper jaws worn, vacuum loss, or finger positioning sensor failed.
- **Corrective action:**
 1. LOTO. Inspect gripper jaws; replace fingers as needed.
 2. Verify vacuum or pneumatic grip pressure.
 3. Test grip retention with a tare load.
- **Restart criteria:** 10 cycles without drop.

4.3 Encoder-Fault

- **Symptoms in telemetry:** `fault_type = "Encoder-Fault"`. Axis tracking error or robot halts to safe state.
- **Likely root cause:** encoder cable damaged or absolute encoder lost position.
- **Corrective action:**
 1. Check encoder cable and connectors; reseal or replace.
 2. Re-zero the affected axis.
 3. Run a full repeatability test.
- **Restart criteria:** repeatability within ± 0.05 mm at the TCP.

5. Preventive maintenance schedule

- **Daily:** visual check of cables and gripper.
- **Weekly:** TCP verification against master.
- **Monthly:** lubrication of harmonic drives per OEM schedule.
- **Quarterly:** full repeatability test.

6. References

- Maintenance_Workflow_Overview.pdf
- Safety_Lockout_Tagout_Procedure.pdf
- Line-C_04_Fastening-Station_SOP.pdf
- Line-C_06_Leak-Test_SOP.pdf