

SMT-Placement — Standard Operating Procedure

SMT-Placement — Standard Operating Procedure

1. Purpose
2. Normal operating envelope
3. Idle reasons
4. Faults & corrective actions
5. Preventive maintenance schedule
6. References

SMT-Placement — Standard Operating Procedure

Audience: Maintenance Tech · Line Manager · Quality Worker
Applies to: Line-E, station 2, SMT-Placement

1. Purpose

SMT-Placement uses pick-and-place heads to mount surface-mount components onto the PCB before the Reflow-Oven solders them. It is the second-highest fault contributor on Line-E (after Wave-Solder).

2. Normal operating envelope

- Ideal cycle time: **15 s**
- Max acceptable cycle time: **20 s**
- Expected reject rate: **$\leq 3\%$**
- Fault probability per cycle: **0.6 %**
- Input buffer capacity: **5 parts**

3. Idle reasons

idle_reason	Meaning here	First check
Starved	PCB-Loader (station 1) is not feeding boards.	Verify PCB-Loader state.
Blocked	Reflow-Oven (station 3) buffer full.	Verify Reflow-Oven state.

4. Faults & corrective actions

4.1 Nozzle-Clog

- **Symptoms in telemetry:** fault_type = "Nozzle-Clog". Components mis-picked; AOI rejects (downstream) climb.
- **Likely root cause:** debris in pick nozzle, or vacuum line leak.
- **Corrective action:**
 1. Clean the nozzle in ultrasonic.
 2. Verify vacuum at the head.

- **Restart criteria:** 20 successful picks.

4.2 Feeder-Jam

- **Symptoms in telemetry:** `fault_type = "Feeder-Jam"`. Component feeder fails to present the next part.
- **Likely root cause:** carrier tape mis-fed; sprocket worn.
- **Corrective action:**
 1. LOTO. Clear the feeder.
 2. Inspect sprocket; replace if worn.
- **Restart criteria:** stable feed for 10 cycles.

4.3 Vision-Fail

- **Symptoms in telemetry:** `fault_type = "Vision-Fail"`. Placement accuracy errors; rotation offsets exceed spec.
- **Likely root cause:** upward-look camera lens fouled, focus drifted.
- **Corrective action:**
 1. Clean camera lens.
 2. Re-run vision calibration.
- **Restart criteria:** placement accuracy within ± 0.05 mm.

5. Preventive maintenance schedule

- **Daily:** clean nozzles; check vacuum.
- **Weekly:** inspect feeders.
- **Monthly:** camera calibration.
- **Quarterly:** head accuracy verification.

6. References

- Maintenance_Workflow_Overview.pdf
- Line-E_01_PCB-Loader_SOP.pdf
- Line-E_03_Reflow-Oven_SOP.pdf
- Line-E_04_AOI-Inspection_SOP.pdf