

PowerFactory 2021

Technical Reference

DIgSILENT F87REF Restricted Earth Fault Generic Rel

Publisher:

DIgSILENT GmbH Heinrich-Hertz-Straße 9 72810 Gomaringen / Germany Tel.: +49 (0) 7072-9168-0 Fax: +49 (0) 7072-9168-88

info@digsilent.de

Please visit our homepage at: https://www.digsilent.de

Copyright © 2021 DIgSILENT GmbH

All rights reserved. No part of this publication may be reproduced or distributed in any form without written permission of DIgSILENT GmbH.

May 6, 2019 PowerFactory 2021 Revision 892

Contents

1	F87REF Restricted Earth Fault			
	1.1	Intent	1	
	1.2	Functionality	1	
	1.3	Inputs	1	
	1.4	Available Units	1	
	1.5	Outputs	2	

1 F87REF Restricted Earth Fault

1.1 Intent

To simulate the restricted earth fault differential feature.

1.2 Functionality

The F87REF Restricted Earth Fault generic relay model simulates a single phase current magnitude differential element with differential threshold double bias restrain characteristic. An unrestrained threshold is also available. The differential trip can be set with a configurable time delay.

1.3 Inputs

- One 3 phase CT ("Phase Ct" block, StaCt class).
- One single phase CT ("Neutral Ct" block, StaCt class).

1.4 Available Units

Measurement

- One 3phase measurement element ("Phase Measurement" block, *RMS Calculation* enabled, *Filter* FFT [*RelMeasure* class]).
- One neutral measurement element ("Neutral Measurement" block, RMS Calculation enabled, Filter FFT [RelMeasure class]).
- One single phase measurement element ("Differential RMS Meas" block, *RMS Calculation* enabled, *Filter* disabled [*RelMeasure* class]).

Protective elements

- One 3 phase CT adapters ("Phase Adapter" block, [emphRelCtadapt class).
- One single phase CT adapter ("Neutral Adapter" block, [emphRelCtadapt class).
- A differential element with *Type* set equal to *Restricted earth fault* ("Differential" block, [RelBiasidiff class]).

Output logic

• One relay trip element ("Output logic" block, RelLogdip class).

1.5 Outputs

- yout associated by default to the differential element trip (any phase).
- y_s associated by default to the differential element trip (any phase). Its behavior is identical to the *yout* signal and has been added to guarantee compatibility with the *F79 Recloser* generic relay.

The output logic can be configured in the "Logic" tab page of the "Output Logic" block.