

# **PowerFactory 2021**

**Technical Reference** 

**Phase Measurement Device** 

 $ElmPhi\_\_pll$ 

# Publisher:

DIgSILENT GmbH Heinrich-Hertz-Straße 9 72810 Gomaringen / Germany Tel.: +49 (0) 7072-9168-0 Fax: +49 (0) 7072-9168-88

info@digsilent.de

Please visit our homepage at: https://www.digsilent.de

# Copyright © 2020 DIgSILENT GmbH

All rights reserved. No part of this publication may be reproduced or distributed in any form without written permission of DIgSILENT GmbH.

December 1, 2020 PowerFactory 2021 Revision 1

# **Contents**

1	General Description											
2	RMS	RMS-Simulation										
	2.1	Three	e-phase measurement			2						
		2.1.1	Blocking functionality			4						
		2.1.2	Signals			4						
		2.1.3	Calculation parameters			4						
	2.2	Single	e-phase measurement			6						
		2.2.1	Blocking functionality			6						
		2.2.2	Signals			6						
		2.2.3	Calculation parameters			6						
3	EMT	Г-Simul	lation			7						
	3.1	Three	e-phase measurement			7						
		3.1.1	Blocking functionality			8						
		3.1.2	Signals			8						
		3.1.3	Calculation parameters			8						
	3.2	Single	e-phase measurement			8						
		3.2.1	Blocking functionality			9						
		3.2.2	Signals			9						
		3.2.3	Calculation parameters			10						
4	Refe	erence	s			11						
Lis	List of Figures											
Lis	ist of Tables											

i

# 1 General Description

PLLs are widely used for synchronization purposes, controller applications and can also be used to demodulate frequency-modulated signals. For more information about PLL definition and applications refer to [1] and [2].

The *Phase-Locked Loop* element (*ElmPhi\_pll*) measures the frequency and phase of a voltage in the system. The PLL model is supported by the RMS and EMT simulations only.

In the following sections the working and behaviour of the PLL  $\mathit{Model Version}\ 2$  and  $\mathit{Model Version}\ 3$  (parameter  $\mathit{mversion}\ )$  are presented. The  $\mathit{Model Version}\ 2$  supports blocking functionality and single-phase measurement. These features are not available in  $\mathit{Model Version}\ 1$ . Additional difference between the two versions is that in  $\mathit{Model Version}\ 1$ , a gain of  $\mathit{Ki}\cdot \mathit{Ki}\ is$  used for the integrator part of the PI controller and in  $\mathit{Model Version}\ 2$  the gain is, as typical,  $\mathit{Ki}\ .$  The  $\mathit{Model Version}\ 3$  uses the tracking angle between the measured frequency and the nominal frequency to transform the in-quadrature input signals of the PLL. Then, this tracking angle is applied to get the corresponding output.

# 2 RMS-Simulation

The PLL uses as inputs, the voltage at the selected *Measurement Point* (reference node) in the input dialogue box of the PLL.

Depending on the selected No. of Phases option (parameter nphase), a three-phase or single-phase measurement is possible.

# 2.1 Three-phase measurement

The PLL structure is the same for both balanced and unbalanced RMS simulations. Internally, the input signals to the PLL ur and ui are the real and imaginary part of the positive sequence voltage (in-quadrature signals).

In the case of balanced network representation, the positive sequence voltage resulting from the simulation is fed directly to the input signals (uR, uI) of the PLL. In the case of unbalanced network representation, the positive sequence voltage is first being calculated using the symmetrical transformation on the input signals fed to the PLL  $(uR\_A, uI\_A, uR\_B, uI\_B, uR\_C, uI\_C)$ .

The block diagram of the PLL version 2 is presented in Figure 2.1 where the following input parameters are used (connected automatically):

- ur and ui are the in-quadrature input signals of the PLL in p.u.;
- u is the magnitude of the input voltage in p.u.; and
- fref is the frequency of the reference machine in p.u.




Figure 2.1: DIgSILENT PLL block diagram Version 2 (RMS simulation)

The blocks shaded in blue colour are enabled if the blocking functionality is being used. Please refer to Section 2.1.1.

The block diagram of the PLL Version 3 is presented in Figure 2.2 where the following input parameters are used (connected automatically):




Figure 2.2: DIgSILENT PLL block diagram Version 3 (RMS simulation)

The limits on the integrator part of the PI controller for PLL Version 2 and Version 3 are calculated using the parameters fmax and fmin (Upper frequency limit and Lower frequency limit) as follows:

$$Lower \, limit = 2 \cdot \pi \cdot Fnom \cdot fmin - 2 \cdot \pi \cdot Fnom \cdot fref - Kp \cdot dphi \tag{1}$$

$$Upper \ limit = 2 \cdot \pi \cdot Fnom \cdot fmax - 2 \cdot \pi \cdot Fnom \cdot fref - Kp \cdot dphi \tag{2}$$

where:

- fmin is the Lower frequency limit parameter in p.u.;
- fmax is the Upper frequency limit parameter in p.u.;
- Fnom is the nominal frequency in Hz;
- fref is the frequency of the reference machine in p.u.;
- Kp is the proportional gain of the PI controller; and
- *dphi* is the dphi signal (see Figure 2.1).

### 2.1.1 Blocking functionality

In real devices, the angle cannot be tracked if the voltage falls below a certain threshold. The option *Enable Blocking* can be used to simulate this. When this option is enabled, the blue colour shaded blocks in Figure 2.1 are considered in the calculation.

The blocking mode uses the parameters *Blocking voltage* umin (in p.u.) and *Blocking filter time* constant Tb (in ms).

If the voltage magnitude drops below the user defined umin, the PLL goes into blocking mode and the signal block is set to 1. If the magnitude of the voltage rises above umin + 5%, the PLL switches to normal mode and the signal block is set to 0.

The following changes are done when the PLL is in blocking mode:

- The outputs of the two integrators and of the tracking (first-order lag) block are kept constant:
- The frequency is calculated using the angular velocity difference input from the tracking block.

Blocking functionality is available in Version 2 and Version 3.

#### 2.1.2 Signals

sinphi

The signals used in the case of a balanced network representation are presented in Table 2.1. The input signals are automatically connected (internally in *PowerFactory*).

Name Symbol Description Unit Type Input Voltage, Real Part  $\overline{uR}$ IN p.u.IN Input Voltage, Imaginary Part uIp.u.IN frefp.u.Reference Frequency FmeasOUT Measured Frequency HzMeasured Frequency fmeasOUT p.u.State variable of the PI controller STATE x1State variable of the integrator (Phi)x2radSTATE OUT  $\cos(Phi)$ cosphi

 $\sin(Phi)$ 

Table 2.1: Signals for Three-Phase Measurement (Balanced RMS-Simulation)

The signals used in the case of an unbalanced network representation are presented in Table 2.2. The input signals are automatically connected (internally in *PowerFactory*).

OUT

### 2.1.3 Calculation parameters

The calculation parameters used in the three-phase RMS measurement are presented in Table 2.3.

Table 2.2: Signals for Three-Phase Measurement (Unbalanced RMS-Simulation)

Name	Symbol	Unit	Type	Description
$uR\_A$		p.u.	IN	Input Voltage, Phase a, Real Part
$uI\_A$		Hz	IN	Input Voltage, Phase a, Imaginary Part
$uR\_B$		p.u.	IN	Input Voltage, Phase b, Real Part
$uI\_B$		Hz	IN	Input Voltage, Phase b, Imaginary Part
$uR\_C$		p.u.	IN	Input Voltage, Phase c, Real Part
$uI\_C$		Hz	IN	Input Voltage, Phase c, Imaginary Part
fref		p.u.	IN	Reference Frequency
Fmeas		Hz	OUT	Measured Frequency
fmeas		p.u.	OUT	Measured Frequency
x1			STATE	State variable of the PI controller
x2		rad	STATE	State variable of the integrator (Phi)
cosphi			OUT	$\cos(Phi)$
sinphi			OUT	$\sin(Phi)$

Table 2.3: Calculation parameters for Three-Phase Measurement (RMS-Simulation)

Name	Symbol	Unit	Description
Kp			PI controller Proportional Gain
Ki			PI controller Integral Gain
ommax		rad/s	Upper Angular Frequency $(2 \cdot \pi \cdot frnom \cdot fmax)$
ommin		rad/s	Lower Angular Frequency $(2 \cdot \pi \cdot frnom \cdot fmin)$
frnom		Hz	Nominal Frequency
hpi		rad/s	Nominal Angular Frequency
Phi		deg	Voltage Angle
$phi\_AC$		rad	Angle between Phase $a$ and $c$
umin		p.u.	Blocking voltage limit
block			Blocking
Tb		s	Blocking Filter Time Constant

# 2.2 Single-phase measurement

Depending on the *Phase Technology* of the selected *Measurement Point*, the single-phase PLL can measure at phase a, b, c, a-n, b-n or c-n. This can be selected by using the *Measured Phase* it2p parameter.

The in-quadrature signals fed to the PLL algorithm are then automatically selected from the phase voltages depending on the *Measured Phase*.

The block diagram of the single-phase PLL is equal to the three-phase PLL diagram (presented in Figure 2.1).

#### 2.2.1 Blocking functionality

Since the PLL structure of the three-phase PLL and single-phase PLL is the same, please refer to Section 2.1.1.

### 2.2.2 Signals

The signals used in the single-phase RMS model are the same as the signals used for the three-phase measurement in the balanced RMS simulation presented in Table 2.1.

### 2.2.3 Calculation parameters

The calculation parameters used for the single-phase measurement in the RMS model are presented in Table 2.4.

Table 2.4: Calculation parameters for Single-Phase Measurement (RMS-Simulation)

Name	Symbol	Unit	Description
Kp			PI controller Proportional Gain
Ki			PI controller Integral Gain
ommax		rad/s	Upper Angular Frequency $(2 \cdot \pi \cdot frnom \cdot fmax)$
ommin		rad/s	Lower Angular Frequency $(2 \cdot \pi \cdot frnom \cdot fmin)$
frnom		Hz	Nominal Frequency
hpi		rad/s	Nominal Angular Frequency
Phi		deg	Voltage Angle
umin		p.u.	Blocking voltage limit
block		_	Blocking
Tb		s	Blocking Filter Time Constant

# 3 EMT-Simulation

Depending on the selected No. of Phases option (parameter nphase), a three-phase or single-phase PLL measurement is possible. The Model Version 2 and The Model Version 3 are identical.

# 3.1 Three-phase measurement

The block diagram of the PLL is presented in Figure 3.1.

The phase voltages available from the EMT-simulation are set to the input values of the PLL  $u\_a$ ,  $u\_b$  and  $u\_c$ . The internally used voltages in the PLL, ur and ui (Figure 3.1), are calculated by using the  $\alpha\beta$  transformation on the input voltages.




Figure 3.1: DIgSILENT PLL block diagram (EMT simulation)

The blocks shaded in blue colour are used when the blocking functionality is being used. Please refer to Section 3.1.1.

The limits of the integral part of the PI controller are back-calculated using the parameters fmax and fmin (*Upper frequency limit* and *Lower frequency limit*) as:

$$Lower \, limit = 2 \cdot \pi \cdot Fnom \cdot fmin - 2 \cdot \pi \cdot Fnom - Kp \cdot dphi \tag{3}$$

$$Upper \ limit = 2 \cdot \pi \cdot Fnom \cdot fmax - 2 \cdot \pi \cdot Fnom - Kp \cdot dphi$$
 (4)

where:

- fmin is the Lower frequency limit parameter in p.u.;
- fmax is the *Upper frequency limit* parameter in p.u.;

- Fnom is the nominal frequency in Hz;
- Kp is the proportional gain of the PI controller;
- *dphi* is the dphi signal (see Figure 3.1).

### 3.1.1 Blocking functionality

The blocking functionality in the EMT model is very similar to the one in the RMS model. When this option is enabled, the blue colour shaded blocks in Figure 3.1 are enabled.

The following changes are done when the PLL is in blocking mode:

- The outputs of the integrator part of the PI controller of the tracking block are being kept constant;
- The frequency and the angle are calculated using the angular velocity difference input from the tracking block.

### 3.1.2 Signals

The signals used for the three-phase measurement in the EMT model are presented in Table 3.1. The input signals are automatically connected (internally in *PowerFactory*).

Name	Symbol	Unit	Type	Description
$u_{-}a$		p.u.	IN	Input Voltage, Phase a
$u\_b$		p.u.	IN	Input Voltage, Phase b
$u\_c$		p.u.	IN	Input Voltage, Phase c
Fmeas		Hz	OUT	Measured Frequency
fmeas		p.u.	OUT	Measured Frequency
x1			STATE	State variable of the PI controller
x2		rad	STATE	State variable of the integrator ( <i>Phi</i> )
cosphi			OUT	$\cos(Phi)$
sinphi			OUT	$\sin(Phi)$

Table 3.1: Signals for Three-Phase Measurement (EMT-Simulation)

#### 3.1.3 Calculation parameters

The calculation parameters used for the three-phase measurement in the EMT model are presented in Table 3.2.

### 3.2 Single-phase measurement

As in the RMS model, the single-phase PLL can measure at phase a, b, c, a - n, b - n or c - n.

Since the EMT simulation provides only one voltage and the PLL algorithm requires in-quadrature signals, the second signal has to be constructed. The in-quadrature image of the input single-phase signal is created using the Inverse Park Transform [3]. The image signal is constructed

Table 3.2: Calculation parameters for Three-Phase Measurement (EMT-Simulation)

Name	Symbol	Unit	Description
Kp			PI controller Proportional Gain
Ki			PI controller Integral Gain
ommax		rad/s	Upper Angular Frequency $(2 \cdot \pi \cdot frnom \cdot fmax)$
ommin		rad/s	Lower Angular Frequency $(2 \cdot \pi \cdot frnom \cdot fmin)$
frnom		Hz	Nominal Frequency
hpi		rad/s	Nominal Angular Frequency
Phi		deg	Voltage Angle
$phi\_AC$		rad	Angle between Phase $a$ and $c$
umin		p.u.	Blocking voltage limit
block			Blocking
Tb		s	Blocking Filter Time Constant
$v_i n_r$		p.u.	Voltage fed to the PLL algorithm
$v_{-}in_{-}i$		p.u.	Voltage fed to the PLL algorithm

by introducing two low-pass filters in a loop consisting of the direct and inverse Park transformations. The filters use the *Low-Pass Filter Time Constant* T1 in ms. The default value of T1 is selected for a 50Hz system [3].

The single-phase signal from the EMT-simulation and the constructed image signal are fed to the PLL algorithm presented in Figure 3.1.

# 3.2.1 Blocking functionality

Since the PLL structure of the three-phase PLL and single-phase PLL is the same, please refer to Section 3.1.1.

### 3.2.2 Signals

The signals used for the single-phase measurement in the EMT model are presented in Table 3.3. The input signal is automatically connected (internally in *PowerFactory*).

Table 3.3: Signals for Single-Phase Measurement (EMT-Simulation)

Name	Symbol	Unit	Туре	Description
uR		p.u.	IN	Input Voltage
Fmeas		Hz	OUT	Measured Frequency
fmeas		p.u.	OUT	Measured Frequency
x1			STATE	State variable of the PI controller
x2		rad	STATE	State variable of the integrator $(Phi)$
cosphi			OUT	$\cos(Phi)$
sinphi			OUT	$\sin(Phi)$
xd			STATE	State variable d Low-Pass Filter
xq			STATE	State variable q Low-Pass Filter

# 3.2.3 Calculation parameters

The calculation parameters used for the single-phase measurement in the EMT model are presented in Table 3.4.

Table 3.4: Calculation parameters for Single-Phase Measurement (EMT-Simulation)

Name	Symbol	Unit	Description
Kp			PI controller Proportional Gain
Ki			PI controller Integral Gain
ommax		rad/s	Upper Angular Frequency $(2 \cdot \pi \cdot frnom \cdot fmax)$
ommin		rad/s	Lower Angular Frequency $(2 \cdot \pi \cdot frnom \cdot fmin)$
frnom		Hz	Nominal Frequency
hpi		rad/s	Nominal Angular Frequency
Phi		deg	Voltage Angle
umin		p.u.	Blocking voltage limit
block			Blocking
Tb		s	Blocking Filter Time Constant
T1		s	Low-Pass Filter Time Constant (used for both Low-Pass
			Filters)
$v_i n_r$		p.u.	Voltage fed to the PLL algorithm
$v_i n_i$		p.u.	Voltage fed to the PLL algorithm
vd		p.u.	Voltage fed to the d Low-Pass Filter
vq		p.u.	Voltage fed to the q Low-Pass Filter

# 4 References

- [1] R. E. Best. *Phase-Locked Loops: Design, Simulation and Applications.* McGraw Hill, 6 edition, 2007.
- [2] B. K. Bose. *Modern Power Electronics and AC Drivers*. Prentice Hall of India, 1 edition, 2008.
- [3] R. Teodorescu, M. Liserre, and P. Rodriguez. *Grid Converters for Photovoltaic and Wind Power Systems*. Wiley, 2011.

# **List of Figures**

2.1	DIgSILENT PLL block diagram Version 2 (RMS simulation)	2
2.2	DIgSILENT PLL block diagram Version 3 (RMS simulation)	3
3.1	DIgSILENT PLL block diagram (EMT simulation)	7

# **List of Tables**

2.1	Signals for Three-Phase Measurement (Balanced RMS-Simulation)	4
2.2	Signals for Three-Phase Measurement (Unbalanced RMS-Simulation)	5
2.3	Calculation parameters for Three-Phase Measurement (RMS-Simulation)	5
2.4	Calculation parameters for Single-Phase Measurement (RMS-Simulation)	6
3.1	Signals for Three-Phase Measurement (EMT-Simulation)	8
3.2	Calculation parameters for Three-Phase Measurement (EMT-Simulation)	9
3.3	Signals for Single-Phase Measurement (EMT-Simulation)	9
3.4	Calculation parameters for Single-Phase Measurement (EMT-Simulation)	10