

Atlas Sensor Product Manual

The supported operating temperature is between 5 and 40 degrees Celsius.
Operating the device outside this range may reduce measurement accuracy.
The status light flashes amber when the sensor requires calibration.