Distribution – General Data

1. General

Fuel from the firewall mounted shut-off valve is routed through an external supply line up to the engine feed port mounted on the fuel heater (refer to PT6A–34, Engine Maintenance Manual). From the fuel heater, fuel is routed through an external line down the right side of accessory gear case to the base of the engine fuel pump, then from the pump through another external line to the fuel control unit (FCU). For further details of engine fuel distribution refer to PT6A–34, Engine Maintenance Manual.

This Page Intentionally Left Blank