Indicating – General Data

1. General

Engine fuel indicating consists of flow indication only. The fuel flow is measured in pounds per hour displayed on the upper RH corner of the primary flight display, on the engine display window. For aircraft configured for SI units, the fuel flow will be displayed in kilograms per hour.

A. Fuel Flow Indicating System

A fuel flow transmitter is installed in each engine nozzle fuel feed line to indicate the rate at which fuel is being delivered to the engine in pounds per hour or optionally kilograms per hour. The system consists of a fuel flow transmitter located in each engine line from the FCU to the manifold, which are connected to the Data Acquisition Units (DAUs); indication is displayed on the Primary Flight Display (PFD) – engine display window.

B. Fuel Flow Indication

Fuel flow indication is displayed in Lb/H (kg/H) the engine display window.

C. Fuel Flow Transmitter

A fuel flow transmitter is located on each engine in the main nozzle feed line. The transmitter is inserted in the engine main fuel feed line, so that fuel flows through the body of the transmitter causing rotation of a turbine that sends pulses to the DAU, that are translated into fuel flow.

This Page Intentionally Left Blank