Fuselage – General Data

1. General

The fuselage is aluminum alloy, semimonocoque construction consisting of longerons, longitudinal stringers, intercostals, frames, and stressed skin panels. It comprises five permanently attached sections: nose section (stations –21.00 to 60.00); flight compartment (stations 60.00 to 110.00); fuselage forward cabin (stations 110.00 to 262.00); fuselage aft cabin (stations 262.00 to 332.00); and rear fuselage (stations 332.00 to 535.24).

On aircraft with Mod S.O.O. 6168, removable ice shields are provided on both sides of the fuselage, in the plane of the propellers, to give protection from ice which may be shed by the propeller blades.

A. Nose Section (Mod 6/2020 or Mod 6/2160)

The cone-shaped nose section forms a baggage/equipment compartment with access through a door on the left side of the nose. Bonding straps from the door hinge and sill are connected to the fuselage at station 44.00. Removable screens at rear of the baggage compartment provide access to equipment forward of bulkhead at station 60.00. Lightning protection strips on the radome are bonded to the exterior of the nose section via metal tabs connected to the copper mesh. The nose is deemed to be a secondary structure.

B. Flight Compartment

The two-seat flight compartment has an entrance door on each side, with an L–type step and a hand-grip at the pilot's side; a similar step and hand-grip is installed on the co-pilot's side of the aircraft. The compartment rear bulkhead provides entrance from the cabin. Maintenance access to flight controls, hydraulic and heating system components below the flight compartment floor is provided by two hinged doors. The compartment front bulkhead carries the nose gear.

C. Cabin Compartment

The cabin has an entrance door on each side, and the cabin front and rear bulkheads provide entry into the flight compartment and baggage compartment respectively. Accommodation is provided for removable and folding seats and the installation of tie-down devices for cargo when carried in place of seats. Detachable upholstery panels provide access to flight and engine controls, bleed air, heating, a pneumatic package and deicing pipes, if fitted. Fuel tanks occupy the area below the cabin floor.

D. Rear Fuselage

The rear fuselage extends from the rear cabin semi-bulkhead to the tail in a gradual taper. A baggage compartment is provided with an external door on the left side. Access to flight controls cable runs in the rear fuselage is provided through the baggage compartment rear bulkhead.

This Page Intentionally Left Blank