Elevators – General Data

1. General

The elevators each comprise a front and rear spar supported by ribs, nose spar and nose ribs, and skin panels. Two hinge attachments are mounted on the front spar, and a third is located on the flange on the end of the torque tube. When elevators are installed, the torque tube flanges, when aligned and bolted together, also provide maximum up and down travel stops. The left elevator carries the elevator trim tab and the right elevator carries the flap/elevator interconnect tab. Refer to 27-30-00, Elevator Control System – General Data and 27-30-11, Elevator – Maintenance Practices, for details on removal, installation, and rigging of the elevator.

This Page Intentionally Left Blank