Constant Speed Governor – Maintenance Practices

1. Removal/Installation

   A. Remove Constant Speed Governor

      1) Gain access to constant speed governor mounted on top of the engine reduction gearbox.

      2) Disconnect control from governor pitch lever.

      3) Disconnect sense tube at governor.

      4) Remove bolt, washer and nut connecting fuel governor lever to interconnecting rod.

      5) Remove bolt, spacer and nut connecting power lever-operated flexible control fork end to propeller reversing lever.

      6) Remove clevis pin from fork end of beta control valve.

      7) Remove nuts and washers and withdraw governor from mounting studs. Remove gasket.

   B. Install Constant Speed Governor

      1) Examine replacement constant speed governor for signs of external damage.

      2) Install gasket over studs on governor mounting pad. Ensure that raised side of screen faces upward.

      3) Install governor and secure with four washers and self-locking nuts. Torque load nuts to between 170 to 190 pound–inches.

      4) Connect fork end of beta control valve to propeller reversing lever with clevis pin. Secure with washer and cotter pin.

      5) Secure fork end of power lever operated flexible control to reversing lever with bolt, washer and nut. Secure nut with cotter pin.

      6) Connect fuel governor lever to interconnecting rod (inner hole) with bolt, washer and nut. Secure nut with cotter pin.

      7) Connect sense tube to governor. Tighten and lockwire coupling nut.

      8) Adjust propeller pitch and engine power lever-operated controls as necessary (refer to 76-10-00, Power Control – Maintenance Practices).

      9) Carry out engine ground run and complete propeller function checks (refer to 71-00-00, Power Plant (Mod 6/2012) – General Data).

This Page Intentionally Left Blank