Distribution – General Data

1. General

The distribution portion of the oil system consists of two external lines, an oil cooler and bypass valve. Scavenge oil is pumped from the engine accessory case through an external line to the oil cooler bypass valve, which either allows oil through the cooler or bypasses oil to the return line if the temperature is low or cooler is restricted. The external return line transfers the oil from the cooler or bypass valve into the base of the fuel heater, mounted on top of the tank in the engine accessory case.

A. Oil Cooler

The oil cooler is located below the engine accessory case and attached to the bottom of an air exit duct assembly by eight bolts, washers and nuts. The oil cooler is of the honeycomb type and fitted with a bypass valve and drain plug.

This Page Intentionally Left Blank