Landing Gear Charts – General Data

1. General

The charts given in this section relate to the various components associated with landing gear.

A. Cable Charts

Table 1 — Nose Wheel Steering – Cable Chart gives the P/N, end terminations, cable size, length, material and cable proof load figures for all cables associated with the landing gear. When using the chart, refer to 91-00-00, Charts - General – General Data, Cable Charts.

Table 1 Nose Wheel Steering – Cable Chart

CABLE PART NO. & LOCATION	END TERMINATIONS		CABLE SIZE	LENGTH INCHES	MATERIAL & SPEC	PROOF LOAD LBS
	LEFT	RIGHT				
NAS312–17–0180 Right cable to steering valve lever drum.	– – – – – – –	– – – – – – –	– – – –	– – – –	– – – – – –	– – –
C6CF1242–3 Nose wheel steering cable in control column.	MS21260S2 LH (Swaged) CENTER TERMINAL MS20663C2 (Swaged)	MS21260S2 RH (Swaged)	1/16 inch 7 X 7	A1 to B9 127.440 ± 0.120 $B9_L$ = 70.250 ± 0.120	Carbon Steel MIL–W–1511	288
C6CF1251–1 Left cable to steering valve lever drum.	MS20663C2 (Swaged)	MS21260S2 RH (Swaged)	1/16 inch 7 X 7	A3 to B2 28.400 ± 0.120	Carbon Steel MIL–W–1511	288