Supplementary Gear – General Data

1. General

The supplementary gear consists of a leaf spring type tail bumper. The tail bumper leaf spring is installed at the aft end of the rear fuselage, and is attached to the fuselage structure by an axle fitting. A rubber bumper pad, bonded to the center of the spring, together with the leaf spring, absorbs shock on contact with the ground. The front end of the leaf spring is shrouded by a cover.

This Page Intentionally Left Blank