Passenger Compartment Lights (Mod 6/2028) – General Data

1. General

The passenger compartment lights include cabin lighting (commuter interior), passenger reading lights and warning sign lights.

2. Description

A. Cabin Lighting

The cabin lighting system consists of six general cabin lights are installed along the centre line of the cabin roof. The lights are controlled from a three position switch labelled CABIN GENERAL on the lower left pilot sub-panel; the switch positions are labelled DIM, OFF and BRIGHT. The circuit is protected by the circuit breakers identified CABIN LIGHTS on the circuit breaker panel, and powered from the left DC bus. (Refer to 24-60-00, DC Electrical Load Distribution – General Data). When the CABIN GENERAL switch is set to the DIM position a 100 ohm dimming resistor is connected in series with the supply to the cabin lights, reducing the luminance of the cabin lights.

B. Passenger Entrance Light

The entrance light is a threshold floodlight recessed in the top of the main cabin door aperture. The light is controlled by either one of two switches; one on the lower left pilot sub-panel label BOARDING and the other (a rocker type switch) on the fascia immediately forward of the door and labelled BOARDING LIGHTS. The entrance light circuit is powered from the hot battery bus through the COMPT LTS circuit breaker on the rear bulkhead circuit breaker panel.

C. Passenger Reading Lights

Twenty passenger reading lights, six on the left and fourteen on the right, are integral with the cove ventilating ducts in the cabin walls. The lights are controlled from a two-position switch labelled CABIN READING on the lower left pilot sub-panel. A switch beside each light provides passenger control over individual lights. Circuit protection is provided by the READING LIGHTS circuit breakers on the main circuit breaker panel and is powered by the right bus. (Refer to 24-30-00, DC Generation – General Data).

On aircraft incorporating Mod 6/2414, there is a light and switch cover to improve air distribution in the cabin gasper vents. For removal and installation instructions refer to 25-20-02, Cabin Compartment – Cabin Upholstery (Mod 6/2013) – General data, Para 3.

D. Cabin Signs

Two cabin signs with pictograms indication NO SMOKING and FASTEN SEAT BELTS are installed in the cabin to the right of the cabin/flight compartment doorway station 111.00. They are illuminated by lights controlled by a three position switch labelled CABIN SIGNS FSB–NS, OFF and NS on the lower left pilot sub-panel. There are three possible switch positions; both off, no smoking on, and both no smoking and fasten seat belt on. (Refer to 24-30-00, DC Generation – General Data). Power is provided by the MAP LIGHTS circuit breaker on the left bus, and installed in the main circuit breaker panel.

3. Adjustment/Test

A. Operational Test Passenger Boarding Light

1) Switch ON BOARDING switch forward of left cabin door and check that the threshold floodlight illuminates.

2) Switch OFF BOARDING switch on lower pilot sub-panel, and check that the threshold floodlight extinguishes.

3) Check that MASTER and POWER SOURCE switches (Pre Mod 6/2314); or EXTERNAL and BATTERY switches (Post Mod 6/2314) have no effect on entrance light operation.

B. Operational Test Cabin Lights

1) Apply DC power (refer to 12-00-00, Servicing – General Data, Para 2.).

2) Set CABIN GENERAL switch to BRIGHT and check that six cabin dome lights illuminate at full brightness; set switch to DIM and check that lights are dimmed; set switch OFF.

3) Switch ON CABIN READING switch and check each reading light by switching on integral switches.

4) Switch OFF CABIN READING switch.

C. Operational Test Cabin Sign Lights

1) With power ON aircraft buses switch CABIN SIGNS to NS and check that NO SMOKING sign comes on.

2) Switch OFF CABIN SIGNS.

3) Switch ON CABIN SIGNS to FSB–NS and check that FASTEN SEAT BELT/NO SMOKING lights come on.