Cargo and Service Compartment Lights (Mod 6/2028) – General Data

1. General

The cargo and service compartment lights comprise front and rear baggage compartment lights.

2. Forward Baggage Compartment Light

The forward baggage compartment light is operated by an integral switch on the light. The light is powered from the battery bus through the CABIN LIGHTS circuit breaker on the rear bulkhead hot battery bus circuit breaker panel.

3. Rear Baggage Compartment Lights

The rear baggage compartment is illuminated by two dome lights which are operated by a limit switch activated by the rear baggage door latching pins, or when the baggage door is closed, by a switch (labelled BAGGAGE COMP LT) on the aft face of the baggage compartment forward bulkhead. The lights are powered from the hot battery bus through the CABIN LIGHTS circuit breaker on the rear bulkhead (station 332.00) circuit breaker panel. When the rear baggage door is open, BAGGAGE COMP LT switch will not turn the lights off (refer to Table 1 — Operation of Rear Baggage Compartment Lights).

Table 1 Operation of Rear Baggage Compartment Lights

Door Position	Switch Position (BAGGAGE COMP LT)	Lights
Closed	OFF	OFF
Closed	ON	ON
Open	OFF	ON
Open	ON	ON

Note Aircraft with S.O.O. 6393 incorporated do not have a rear baggage compartment door, and the two dome lights in the rear baggage compartment are only operated by the switch (labelled BAGGAGE COMP LT) on the aft face of the baggage compartment forward bulkhead.

4. Adjustment/Test

A. Operational Test Front and Rear Baggage Compartment Lights

Note On aircraft with S.O.O. 6393 incorporated, there is no rear baggage compartment door. In the following test, any reference to close/open the rear baggage door is not applicable.

1) With the rear baggage compartment door closed, switch ON BAGGAGE COMP LT switch on bulkhead at station 332.00 and check that the rear baggage compartment lights come on. Switch OFF BAGGAGE COMP LT switch.

2) Open the rear baggage compartment door and check that lights come on. Close door.

3) Open the front baggage compartment door, check front light by operating integral switch on the light.

4) Check that MASTER and POWER SOURCE switches (Pre Mod 6/2314), or EXTERNAL and BATTERY switches (Post Mod 6/2314) have no effect on front and rear baggage compartment lights operation.

This Page Intentionally Left Blank