Engine Model(s): PT6A

61-20-00

PROPELLER GOVERNOR - DESCRIPTION AND OPERATION

1. General

The propeller governor, installed at the 12 o'clock position on the front case of the reduction gearbox and driven by the propeller shaft through a bevel gear, controls the propeller speed and pitch settings as dictated by the cockpit control settings and flight conditions. Refer to Chapter 76-00-00 for further details of the propeller control system. Refer also to the Airframe Manufacturer's Maintenance Manual, Chapter 61.

2. Fault Isolation

For detailed fault isolation of the propeller governor, refer to Chapter 72-00-00, FAULT ISOLATION.

Printed on 10/NOV/26 P&WC Proprietary – subject to restrictions in Technical Data Agreement