Ejector – Maintenance Practices

1. Removal/Installation

A. Remove Ejector

1) Gain access to compartment, under flight compartment floor, on the left-hand side of fuselage. (Refer to 12-00-00, Servicing – General Data).

2) Slacken and remove recirculated air duct clamps and sleeves. Remove recirculated air duct.

3) Slacken and remove ejector diffuser outlet clamp and sleeve.

4) Slacken and remove clamps and sleeve from hot air valve outlet, and remove pipe between hot air valve and expansion chamber inlet.

5) Remove bolts securing ejector brackets to aircraft structure.

6) Remove ejector, complete with expansion chamber, from aircraft.

7) Remove expansion chamber from ejector.

B. Install Ejector

1) Secure expansion chamber to ejector using a new insulation gasket, bolts and washers.

Note Ensure expansion chamber is located correctly in relation to ejector.

2) Position ejector, complete with expansion chamber, in aircraft.

3) Install bolts to secure ejector brackets to aircraft structure.

4) Install pipe between expansion chamber inlet and hot air valve outlet. Install hot air valve outlet sleeve and clamp, torque clamp to 35 to 45 pound–inches.

5) Install ejector diffuser outlet to silencer duct, sleeve and clamp. Tighten clamp.

6) Install recirculated air duct using sleeves and clamps. Tighten clamps.

7) At subsequent engine ground run check ducts and pipe joints for air leaks.

8) Secure access panel. (Refer to 12-00-00, Servicing – General Data).

This Page Intentionally Left Blank