Hydraulic Pressure Switch – Maintenance Practices

1. Removal/Installation

   A. Remove Hydraulic Pressure Switch

      1) Remove hydraulic power package (refer to 29-10-00, Hydraulic Power Package (Mod 6/2039) – General Data).

      2) Disconnect hydraulic line from pressure switch.

      3) Remove and retain nut, bolt, washer and spacer securing pressure switch clamp to hydraulic package tray. Remove pressure switch.

      4) Cap open hydraulic line and pressure switch inlet.

   B. Install Hydraulic Pressure Switch

      1) Check replacement pressure switch is of the correct type.

      2) Examine pressure switch for signs of damage and corrosion.

      3) Install pressure switch on hydraulic package tray and secure with clamp, bolt, spacer, washer and nut.

      4) Remove blanking caps, connect and secure hydraulic line to pressure switch.

      5) Install hydraulic power package (refer to 29-10-00, Hydraulic Power Package (Mod 6/2039) – General Data).

2. Adjustment/Test

   A. Operational Test Hydraulic Pressure Switch (Pre Mod 6/2313)

      1) With the HYDRAULIC OIL PUMP circuit breaker engaged, apply external power (refer to 12-00-00, Servicing – General Data).

      2) Check hydraulic pump operates, and when hydraulic pressure reaches 1575 ± 50 psi (as registered on hydraulic system indicator), that pump stops.

      3) Operate brake pedals and check hydraulic pump cuts in when hydraulic pressure falls to 150 – 300 psi below the cut out pressure obtained in Para 2.A.2).

      4) Repeat Para 2.A.2) and Para 2.A.3) to recheck cut in and cut out pressures.

   B. Operational Test Hydraulic Pressure Switch (Post Mod 6/2313) (Post Mod 6/2456)

      1) With the HYDRAULIC OIL PUMP circuit breaker engaged, apply external power (refer to 12-00-00, Servicing – General Data).

      2) Check hydraulic pump operates, and when hydraulic pressure reaches <1700 psi (as registered on hydraulic system indicator), that pump stops.

      3) Operate brake pedals and check hydraulic pump cuts in when hydraulic pressure falls to 150 – 350 psi below the cut out pressure obtained in Para 2.B.2) and pump restarts at >1225 psi.

      4) Repeat Para 2.B.2) and Para 2.B.3) to recheck cut in and cut out pressures.

This Page Intentionally Left Blank