Brake Pressure Relief Valve – Maintenance Practices

1. Adjustment/Test

Equipment required:

- Suitable hydraulic test rig

A. Bench Test Brake Pressure Relief Valve

1) Gain access to hydraulic power package, under flight compartment floor, from right hand access panel. (Refer to 12-00-00, Servicing – General Data).

2) Remove brake pressure relief valve from hydraulic power package.

3) Check for obvious damage.

4) Connect relief valve into circuit of suitable test rig.

5) With outlet port to return, slowly apply hydraulic pressure to inlet port.

6) Check that valve cracks open at 1750 + 50 or – 0 psi pressure.

7) Slowly release pressure. Check that valve reseats at 1600 psi minimum pressure.

8) Remove valve from test rig.

9) If required for service, reinstall relief valve in hydraulic power package.

This Page Intentionally Left Blank