Flap System Thermal Relief Valve – Maintenance Practices

1. Adjustment/Test

Equipment required:

- Suitable hydraulic test rig

A. Bench Test Thermal Relief Valve

1) Remove appropriate cabin ceiling panels to gain access to thermal relief valve.

2) Relieve hydraulic system pressure by cycling flaps.

3) Remove thermal relief valve from aircraft.

4) Check for obvious damage.

5) Connect thermal relief valve into circuit of test rig.

6) With outlet port to return, slowly apply hydraulic pressure to inlet port.

7) Check that valve cracks open at 1750 + 50 or – 0 psi pressure.

8) Slowly release pressure. Check that valve reseats at 1575 psi minimum pressure.

9) Remove valve from test rig.

10) If required for service, reinstall relief valve in aircraft.

This Page Intentionally Left Blank