Hydraulic Handpump (Mod 6/2093) – Maintenance Practices

1. Servicing

   A. Bleed Hydraulic Handpump

      1) Ensure electrical power is OFF.

      2) Discharge damping accumulator by operating wing flaps and wheel brake accumulator by pumping brake pedals.

      3) Open access panels on left and right-hand underside of nose section. (Refer to 12-00-00, Servicing – General Data).

      4) Slacken off handpump pressure line at tee of forward accumulator on hydraulic power package. Operate handpump until air has been expelled from line and fluid emerges in solid stream. Retighten handpump pressure line at tee. Stow handpump handle.

      5) Clean up hydraulic fluid spillage. Check reservoir fluid level.

      6) Close access panels. (Refer to 12-00-00, Servicing – General Data).

2. Removal/Installation

   A. Remove Handpump

      1) Discharge damping accumulator by operating wing flaps and wheel brakes accumulator by pumping brake pedals.

      2) Open access panel on left-hand underside of nose section. (Refer to 12-00-00, Servicing – General Data).

      3) Place container to receive spillage. Disconnect and cap return line and pressure line at elbows on handpump.

      4) Remove two bolts attaching handpump to structure and remove handpump.

   B. Install Handpump

      1) Position handpump and attach to structure with two bolts, washers and nuts, ensuring that longer bolt is used at upper attachment point.

      2) Connect return line and pressure line to elbows on handpump.

      3) Check reservoir fluid level. Bleed hydraulic handpump system. Refer to Para 1.A.

      4) Function test handpump. Refer to Para 3.A.

3. Adjustment/Test

   A. Function Test Handpump

      1) Ensure electrical power is switched OFF.

      2) Open access panel on left-hand underside of nose section. (Refer to 12-00-00, Servicing – General Data).

      3) Discharge airframe accumulator by operating wing flaps and wheel brakes accumulator by pumping brake pedals.

      4) Operate handpump and recharge both accumulators. Check that flight compartment hydraulic pressure indicators show same reading as accumulator pressure indicators within tolerance range.

5) Operate wing flaps until damping accumulator pressure is discharged. Check that wheel brakes accumulator pressure remains fully charged.

6) Operate handpump and select wing flaps up and down at random, ending with wing flaps fully up.

7) Recharge airframe accumulator using handpump. Stow handpump handle.

8) Close access panels. (Refer to 12-00-00, Servicing – General Data).