Hydraulic Accumulator Air Charging Valve and Indicator Assembly – Maintenance Practices

1. Adjustment/Test

Equipment required:

- Pressure indicator of proven accuracy

A. Bench Test Pressure Indicator

Note This test applies to both damping and wheel brake accumulators.

1) Discharge system hydraulic pressure by operating wing flaps and brakes.

2) Release accumulator air pressure.

3) Remove air charging valve and indicator assembly from aircraft. Block outlet port.

4) Connect source of nitrogen or dry air and standard indicator of proven accuracy to air charging valve.

5) Apply pressure and increase gradually. At each test pressure point noted in Table 1 — Calibration Tolerances maintain pressure and compare assembly indicator with standard indicator or proven accuracy. Tap indicator gently to obtain true reading.

6) Slowly reduce pressure and check accuracy of indicator at test pressures shown in Table 1 — Calibration Tolerances.

7) Remove block from outlet port, and source of pressure. Cap port.

8) If required for service, install assembly in aircraft.

Table 1 Calibration Tolerances

TEST PRESSURE PSI	TOLERANCE ± PSI
0	30
400	40
800	50
1200	50
1600	50
2000	50

This Page Intentionally Left Blank