Towing and Taxiing – General Data

1. General

CAUTION **ENSURE THAT BRAKE ACCUMULATOR IS FULLY CHARGED TO 1500 PSI BEFORE COMMENCING TO TOW AIRCRAFT.**

Towing the aircraft is accomplished by attaching a towbar, approved by Viking for the aircraft landing gear configuration (refer to PSM 1-6-2T), to the nose wheel axle and disconnecting the nose leg torque links. To connect the tow bar to the nose wheel axle, insert pawl pins through ends of the tow bar into the axle spools, then insert L-shaped locking pins vertically through ends of the tow bar and the groove in pawl pins.

Station a crew member in flight compartment to operate brakes when aircraft is being towed.

This Page Intentionally Left Blank