PTF ALL

Maintenance Message 21-30160 - Fault Isolation

CABIN PRESSURE SELECTOR PANEL HAS A FAULT

DETECTED BY: CABIN PRESSURE CONTROLLER (CPC)-1

CORRECTIVE ACTION SUMMARY

Replace Cabin Pressure Control Module [P5-6]
Repair Wiring D10726-Circuit Breaker C1270
Repair Wiring D10724-Circuit Breaker C1269
Repair Wiring D10724-D10728
Repair Wiring D10724-D10730
Replace Cabin Pressure Outflow Valve [V48]

A. Description

(1) This task is for this maintenance message:

(a) CABIN PRESSURE SELECTOR PANEL HAS A FAULT

B. Initial Evaluation

(1) Do a test of the cabin pressure controller 1. This is the task:

- Cabin Pressure Controller (CPC) BITE Procedure, AMM TASK 21-31-00-740-801.

(2) If the maintenance message shows, then do the Fault Isolation Procedure below.

(3) If the maintenance message does not show, then there was an intermittent fault.

C. Fault Isolation Procedure

(1) Replace the cabin pressure control module, P5-6. These are the tasks:

- Cabin Pressure Control Module Removal, AMM TASK 21-31-02-000-801,
- Cabin Pressure Control Module Installation, AMM TASK 21-31-02-400-801.

(a) Do the test of the cabin pressure controller 1 that you did at the start of this task.

(b) If the maintenance message does not show, then you corrected the fault.

(c) If the maintenance message shows, then continue.

(2) Do this check of the wiring:

(a) Disconnect connector D10726 from the cabin pressure control module, P5-6.

(b) Open the PRESSURIZATION CONTROL AUTO 1 circuit breaker, C1270 [P6-4, F3].

(c) Do a wiring check between this pin of connector D10726 at the cabin pressure control module and this terminal of circuit breaker C1270 (WDM 21-31-22):

D10726		**C1270**
pin 20	.....	term =L

(d) Do a wiring check to make sure that pin 21 of D10726 has continuity to ground.

(e) If you find a problem with the wiring, then do these steps:

1) Repair the wiring.

2) Re-connect connector D10726 to the cabin pressure control module, P5-6.

3) Close the PRESSURIZATION CONTROL AUTO 1 circuit breaker, C1270 [P6-4, F3].

4) Do the test of the cabin pressure controller 1 that you did at the start of this task.

5) If the maintenance message does not show, then you corrected the fault.

(f) If you do not find a problem with the wiring, then continue.

(g) Re-connect connector D10726 to the cabin pressure control module, P5-6.

(h) Close the PRESSURIZATION CONTROL AUTO 1 circuit breaker, C1270 [P6-4, F3].

(3) Do this check of the wiring:

(a) Disconnect connector D10724 from the cabin pressure control module, P5-6.

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details

(b) Open the PRESSURIZATION CONTROL MANUAL circuit breaker, C1269 [P6-4, F6].

(c) Do a wiring check between this pin of connector D10724 at the cabin pressure control module and this terminal of circuit breaker C1269 (WDM 21-31-11):

D10724		C1269
pin 15	.....	term =L

(d) Do a wiring check to make sure that pin 28 of D10724 has continuity to ground.

(e) If you find a problem with the wiring, then do these steps:

1) Repair the wiring.
2) Re-connect connector D10724 to the cabin pressure control module, P5-6.
3) Close the PRESSURIZATION CONTROL MANUAL circuit breaker, C1269 [P6-4, F6].
4) Do the test of the cabin pressure controller 1 that you did at the start of this task.
5) If the maintenance message does not show, then you corrected the fault.

(f) If you do not find a problem with the wiring, then continue.

(g) Close the PRESSURIZATION CONTROL MANUAL circuit breaker, C1269 [P6-4, F6].

(4) Do this check of the wiring:

(a) Disconnect connector D10728 from the cabin pressure outflow valve, V48.

(b) Do a wiring check between these pins of connector D10724 at the cabin pressure control module and these pins of connector D10728 at the cabin pressure outflow valve (WDM 21-31-11):

D10724		D10728
pin 18	.....	pin F
pin 30	.....	pin H
pin 31	.....	pin G

(c) If you find a problem with the wiring, then do these steps:

1) Repair the wiring.
2) Re-connect connector D10724 to the cabin pressure control module, P5-6.
3) Re-connect connector D10728 to the cabin pressure outflow valve, V48.
4) Do the test of the cabin pressure controller 1 that you did at the start of this task.
5) If the maintenance message does not show, then you corrected the fault.

(d) If you do not find a problem with the wiring, then continue.

(e) Re-connect connector D10728 to the cabin pressure outflow valve, V48.

(5) Do this check of the wiring:

(a) Disconnect connector D10730 from the cabin pressure outflow valve, V48.

(b) Do a wiring check between these pins of connector D10724 at the cabin pressure control module and these pins of connector D10730 at the cabin pressure outflow valve (WDM 21-31-11):

D10724		D10730
pin 25	.....	pin A
pin 24	.....	pin B

(c) Do a wiring check to make sure that pin D of D10730 has continuity to ground.

(d) If you find a problem with the wiring, then do these steps:

1) Repair the wiring.
2) Re-connect connector D10724 to the cabin pressure control module, P5-6.
3) Re-connect connector D10730 to the cabin pressure outflow valve, V48.
4) Do the test of the cabin pressure controller 1 that you did at the start of this task.
5) If the maintenance message does not show, then you corrected the fault.

(e) If you do not find a problem with the wiring, then continue.

(f) Re-connect connector D10724 to the cabin pressure control module, P5-6.

(g) Re-connect connector D10730 to the cabin pressure outflow valve, V48.

(6) Replace the cabin pressure outflow valve, V48. These are the tasks:

BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details

- Aft Outflow Valve Assembly Removal, AMM TASK 21-31-03-000-801,
- Aft Outflow Valve Assembly Installation, AMM TASK 21-31-03-400-801.

(a) Do the test of the cabin pressure controller 1 that you did at the start of this task.

(b) If the maintenance message does not show, then you corrected the fault.

--------- END OF CONTENT ---------

EXPORT CONTROLLED:9E991
BOEING PROPRIETARY - Copyright © - Unpublished Work - See title page for details