Bleed Air Shut-off Valve – Maintenance Practices

1. Removal/Installation

   A. Remove Bleed Air Shut-off Valve

      1) Gain access to appropriate engine nacelle.

      2) Disconnect electrical connections from shut-off valve.

      3) Remove valve and pipe insulation as necessary.

      4) Remove the two clamps securing shut-off valve to bleed pipes and remove valve.

   B. Install Bleed Air Shut-off Valve

      1) Examine replacement shut-off valve for signs of damage.

      2) Install valve (solenoid end of valve towards engine) using the two clamps and a new metal O-ring. Tighten clamps and torque to 35 to 45 pound–inches.

      3) Install pipe and valve insulation and wirelock.

      4) Connect electrical connections to valve.

      5) Test bleed air system for leaks. (Refer to 21-40-00, Heating System – General Data).

      6) Complete temperature control system function test. (Refer to 21-60-00, Environmental Control System – General Data).

2. Adjustment/Test

   A. Operational Test – Solenoid

      Note To pressure test the operation of the bleed air shut-off valve, refer to 21-40-00, Heating System – General Data.

      1) Ensure applicable BLEED AIR (L or R) circuit breaker is in.

      2) Apply DC power (refer to 12-00-00, Servicing – General Data, Para 2.).

      3) Select BLEED AIR switch to LEFT or RIGHT as applicable and listen for sound (audible click) of bleed air shut-off valve solenoid operating.

      4) Select BLEED AIR switch to OFF and note similar sound of valve solenoid operating in other direction.

      5) Disconnect DC power (refer to 12-00-00, Servicing – General Data, Para 2.).

This Page Intentionally Left Blank