Hot Air Valve – Maintenance Practices

1. Removal/Installation

   A. Remove Hot Air Valve

      1) Remove hot air valve cover under pilot's seat.

      2) Gain access to compartment under flight compartment floor, through access panel on left-hand side of fuselage. (Refer to 12-00-00, Servicing – General Data).

      3) Remove cover under pilot's seat.

      4) Disconnect electrical wiring from hot air valve.

      5) Remove hot air valve inlet and outlet clamps and sleeves.

      6) Remove hot air valve from aircraft.

   B. Install Hot Air Valve

      1) Examine replacement hot air valve for signs of damage.

      2) Position valve in aircraft, and secure with sleeves and clamps. Torque clamps to 35 to 45 pound–inches.

      3) Connect electrical wiring to hot air valve.

      4) Test environmental control system controls, and function test environmental control system during engine ground run (refer to 21-60-00, Environmental Control System (Mod 6/2014) – General Data). Check disturbed clamp joints for air leaks during initial stage of ground run.

      5) Install cover under pilot's seat and secure nose fuselage access panel. (Refer to 12-00-00, Servicing – General Data).

2. Adjustment/Test

   A. Operational Test

      Note To test the operation of the hot air valve, refer to 21-60-00, Environmental Control System (Mod 6/2014) – General Data, Para 4.A.

**This Page Intentionally Left Blank**