Emergency Shut-off Valve – Maintenance Practices

1. Adjustment/Test

   A. Operational Test

      1) Release lower cowling and allow to swing down.

      2) Apply DC power (refer to 12-00-00, Servicing – General Data, Para 2.).

      3) Ensure applicable FUEL SHUTOFF (L or R) circuit breaker is in.

      4) Select applicable shut-off switch on the emergency panel to FUEL OFF and observe red indicator arm on valve rotates to the closed (down) position.

      5) Select shut-off switch to NORMAL and observe red indicator arm rotates to the open (up) position.

      6) Raise and secure lower cowling.

      7) Disconnect DC power (refer to 12-00-00, Servicing – General Data, Para 2.).

This Page Intentionally Left Blank